

# Steering System

## GENERAL

### STEERING COLUMN & SHAFT STEERING COLUMN / SHAFT

### MECHANICAL POWER STEERING SYSTEM

POWER STEERING GEAR BOX  
POWER STEERING HOSES  
POWER STEERING OIL PUMP

### EPS (ELECTRONIC POWER STEERING) SYSTEM

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



ST -2

STEERING SYSTEM

## GENERAL

## SPECIFICATIONS E52E8BEB

Item		Specifications	
Column and shaft		Shaft and joint type	Collapsible, crossjoint with tilt column
		Steering gear type	Rack and pinion
		Rack stroke mm	146
		Tilt stroke(Manual/Power)	±7°
		Tele stroke(Manual/Power)	30mm
Oil pump	3.3L/3.8L	Type	Vane type
		Displacement	9.6 cc/rev
		Relief pressure	100 ± 4 kgf/cm <sup>2</sup>
Steering angle		Inner	37.68° ± 2°
		Outer	30.71°
		Tie rod end ball joint starting torque	30kg·cm or less

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## GENERAL

## ST -3

## TIGHTENING TORQUE

EC7E7013

Items		Nm	kgf-m	lb-ft
Steering column and shaft	Steering column to column member mounting (upper)	13 ~ 18	1.3 ~ 1.8	9.4 ~ 13
	Steering column to column member mounting (lower)	13 ~ 18	1.3 ~ 1.8	9.4 ~ 13
	Steering column dust cover mounting bolt	13 ~ 18	1.3 ~ 1.8	9.4 ~ 13
	Steering wheel lock nut	40 ~ 50	4 ~ 5	28.9 ~ 36.1
	Joint assembly(upper)	15 ~ 20	1.5 ~ 2.0	10.8 ~ 14.4
	Joint assembly(lower)	18 ~ 25	1.8 ~ 2.5	13 ~ 18
Steering gear box	Wheel nut	90 ~ 110	9 ~ 11	66 ~ 81
	Pressure hose to gear box	12 ~ 18	1.2 ~ 1.8	8.6 ~ 13
	Return tube to gear box	12 ~ 18	1.2 ~ 1.8	8.6 ~ 13
	Tie rod end lock nut	50 ~ 55	5.0 ~ 5.5	36.1 ~ 39.7
	Pinion and valve assembly to self locking nut	20 ~ 30	2 ~ 3	14.4 ~ 21.6
	Yoke plug lock nut	50 ~ 70	5 ~ 7	36.1 ~ 50.6
	Tie rod end self locking nut	24 ~ 34	2.4 ~ 3.4	17.3 ~ 24.5
	Mounting bracket to crossmember	140 ~ 160	14 ~ 16	101 ~ 118
	Steering gear box Mounting	45 ~ 55	4.5 ~ 5.5	33 ~ 39.7
Oil pump	Pressure hose to oil pump	55 ~ 65	5.5 ~ 6.5	39.7 ~ 47
	Oil pump mounting bolt [3.3L],[3.8L]	35 ~ 55	3.5 ~ 5.5	25.3 ~ 39.7
	Pump cover to pump body	18 ~ 22	1.8 ~ 2.2	13 ~ 15.9
	Suction connector to oil pump body	6 ~ 10	0.6 ~ 1	4.3 ~ 7.2
	Flow control valve connector to pump body	55 ~ 65	5.5 ~ 6.5	39.7 ~ 47
Steering hoses and oil reservoir	Oil reservoir bracket mounting bolt	4 ~ 6	0.4 ~ 0.6	2.8 ~ 4.3
	Cooler tube clamp mounting bolt	4 ~ 6	0.4 ~ 0.6	2.8 ~ 4.3
	Tube clip and tube bracket	4 ~ 6	0.4 ~ 0.6	2.8 ~ 4.3
	Pressure hose bracket mounting bolt	4 ~ 6	0.4 ~ 0.6	2.8 ~ 4.3
	Hose clamp	4 ~ 6	0.4 ~ 0.6	2.8 ~ 4.3






## LUBRICANTS

Items	Specified lubircant	Quantity
Steering column bearing	Multipurpose grease SAE J310a, NLGI No.2	As required
Steering gear box rack, pinion gear part	Multipurpose grease SAE J310a, NLGI No.2	As required
Bellows	Silicone grease	As required
Oil pump	Power steering fluid (PSF-3)	As required
Power steering fluid	Power steering fluid (PSF-3)	1.0 lit
Tie rod end ball joint	SUNLIGHT MB-2	4g

## ST -4

## STEERING SYSTEM






## SPECIAL TOOLS E215AE3F

Tool (Number and Name)	Illustration	Use
09222-32100 Valve stem oil seal installer	 EPRF001B	Installation of the oil pump oil seal
09555-21000 Bar	 EPRF001D	Removal and installation of the oil seal (Use with 09573-33100, 09573-33000, 09573-21000)
09561-11001 Steering wheel puller	 EPRF001E	Removal of steering wheel
09568-4A000 Tie rod end puller	 KPRE103I	Separation of the tie rod end bail joint
09572-21000 Oil pressure gauge	 EPRF001F	Measurement of the oil pressure (Use with 09572-22100, 09572-21200)





## GENERAL

## ST -5

<p>09572-21200 Oil pressure gauge adapter</p>	 <p>EPRF001G</p>	<p>Measurement of the oil pressure (Use with 09572-21000, 09572-22100)</p>
<p>09572-22100 Oil pressure gauge adapter</p>	 <p>EPRF001H</p>	<p>Measurement of the oil pressure (Use with 09572-21000, 09572-21200)</p>
<p>09573-21100 Oil seal installer</p>	 <p>EPRF001I</p>	<p>Installation of the back up washer and oil seal (Use with 09753-21000, 09573-33100, 09555-21000)</p>
<p>09573-33100 Oil seal guide</p>	 <p>EPRF001K</p>	<p>Removal and installation of the oil seal (Use with 09573-21000, 09573-33000, 09555-21000)</p>
<p>09432-21600 Braring installer</p>	 <p>APJF001K</p>	<p>Installing the pinion gear bearing</p>

## ST -6

## STEERING SYSTEM

<p>09434-14200 Counter shaft bearing installer</p>	 <p>APJF001M</p>	<p>Installing the gear box oil seal</p>
<p>09565-11100 Preload socket</p>	 <p>APJF001A</p>	<p>Measuring the pinion shaft preload</p>

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## GENERAL

ST -7

## TROUBLESHOOTING

E80E87DD

Symptom	Probable cause	Remedy
Excessive play in steering	Loose yoke plug	Retighten
	Loose steering gear mounting bolts	Retighten
	Loose or worn tie rod end	Retighten or replace as necessary
Steering wheel operation is not smooth (Insufficient power assist)	V-belt slippage	Readjust
	Damaged V-belt	Replace
	Low fluid level	Replenish
	Air in the fluid	Bleed air
	Twisted or damaged hoses	Correct the routing or replace
	Insufficient oil pump pressure	Repair or replace the oil pump
	Sticky flow control valve	Replace
	Excessive internal oil pump leakage	Replace the damaged parts
	Excessive oil leaks from rack and pinion in gear box	Replace the damaged parts
	Distorted or damaged gear box or valve body seals	Replace
Steering wheel does not return properly	Excessive turning resistance of tierod end	Replace
	Yoke plug excessively tight	Adjust
	Tie rod and/or ball joint cannot turn smoothly	Replace
	Loose mounting of gear box mounting bracket	Retighten
	Worn steering shaft joint and/or	Correct or replace
	Worn steering shaft joint and/or body grommet	
	Distorted rack	Replace
	Damaged pinion bearing	Replace
	Twisted or damaged hoses	Reposition or replace
	Damaged oil pressure control valve	Replace
	Damaged oil pump input shaft bearing	Replace
Noise	Hissing Noise in Steering Gear There is some noise with all power steering systems. One of the most common is a hissing sound when the steering wheel is turned and the car is not moving. This noise will be most evident when turning the wheel while the brakes are being applied. There is no relationship between this noise and steering performance. Do not replace the valve unless the "hissing" noise becomes extreme. A replaced valve will also make a slight noise, and is not always a solution for the condition.	
Rattling or chucking noise in the rack and pinion	Interference with hoses from vehicle body	Reposition
	Loose gear box bracket	Retighten
	Loose tie rod end and/or ball joint	Retighten
	Worn tie rod and/or ball joint	Replace
Noise in the oil pump	Low fluid level	Replenish
	Air in the fluid	Bleed air
	Loose pump mounting bolts	Retighten

## ST -8

## STEERING SYSTEM

## SERVICE ADJUSTMENT


## PROCEDURE EF4B5EEB

## CHECKING STEERING WHEEL FREE PLAY

1. Start the engine and with the steering wheel in the straight ahead position.
2. Measure the play while turning the steering wheel to the left and right.

**Standard value :**

Steering wheel free play : 30 mm (1.1 in)



KPBF010C

3. If the play exceeds the standard value, inspect the connection between the steering shaft and tie rod ends.

## CHECKING STEERING ANGLE


1. Place the front wheel on a turning radius gauge and measure the steering angle.

**Standard value :**

Wheel angle

Inside wheel  $39.17^{\circ} \pm 2^{\circ}$ Outside wheel  $31.56^{\circ}$ 


2. If the measured value is not within the standard value, adjust the toe and inspect again.



EPRF010A

CHECKING THE TIE ROD END BALL JOINT  
STARTING TORQUE

1. Disconnect tie rod and knuckle with the special tool (09568-4A000).



KPBF010E

## GENERAL


ST -9

2. Shake the ball joint stud several times to check for looseness.

---

**Tie rod end ball joint starting torque :**  
30 kg-cm or less

---



KPBF010F

3. If the starting torque exceeds the upper limit of the standard value, replace the tie rod end.
4. Even if the starting torque is below the lower limit of the standard value, check the play of the ball joint and replace if necessary.

**CHECKING STEERING WHEEL RETURN**

1. The force required to turn the steering wheel and the wheel return should be the same for both moderate and sharp turns.
2. When the steering wheel is turned 90° and held for a couple of seconds while the vehicle is being driven at 20-30 kph (12-19 mph), the steering wheel should return at least 20° from its central position when it is released.

**NOTE**

*If the steering wheel is turned very quickly, steering may be momentarily difficult. This is not a malfunction because the oil pump output will be somewhat decreased.*



KPBF010G

**CHECKING POWER STEERING BELT TENSION**

Refer to EM group(Timing system).

**CHECKING POWER STEERING FLUID LEVEL**

1. Position the vehicle on a level surface.
2. Start the engine. With the vehicle kept stationary, turn the steering wheel several times continuously to raise the fluid temperature to 50-60°C (122-140°F).
3. With the engine at idle, turn the steering wheel fully clockwise and counter-clockwise several times.
4. Make sure that there is no foaming or cloudiness in the reservoir fluid.


## ST -10

## STEERING SYSTEM

5. Stop the engine and check for any difference in fluid level between a stationary and a running engine.

**NOTE**

1. If the fluid level varies 5 mm (0.2 in) or more, bleed the system again.
2. If the fluid level suddenly rises after stopping the engine, further bleeding is required.
3. Incomplete bleeding will produce a chattering sound in the pump and noise in the flow control valve, and lead to decreased durability of the pump.



KPBFO10H

**REPLACING POWER STEERING FLUID**

1. Jack up the front wheels and support them with jack-stands.
2. Disconnect the return hose from the oil reservoir and plug the oil reservoir.
3. Connect a vinyl hose to the disconnected return hose, and drain the oil into a container.
4. Disconnect the high-tension cable at the ignition coil side. While operating the starter motor intermittently, turn the steering wheel all the way to the left and then to the right several times to drain the fluid.
5. Connect the return hoses, then fill the oil reservoir with the specified fluid.
6. Start the engine. Check for oil leakage.
7. Stop the engine.
8. Bleed the system.

**Power steering fluid type : PSF-3**

Total quantity : Approx 1.0 liter

**AIR BLEEDING**

1. Disconnect the high tension cable, and while operating the starting motor intermittently (for 15-20 seconds), turn the steering wheel all the way to the left and then to the right five or six times.

**NOTE**

1. During air bleeding, replenish the fluid supply so that the level never falls below the lower position of the filter.
2. If air bleeding is done while the vehicle is idling, the air will be broken up and absorbed into the fluid. Be sure to do the bleeding only while cranking.
3. Connect the high tension cable, and start the engine(idling).
4. Turn the steering wheel to the left and the right until there are no air bubbles in the oil reservoir.

**CAUTION**

**Do not hold the steering wheel turned all the way to either side for more than ten seconds.**


5. Confirm that the fluid is not milky, and that the level is up to the position specified on the level gauge.
6. Confirm that there is little change in the surface of the fluid when the steering wheel is turned left and right.

**CAUTION**

1. If the surface of the fluid changes considerably, air bleeding should be done again.
2. If the fluid level rises suddenly when the engine is stopped, it indicates that there is still air in the system.
3. If there is air in the system, a jingling noise may be heard from the pump and the control valve may also produce unusual noises. Air in the system will shorten the life of the pump and other parts.

## GENERAL

## ST -11




KPB010J

## OIL PUMP PRESSURE TEST (OIL PUMP RELIEF PRESSURE)

1. Disconnect the pressure hose from the oil pump. Connect the special tool between the oil pump and pressure hose as illustrated.
2. Bleed the air, and then start the engine and turn the steering wheel several times so that the fluid temperature rises to approximately 50°C (122°F).
3. Set the engine speed to 1,000 rpm.
4. Close the shut-off valve of the special tool and measure the fluid pressure to confirm that it is within the range.

## standard vaule :

Relief pressure: 90 +3/-2 kgf/cm<sup>2</sup>

EPRF002B

5. Remove the special tools, and tighten the pressure hose to the specified torque.

## Tightening Torque Nm(kgf-m, lb-ft) :

55 ~ 65(5.5 ~ 6.5, 39.7 ~ 47)

6. Bleed the system.

## ⚠ CAUTION

*Don' t keep the shut-off valve on the pressure gauge closed for longer than seconds.*




ST -12

STEERING SYSTEM

## STEERING COLUMN & SHAFT

### STEERING COLUMN / SHAFT

#### COMPONENTS EE8A2FB4



- |                             |                                   |
|-----------------------------|-----------------------------------|
| 1. Steering wheel           | 5. Steering column shaft assembly |
| 2. Key lock assembly        | 6. Steering column upper shroud   |
| 3. Dust cover assembly      | 7. Steering column lower shroud   |
| 4. Universal joint assembly | 8. Multifunction switch           |

EPBF500A




## STEERING COLUMN &amp; SHAFT


ST -13

## REMOVAL E8272C54

1. Disconnect the negative (-) terminal(A) from the battery.



APIE102B




EPBF500K


2. Loosen the tapping screws and lift up the horn pad and remove it.
3. Remove the lock nut and the washer.

**! CAUTION**


Before doing these procedures, see the SRS section (RT Group. Only for vehicle equipped with SRS).



EPBF500L



EPBF500W



EPBF500X

4. Remove the steering wheel with (09561-11001).

**! CAUTION**

Do not hammer on the steering wheel to remove it may cause the damage to the collapsible mechanism.



## ST -14

## STEERING SYSTEM

5. Remove the lower cover(A).

[RHD]


[LHD]



EPBF500N

EPBF500M

6. Remove the steering column lower and upper shrouds.




EPBF500O

## STEERING COLUMN &amp; SHAFT

ST -15


7. Disconnect the connectors and remove the multifunction switch.



EPBF500P

9. Remove the dust cover mounting bolts.


[LHD]



KPB101H


8. Remove the bolts securing the coupling and universal joint. Pull out the universal joint from the gear box.

[LHD]




KHB140F

[RHD]




EPRF700G

[RHD]



EPBF500Q

10. Remove the steering column mounting bolts (4bolts).



KPB101I

11. Remove the steering column and shaft with the universal joint and cover.


## ST -16

## STEERING SYSTEM

## DISASSEMBLY EB261A91


## KEY LOCK ASSEMBLY

1. If it is necessary to remove the key lock assembly(A), use a punch to make a groove on the head of the special bolt(B), and then use a screwdriver to remove the key lock assembly mounting bracket(C).



KPBF111A

2. Disassemble the key lock assembly(A) from the steering column and shaft assembly(B).




KPBF111B

3. Reassembly is reverse of disassembly.


## UNIVERSAL JOINT ASSEMBLY

1. Remove the bolt(A) connecting the universal joint assembly(B) and the steering column and shaft assembly(C).



KPBF111C

2. Remove the universal joint assembly(A) from the steering column and shaft assembly(B).



KPBF111D

3. Reassembly is reverse of disassembly.

## STEERING COLUMN &amp; SHAFT

ST -17

## INSPECTION

E1CCD66E

1. Check the steering shaft for damage, play and round-movement.
2. Check the upper and lower bearing for wear or damage.
3. Check the joints for excessive play, damage or rough-movement.
4. Check the tilt bracket for cracks or damage.
5. Check the cover or boot for damage.
6. Check that the steering lock mechanism operates properly. If necessary, replace.

## REASSEMBLY

EEAA2192

1. Reassembly is reverse of the removal.
2. Make parallel the steering shaft's groove to the hook of the steering lock, when installing the steering lock-assembly.

## INSTALLATION


EFEECD62

1. Before installation, grease the inner side of the bearing, the boot, and the dust cover
2. Install the steering column mounting bolts(A) and nuts(B)

**Tightening Torque Nm(kgf-m, lb-ft) :**  
13 ~ 18(1.3 ~ 1.8, 9.4 ~ 13)

**! CAUTION**

**Connect the universal joint to the pinion shaft of the gear box in advance.**




KPDF101I

3. Install the dust cover mounting nuts(A).


**Tightening Torque Nm(kgf-m, lb-ft) :**  
13 ~ 18(1.3 ~ 1.8, 9.4 ~ 13)

[LHD]



KPDF101H

[RHD]



EPRF700G


## ST -18

## STEERING SYSTEM

4. Install the connecting bolt(A) between the universal joint and the pinion shaft.


**Tightening Torque Nm(kgf-m, lb-ft) :**  
18 ~ 25(1.8 ~ 2.5, 13 ~ 18)

[LHD]




KHBF140F

[RHD]




EPBF500Q

5. Install the multifunction switch(B) mounting screws(A) and the connectors.



EPBF500P

6. Install the steering column lower(A) and upper(B) shrouds.



EPBF500O




## STEERING COLUMN &amp; SHAFT

ST -19


7. Install the crush pad lower cover(A).

[LHD]



EPBF500Y

[RHD]




EPBF500Z

8. Install the steering wheel locking nut(A).

**Tightening Torque Nm(kgf-m, lb-ft) :**  
 40 ~ 50(4 ~ 5, 28.9 ~ 36.1)


**NOTE**

Check that the front wheels is in the right direction in advance.




EPBF500K

9. Install the two steering wheel cover(A) bolts by using the hexagon wrench.




EPBF500X



EPBF500W

10. Connect the negative (-) terminal(A) to the battery.



APIE102B


ST -20

STEERING SYSTEM

# MECHANICAL POWER STEERING SYSTEM


## COMPONENTS E401C9A1

[LHD]



[RHD]

اولین سامانه دیجیتالی تعمیرکاران خودرو در ایران



1. Bellows
2. Rack housing
3. Feed tube

4. Valve body assembly
5. Tie rod assembly
6. Lock nut

EPBF500V



## MECHANICAL POWER STEERING SYSTEM


ST -21

## POWER STEERING GEAR BOX

## COMPONENTS

E15DDC7A

[LHD]




- |                          |  |                  |
|--------------------------|--|------------------|
| 1. Feed tube             | 9. Rack support spring                     | 17. Bellows clip |
| 2. Valve body housing    | 10. Rack support yoke                      | 18. Bellows      |
| 3. Bolt                  | 11. Rack housing                           | 19. Bellows band |
| 4. Oil seal              | 12. Power steering gear box mounting clamp | 20. Tie rod      |
| 5. Pinion valve assembly | 13. Oil seal                               | 21. Circlip      |
| 6. Oil seal              | 14. Rack                                   | 22. Oil seal     |
| 7. Yoke plug             | 15. Tie rod end                            | 23. Rack stopper |
| 8. Lock nut              | 16. Lock nut                               |                  |

EPRF700P

## ST -22

## STEERING SYSTEM

[RHD]



- |                          |  |                  |
|--------------------------|--|------------------|
| 1. Feed tube             | 9. Rack support spring                     | 17. Bellows clip |
| 2. Valve body housing    | 10. Rack support yoke                      | 18. Bellows      |
| 3. Bolt                  | 11. Rack housing                           | 19. Bellows band |
| 4. Oil seal              | 12. Power steering gear box mounting clamp | 20. Tie rod      |
| 5. Pinion valve assembly | 13. Oil seal                               | 21. Circlip      |
| 6. Oil seal              | 14. Rack                                   | 22. Oil seal     |
| 7. Yoke plug             | 15. Tie rod end                            | 23. Rack stopper |
| 8. Lock nut              | 16. Lock nut                               |                  |


EPRF700Q

## MECHANICAL POWER STEERING SYSTEM

ST -23

## REMOVAL E54305AB

1. Loosen the wheel nuts slightly.  
Raise the front of the vehicle, and make sure it is securely supported.
2. Remove the front wheel and tire(A) from front hub(B).




EIRF101A

**CAUTION**


Be careful not to damage the hub bolts(C) then remove the front wheel and tire(A).

3. Drain the power steering fluid.
4. Disconnect the pressure hose and the retrun tube.




KPB211A

5. Remove the pressure sensor connector(A) from the pressure hose




KPB222A

6. Remove the nut(B) from the stabilizer bar link(A).



KHRE110B


7. Using the specil tool(09568-4A000) disconnect the tie rod end from the knuckle arm.



EPBF500G


## ST -24

## STEERING SYSTEM




KHBf105B

8. Remove the lower arm mounting bolts(A).



KHBf140D

9. Remove the front fork and the knuckle ball joint from the front lower arm.




KHBf140E

**CAUTION**

**Be careful not to damage to the aluminium lower arm.**


10. Remove the joint assembly connecting bolt.

[LHD]




KHBf140F

[RHD]



EPBF500Q

11. Remove the connecting bolts of front and rear roll stopper.




KHBf301A

## MECHANICAL POWER STEERING SYSTEM


ST -25

12. Remove the mounting bolts(10EA) of cross member complete assembly.

[RHD]



KHB301C



EPRF700L


13. Remove the heat protecting cover(A) mounting bolts(B).

**CAUTION**


*When removing the gear box, pull it out carefully and slowly to avoid damaging the boots.*

15. Disconnect the pressure hose and the retrun tube.

[LHD]



KPB301E




KPB301D


14. Remove the steering gear box mounting bolts and remove the steering gear box assembly and the mounting rubber.

[LHD]

[RHD]



KPRE301E




EPRF700K

## ST -26

## STEERING SYSTEM


## DISASSEMBLY E6CAB1AD

1. Remove the tie rod end(B) from the tie rod(A).




KPBF202A

2. Remove the dust cover(B) from the ball joint(A).




EPBF500H

3. Remove the bellows band(A).



KPBF006F

4. Remove the bellows clip(A).




EPKE013I

5. Pull the bellows out toward the tie rod.

**NOTE**

Check for rust on the rack when the bellows are replaced.

6. Remove the feed tube(A) from the rack housing.



APHE006H


7. While moving the rack slowly, drain the fluid from the rack housing.



## MECHANICAL POWER STEERING SYSTEM


ST -27

8. Unstake the tab washer(A) which fixes the tie rod(B) and rack(C) with a chisel.



EPKE037A

11. Remove the yoke plug(B) with a 14mm socket(A).




KPBF006L

9. Remove the tie rod(B) from the rack(A).


**! CAUTION**

**Remove the tie rod(B) from the rack(A), taking care not to twist the rack.**




KPBF006J

12. Remove the lock nut(D), yoke plug(C), rack support spring(B) and rack support yoke(A) from the gear box.



APJF005L

10. Remove the yoke plug locking nut(A).



KPBF006K


## ST -28

## STEERING SYSTEM

13. When the end of the circlip comes out of the notched hole of the housing rack cylinder, turn the rack stopper counterclockwise and remove the circlip.


**CAUTION**

*Be careful not to damage the rack.*



EPKE013Q

14. When the end of the circlip comes out of the notched hole of the housing rack cylinder, turn the rack stopper counterclockwise and remove the circlip.




EPKE013R

**CAUTION**

*Be careful not to damage the rack.*


15. Remove the rack bushing and rack from the rack housing.

16. Remove the O-ring(A) from the rack bushing(B).




EPKE013T

17. Remove the oil seal(B) from the rack bushing(A).



EPKE013U

18. Remove the valve body from the valve body housing with a soft hammer.



EPKE210A

19. Using the special tool, remove the oil seal and ball-bearing from the valve body housing.



## MECHANICAL POWER STEERING SYSTEM

ST -29

20. Remove the oil seal and O-ring from the rack housing.


**CAUTION**

**Be careful not to damage the pinion valve cylinder inside of the rack housing.**

21. Using the special tool(09573-33100, 09555-21000), remove the oil seal(A) from the rack housing.


**CAUTION**

**Be careful not to damage the rack cylinder inside of the rack housing.**



2. Pinion valve

- 1) Check for pinion gear tooth face damage or wear.
- 2) Check for oil seal contact surface damage.
- 3) Check for seal ring damage or wear.
- 4) Check for oil seal damage or wear.



APJF013Z

3. Bearing

- 1) Check for seizure or abnormal noise during abearing rotation.
- 2) Check for excessive play.
- 3) Check for missing needle bearing rollers.

4. Others

- 1) Check for damage of the rack housing cylinder bore.
- 2) Check for boot damage, cracking or aging.

**INSPECTION**

EA7CDA9B

1. Rack

- 1) Check for rack tooth face damage or wear.
- 2) Check for oil seal contact surface damage.
- 3) Check for rack bending or twisting.
- 4) Check for oil seal ring damage or wear.
- 5) Check for oil seal damage or wear.



LPJF006C

## ST -30

## STEERING SYSTEM

## REASSEMBLY

EA4ABAC8


1. Apply the specified fluid to the entire surface of the rack oil seal.

---

Recommended fluid : PSF-3

---

2. Install the backup washer and oil seal(A) to the specified position in the rack housing.



KPBFO07F


3. Apply the specified fluid to the entire surface of the rack bushing oil seal.

---

Recommended fluid : PSF-3

---

4. Install the oil seal(A) in the rack bushing(B).



EPKE230B

5. Apply the specified fluid to the entire surface of the O-ring and install it in the rack bushing.

6. Apply the specified grease to the rack teeth.


---

Recommended grease  
Multipurpose grease SAE J310a NLGI No.2

---


**NOTE**

*Do not plug the vent hole(A) in the rack with grease.*



APJF014E

7. Insert the rack(A) into the rack housing(B) and install the rack bushing(C).



EPKE230I


## MECHANICAL POWER STEERING SYSTEM

ST -31


8. Push in the rack stopper until the circlip groove of the rack stopper is aligned with the notched hole of the rack housing. Then, install the circlip while turning the rack stopper.

**CAUTION**

*The circlip should not be visible through the notched hole of the rack housing.*




9. Using special Tool(09432-21600), install the oil seal and the ball bearing in the valve body(A).




APGE008G

10. After applying the specified fluid and grease to the pinion valve assembly(A), install it in the rack housing assembly.



EPKE230E

11. After applying the specified fluid to the oil seal, install it in the rack housing and fix the valve body assembly(A) and O-ring in the gear box(B).




APHE007F

## ST -32

## STEERING SYSTEM


12. Install the rack support yoke(A), rack support spring(B), yoke plug(C) and lock nut(D) in the order shown in the illustration. Apply semi-drying sealant to the threaded section of the yoke plug before installation.



APJF005L


13. With the rack placed in the center position, attach the yoke plug to the rack housing. Tighten the yoke plug to 12 Nm (120 kg-cm, 8.9 lb-ft), with a 14mm socket(A). Loosen the yoke plug approximately from 30° to 60° and tighten the yoke nut to the specified torque.

**Tightening Torque Nm(kgf-m, lb-ft) :**  
50 ~ 70(5 ~ 7, 37 ~ 52)



APHE007I


14. Tighten the feed tube(A) to the specified torque and install the mounting rubber using adhesive.



APHE006H

15. Apply the specified grease to the bellows mounting position (fitting groove) of the tie rod.

Recommended grease : Silicone grease



APGE008C

16. Install the new attaching band to the bellows.

**NOTE**

*When the bellows are installed, a new band must be used.*

17. Install the bellows in position, taking care not to twist it.

## MECHANICAL POWER STEERING SYSTEM

ST -33


18. Fill the dust cover inner side and lip with the specified grease, and fix the dust cover in position with the clip ring attached in the groove of the tie rod end.

Recommended grease

A : POLY LUB GLY 801K or equivalent


B : SHOWA SUNLIGHT MB2 or equivalent

Dust cover inner side and lip : THREE BOND




EPKE043A

19. Install the tie rod(A) to the tie rod end(B).



KPB202A

20. Check for total pinion preload.




APHE006B

## INSTALLATION

E5D30F7E

## NOTE

Be sure to connect between a tube and a hose as shown in the illustration.



APJF009A

1. Installation is reverse of removal.

## TIGHTENING TORQUE Nm(kgf-m, lb-ft)

Pressure hose to gear box :

12~18(1.2~1.8, 8.6~13)

Return tube to gear box :

12~18(1.2~1.8, 8.6~13)

Tie rod end lock nut :

50~55(5~5.5, 36.1~39.7)

Pinion and valve assembly to self locking nut :

20~30(2~3, 14.4~21.6)

lock nut :

50~70(5~7, 36.1~50.6)

Tie rod end self locking nut :

24~34(2.4~3.4, 17.3~24.5)

Mounting bracket to crossmember :

60~80(6~8, 43.3~57.8)


2. After installation, bleed the air in the power steering system(See page ST-10).

ST -34

STEERING SYSTEM

## POWER STEERING HOSES

## COMPONENTS E1AFD16E



1. Power steering oil reservoir
2. Suction hose
3. Oil pump
4. Pressure hose

5. Power steering gear box
6. Return tube
7. Cooler tube


EPBF500D

## MECHANICAL POWER STEERING SYSTEM

ST -35

## REMOVAL E1AFEC1C


While installing the tube and hose assembly, be sure to align white marks on each fitting.



KPB301A

4. Remove the return tube and hose.

[LHD]




KPB304D

## PRESSURE HOSE, TUBE AND RETURN TUBE, HOSE


1. Remove the mounting clamps from the pressure tube and the return tube.

[LHD]




KPB302B

[RHD]



EPRF7000

2. Remove the fitting of both the pressure tube and the return tube from the gear box.
3. Remove the pressure hose and tube.



KPB303C

## INSTALLATION E5DC84CE

Installation is the reverse of removal.

**NOTE**

- Install the return tube and hoses so that they are not twisted and it does not come in contact with any other parts.
- After installation, air bleed the system.




ST -36

STEERING SYSTEM

## POWER STEERING OIL PUMP

## COMPONENTS EBC21FCC



TORQUE : Nm (kgf·m, lb-ft)

1. Rear cover
2. Snap ring
3. Gasket
4. Vanes
5. Rotor

6. Cam ring
7. Front side plate
8. O-ring (Outer)
9. O-ring (Inner)
10. Front housing

11. Flow control spring
12. Flow control valve
13. Connector
14. Pulley
15. Suction pipe

EPBF500E




## MECHANICAL POWER STEERING SYSTEM

ST -37

## REMOVAL


E64E3B0B

1. Remove the pressure hose from the oil pump and the suction hose from the suction pipe, then drain the powersteering oil.



KPB211A

4. Remove the powersteering oil pump assembly by removing the three bolts as shown below.




KPB401D

## DISASSEMBLY


E41A4D99

2. Release the tension of the powersteering V-type belt by lifting the auto-tensioner pulley.



KPB401B


1. Remove the bolts from the oil pump body, and then remove the suction pipe and O-ring.



KPB402A

3. Remove the V-type belt from the pulley of the powersteering oil pump.

2. Remove the power steering oil pump rear cover(A) and the O-ring(B) by removing the four bolts.




KPB412A

ST -38


STEERING SYSTEM

3. Remove the cam ring.




KPBF412D

6. Remove the oil pump side plate.




KPBF412E

4. Remove the cam ring.




KPBF412B

7. Remove the inner O-ring and outer O-ring.




KPBF412F

5. Remove the rotor and vanes.



KPBF412C

8. Remove the pulley and the shaft(A).




KPBF412G

## MECHANICAL POWER STEERING SYSTEM


ST -39

9. Remove the oil seal from the oil pump body.



KPB402D

10. Remove the connector from the oil pump body, and take out the flow control valve and the flow control spring.



KPB412H

11. Remove the O-ring from the connector.

**CAUTION**

**Do not disassemble the flow control valve.**

**INSPECTION**


EA05A7C8

1. Check that the flow control valve is not bent.
2. Check the shaft for wear and damage.
3. Check the V-belt for wear and deterioration.
4. Check the grooves of the rotor and vanes for stratified abrasion.
5. Check the contact surface of the cam ring and vanes for stratified abrasion.
6. Check vanes for damage.
7. Check that there is no striped wear in the side plate or contacting part between the shaft and the pump cover surface.

**REASSEMBLY**


EC78610A

1. Install the flow control spring, the flow control valve and the connector in to the pump body.



KPB412H

2. Install the oil seal in the pump body by using the special tool(09222-32100).




KPB404B

ST -40


STEERING SYSTEM

3. Install the pump pulley.




KPBF412G

6. After inserting the lock pin into the groove of the front housing, install the camring attending to the direction.




KPBF404F

4. Install the outer(A) and inner(B) O-rings




KPBF414D

7. Install the rotor.




KPBF414E

5. Install the side plate(A).



KPBF412E

8. Install the vanes.




KPBF414F

## MECHANICAL POWER STEERING SYSTEM

ST -41

10. Install the suction pipe and O-ring.


**Tightening Torque Nm(kgf-m, lb-ft) :**  
 6 ~ 10(0.6 ~ 1, 4.3 ~ 7.2)




EPRF401D

9. After installing the O-ring(A) and the snap ring(C), install the rear cover assembly(B).


**Tightening Torque Nm(kgf-m, lb-ft) :**  
 18 ~ 22(1.8 ~ 2.2, 13 ~ 15.9)



KPBF414H



KPBF424G



KPBF414G

## ST -42

## STEERING SYSTEM


## INSTALLATION

EBFE3F36

1. Install the oil pump to the oil pump bracket.

**Tightening Torque Nm(kgf-m, lb-ft) :**

35 ~ 55(3.5 ~ 5.5, 25.3 ~ 39.7)



KPDF401D

2. Install the "V"-type belt by pulling the auto tensioner.
3. Install the suction hose.

**CAUTION**

**Install the pressure hose to the oil pump.**


4. Install the pressure hose to the oil pump.

**Tightening Torque Nm(kgf-m, lb-ft) :**

55 ~ 65(5.5 ~ 6.5, 39.7 ~ 47)

**NOTE**

*Install the pressure hose being careful so that it does not twist and come in contact with other components.*



KPDF211A




## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -43

## EPS (ELECTRONIC POWER STEERING) SYSTEM

## GENERAL E7A2FF5F

The electronic power steering (EPS) system includes the same components of conventional power steering system.



EPS performs the conventional power steering function in case a failure has occurred in the system. EPS electronically controls the current to the solenoid of by-pass valve by inputting sensor's signals to control the hydraulic amount in cylinder chamber and thereby varying the steering effort versus the hydraulic pressure according to vehicle speed. In addition, it has a solenoid valve on power steering gear box, and a control unit underneath the audio of the center fascia. To control the oil flow of steering gear box, a solenoid is provided and it functions by the current from control module which receives signals from VSS (Vehicle Speed Sensor) and TPS.




ST -44

STEERING SYSTEM

**REMOVAL AND INSTALLATION** EED98798

The removal and installation procedure is the same as that of conventional power steering system except for the solenoid valve components and EPS control module. Refer to the following figures.



KPB500D

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -45

ELECTRONIC POWER STEERING  
CONTROL MODULE

E8F19C24



دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

## PIN LAYOUT

PIN NO.	DESCRIPTION
1	Solenoid
2	Solenoid
3	Sensor signal from vehicle speed sensor
4	IG2
5	Data link connector
6	Sensor signal from TPS
7	-
8	Ground

EPBF5001

## STEERING SYSTEM

## EAABCA6A



## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -47

## TROUBLESHOOTING

E7A90FA2

**NOTE**

For checking procedures for each problem, refer to the flow-chart type of troubleshooting guide on the following page.

**Trouble symptom 1**

Steering effort remains light at moderate and high speeds

**NOTE**

1. Check to be made by using the scan tool or test lamp.
2. Refer to the circuit diagram for terminal numbers at the harness side of the E.P.S control module.

Does the stationary steering effort change within the standard value ?

**Standard value :**

E.P.S.

2.4 N (2.5 kg, 5.1 lbs) Max.

No

Malfunction of E.P.S. solenoid

Repair the steering gear box or replace the E.P.S. solenoid

Yes

Is the function of the vehicle speed sensor normal?

No

Replace vehicle speed sensor

Yes

Repair the connector connection or repair the harness (Connect the connector, or repair the harness between the vehicle speed sensor and the control module)


EPRF502A

## ST -48

## STEERING SYSTEM

## Trouble symptom 2


No flow of solenoid current (large steering effort required to turn steering wheel fully) when the ignition switch is at the ON position.



EPRF502B

## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -49



EPRF502C


DTC	Trouble	Condition	Measure time	Disposal	
C1101	Voltage over	IG[V] > 17V	1sec	Solenoid control stop	10V < IG[V] < 16V
C1102	Voltage under	IG[V] > 8V	1sec	Solenoid control stop	10V < IG[V] < 16V
C1212	Vehicle speed sensor	TPS > 30% over and vehiclespeed 0km/h	60sec	Vehicle speed : 80km/h	Vehicle speed > 5km/h
C1604	ECU error	EEPROM Read/Write fail andPWM management error	1sec	Solenoid control stop	IGN ON/OFF
C2230	Solenoid current error	Measure voltage > 1.28A	1sec	Solenoid control stop	Power ON reset
		Solenoid disconnection	1sec		
		Target voltage-Measuervoltage > 0.2A and IG[V] > 13V	2sec		

ST -50

STEERING SYSTEM

**DTC C1101 BATTERY VOLTAGE HIGH****COMPONENT LOCATION**

E97277B3



EPRF602A

**GENERAL DESCRIPTION**

EBF87DB7

EPS CM precisely controls the EPS solenoid's current, according to the vehicle speed. The value of the controlled current, according to voltage changes, are minute, and power is provided by IG2. EPS CM does monitor IG2 voltage to monitor excessive rises and drops in voltage. Current control is limited which prevents, damage to the EPS CM due to over-voltage, and operation of the EPS CM at low voltage.

**DTC DESCRIPTION**

EA850CB5

Trouble code occurs when high voltage is caused by a fault in the charging system or IG2 power circuit. EPS CM prohibits solenoid current control by monitoring IG2 battery voltage of EPS CM.

**DTC DETECTING CONDITION**

EEEE98F3

Item	Detecting Condition	Possible cause
<b>DTC strategy</b>	Voltage monitoring	<ul style="list-style-type: none"> <li>- Open in ground circuit</li> <li>- Contact resistance in connections.</li> <li>- Faulty battery voltage</li> </ul>
<b>Enable conditions</b>	IG key "ON"	
<b>Threshold value</b>	IG2 > 17V	
<b>Diagnosis time</b>	1 sec	
<b>Fail safe</b>	Prohibit solenoid's current control ( 0 A ) Restoration condition : 10V < IG2(V) < 16V ⇒ When the voltage is restored to normal from over voltage, restart solenoid's current control.	



## EPS (ELECTRONIC POWER STEERING) SYSTEM


ST -51

## MONITOR SCANTOOL DATA E16E12F3

1. Connect scantool to Data Link Connector(DLC).
2. Start engine and turn the headlight and the heatwire on.
3. Monitor the "BATTERY VOLTAGE" parameter on the scantool.
4. Maintaining ENG. RPM at 2,500RPM(idle) over 2 minutes.

## ■ Specification

	IG Key ON	ENG. ON
Bat. Voltage	Approx. 11.8V~12.5V	Approx. 12.5V~14.5V



BPCE601B

5. Is parameter within specifications?

**YES**

⇒ Fault is intermittent and caused either by poor contact in connectors or wiring harness, or it has been repaired and EPS CM memory is not cleared yet. Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Go to "W/Harness Inspection" procedure.

## ST -52

## STEERING SYSTEM

## TERMINAL AND CONNECTOR INSPECTION EDCEDFBB

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

⇒ Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Go to ""Charging System Inspection"" procedure.

## CHARGING SYSTEM INSPECTION EA9BFA1A

1. Engine "ON", headlight and horn "ON".
2. Measure voltage between terminal (+) and (-) of battery maintaining ENG. RPM at 2,500RPM(idle) over 2 minutes.

## ■ Specification

	IG Key ON	ENG. ON
Bat. Voltage	Approx. 11.8V~12.5V	Approx. 12.5V~14.5V

3. Is the measured voltage within specifications?

**YES**

⇒ Go to "Power Circuit Inspection" procedure.

**NO**

⇒ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage from battery to alternator and fault in charging system.  
Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -53


## POWER CIRCUIT INSPECTION

EBCF3E95

1. Ignition "OFF".
2. Disconnect EPS CM connector.
3. Engine "ON", headlight and heatwire "ON".
4. Measure voltage between terminal "4" of EPS CM harness connector and chassis ground maintaining ENG. RPM at 2,500RPM(idle) over 2 minutes.

## ■ Specification

	IG Key ON	ENG. ON
Bat. Voltage	Approx. 11.8V~12.5V	Approx. 12.5V~14.5V



شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



5. Is the measured voltage within specifications?

**YES**

⇒ Go to "Ground Circuit Inspection" procedure.

**NO**

⇒ Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage.  
Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

## ST -54


## STEERING SYSTEM

## GROUND CIRCUIT INSPECTION

E3BAD232

1. Ignition "OFF".
2. Disconnect EPS CM connector.
3. Measure resistance between terminal "8" of EPS CM harness connector and chassis ground.

■ Specification : Approx. 0  $\Omega$



4. Is the measured resistance within specifications?

**YES**

⇒ Substitute with a known-good EPS CM and check for proper operation.  
If the problem is corrected, replace EPS CM and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Check for open or contact resistance in ground harness.  
Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

## VERIFICATION OF VEHICLE REPAIR

ED1D3D48

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present ?

**YES**

⇒ Go to the applicable troubleshooting procedure.

**NO**

⇒ System performing to specification at this time.

## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -55

**DTC C1102 BATTERY VOLTAGE LOW****COMPONENT LOCATION**

EFA63D86

Refer to DTC C1101

**GENERAL DESCRIPTION**

EE97FC3D

Refer to DTC C1101

**DTC DESCRIPTION**

E02BBE82

Refer to DTC C1101

**DTC DETECTING CONDITION**

ECF85A0B

Item	Detecting Condition	Possible cause
<b>DTC strategy</b>	Voltage check	<ul style="list-style-type: none"> <li>- Open/short in power.</li> <li>- Contact resistance in connections.</li> <li>- Poor contact of fail-safe relay.</li> <li>- Faulty charging system.</li> <li>- Low idle rpm.</li> <li>- Loose alternator belt tension.</li> </ul>
<b>Enable conditions</b>	IG key "ON"	
<b>Threshold value</b>	IG2 < 8V	
<b>Diagnosis time</b>	1 sec	
<b>Fail safe</b>	Prohibit current control of EPS solenoid ( 0 A ) Restoration condition : 10V < IG2(V) < 16V ⇒ When the voltage is restored to normal from low voltage, restart solenoid's current control "	

**MONITOR SCANTOOL DATA**

E17D2FAC

Refer to DTC C1101

**TERMINAL AND CONNECTOR INSPECTION**

EA41C87A

- Many malfunctions in the electrical system are caused by poor harness and terminals.  
Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage.
- Has a problem been found?

**YES**

⇒ Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Go to "Charging System Inspection" procedure.

## ST -56

## STEERING SYSTEM

## CHARGING SYSTEM INSPECTION

EA3B2FDC

1. Engine "ON", headlight and heatwire "ON".
2. Measure voltage between terminal (+) and (-) of battery maintaining ENG. RPM at 2,500RPM(idle) over 2 minutes.

## ■ Specification

	IG Key ON	ENG. ON
Bat. Voltage	Approx. 11.8V~12.5V	Approx. 12.5V~14.5V

3. Is the measured voltage within specifications?

**YES**

⇒ Go to "Power Circuit Inspection" procedure.

**NO**

⇒ Check for fault in charging system and check for tension of alternator drive belt, ENG.idle rpm or open/short in harness from battery to alternator.

Repair as necessary and then go to "Verification of Vehicle Repair" procedure.


## POWER CIRCUIT INSPECTION

EEAA20E1

1. Ignition "OFF".
2. Disconnect EPS CM connector.
3. Engine "ON", headlight and heatwire "ON".
4. Measure voltage between terminal "4" of EPS CM harness connector and chassis ground maintaining ENG. RPM at 2,500RPM(idle) over 2 minutes.

## ■ Specification

	IG Key ON	ENG. ON
Bat. Voltage	Approx. 11.8V~12.5V	Approx. 12.5V~14.5V



1. EPS solenoid "+"
2. EPS solenoid "-"
3. Vehicle speed
4. IG 2
5. OBD
6. TPS PWM
8. Ground

BPCE601C

**EPS (ELECTRONIC POWER STEERING) SYSTEM****ST -57**

5. Is the measured voltage within specifications?

**YES**

⇒ Substitute with a known-good EPS CM and check for proper operation.

If the problem is corrected, replace EPS CM and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Check for open/short to ground in power harness.

Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





ST -58

STEERING SYSTEM

**DTC C1212 VEHICLE SPEED SENSOR****COMPONENT LOCATION** E2E0C30B

EPRF602E

**GENERAL DESCRIPTION** ED23CCD1

Speed sensor is a sensor which applies a principal of Hall-effect and is located at speedmeter driven gear of transaxle. If output shaft of transaxle rotates, the rotation of Rotor which has 4 teeth inside the sensor generate a hall effect and outputs the digital pulse. EPS CM detects vehicle speed based on digital pulse signal and controls amount of current of solenoid valve which controls driving force of steering wheel.

**DTC DESCRIPTION** EA61B55B

Trouble code occurs when a faulty circuit related to the sensor is detected or when an open/short is detected in the speed sensor circuit. EPS CM detect trouble code and sets solenoid current values according to corresponding 80kph(48mph) values, to reserve driving stability.

**DTC DETECTING CONDITION** E6F1FDC2

Item	Detecting Condition	Possible cause
<b>DTC strategy</b>	Signal check	<ul style="list-style-type: none"> <li>- Open/short in power circuit</li> <li>- Open/short in signal circuit</li> <li>- Open in ground circuit</li> <li>- Contact resistance in connections.</li> <li>- Faulty circuit to use VSS</li> <li>- Faulty sensor</li> </ul>
<b>Enable conditions</b>	IG key "ON"	
<b>Threshold value</b>	TPS PWM > 30% vehicle speed < 0 kph(0mph)	
<b>Diagnosis time</b>	60 sec	
<b>Fail safe</b>	Fixing solenoid current value corresponding to 80kph(48mph) Restoration : Normal vehicle speed 5kph(0.8mph) of input for 1sec	

## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -59

## SIGNAL WAVEFORM

E08D60EC




Fig1) Driving : Vehicle speed sensor output 8.0~12.5V(HIGH SIGNAL) or 0.2~0.5V(LOW SIGNAL), as the vehicle moves, the 50% of digital duty wave is output. ( As vehicle speed increase, Hz increase)

Fig2) Engine RPM signal at idle (TPS PWM duty 10%)

Fig3) Engine RPM signal at acceleration (TPS PWM duty 45%)


BPCE603B

## MONITOR SCANTOOL DATA

E62D0229

1. Connect scantool to Data Link Connector(DLC).
2. Start engine and monitor the "VEHICLE SPEED SENSOR" parameter on the scantool.
3. Drive the vehicle approx.80kph(48mph) watching the speedometer on the instrument panel.

■ Specification : [Current data value - speedometer value] ≤ [ ± 10 % ]



BPCE603C

## ST -60

## STEERING SYSTEM

4. Is parameter within specifications?

**YES**

⇒ Fault is intermittent and caused either by poor contact in connectors or wiring harness, or it has been repaired and EPS CM memory is not cleared yet. Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Go to "W/Harness Inspection" procedure.

**TERMINAL AND CONNECTOR INSPECTION** EAAC1E11

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage.
- Has a problem been found?

**YES**

⇒ Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Check DTC on engine, A/T and other systems which use VSS.

▶ If DTC is detected DTC only in EPS, go to "Signal Circuit Inspection" procedure.

▶ If DTC is detected DTC in other systems also, remove speedometer driven gear and check damage of gear.

→ If Speedometer driven gear is damaged, change it and then go to "Verification of Vehicle Repair" procedure.

→ If Speedometer driven gear is normal, go to "Power Circuit Inspection" procedure.

**POWER CIRCUIT INSPECTION** EC9977DA


- Ignition "OFF".
- Disconnect vehicle speed sensor connector.
- Engine "ON".
- Measure voltage between terminal "1" of vehicle speed sensor harness connector and chassis ground.

■ Specification : Approx. B+

## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -61

&lt; N-03 &gt;



1. Power supply
2. Sensor Ground
3. Sensor signal

BPCE603D

5. Is the measured voltage within specifications?

**YES**

⇒ Go to "Ground Circuit Inspection" procedure.

**NO**


⇒ Check for open/short to ground in power harness.  
Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**GROUND CIRCUIT INSPECTION** EE715533

1. Ignition "OFF".
2. Disconnect vehicle speed sensor connector.
3. Measure resistance between terminal "2" of Vehicle speed sensor harness connector and chassis ground.

■ Specification : Approx. 0 Ω

&lt; N-03 &gt;



1. Power supply
2. Sensor Ground
3. Sensor signal

EPRF603E

## ST -62

## STEERING SYSTEM

4. Is the measured resistance within specifications?

**YES**

⇒ Go to "Signal Circuit Inspection" procedure.

**NO**


⇒ Check for open/short to power in ground harness.

Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

## SIGNAL CIRCUIT INSPECTION

EBDBEE5D

1. Ignition "OFF".
2. Connect Scantool to Data Link Connector(DLC).
3. Start engine and select "SCOPEMETER FUNCTION" on scantool.
4. Drive the vehicle and measure output signal between terminal "3" of EPS CM harness connector and chassis ground.  
■ Specification : Refer to 'Signal Waveform'



BPCE603F

5. Is vehicle speed sensor output signal within specifications?

**YES**

⇒ Substitute with a known-good EPS CM and check for proper operation.

If the problem is corrected, replace EPS CM and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Check for open/short to ground in signal circuit and other systems which use VSS.

Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

If a problem hasn't found, go to "Component Inspection" procedure.

## EPS (ELECTRONIC POWER STEERING) SYSTEM


ST -63

## COMPONENT INSPECTION

EFEA3BCD

1. Ignition "OFF".
2. Connect Scantool to Data Link Connector(DLC).
3. Start engine and select "SCOPEMETER FUNCTION" on scantool.
4. Drive the vehicle and measure output signal between terminal "3" of Vehicle speed sensor harness connector and chassis ground.

&lt; N-03 &gt;



1. Power supply
2. Sensor Ground
3. Sensor signal

■ Specification : Refer to 'Signal Waveform'

5. Is vehicle speed sensor output signal within specifications?

YES

⇒ Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

⇒ Check vehicle speed sensor for contamination, deterioration, or damage.


Substitute with a known-good vehicle speed sensor and check for proper operation.

If the problem is corrected, replace vehicle speed sensor and then go to "Verification of Vehicle Repair" procedure.



ST -64

STEERING SYSTEM

**DTC C1604 ECU HARDWARE ERROR****COMPONENT LOCATION** EADC45EC

EPBF500J

**GENERAL DESCRIPTION** E1F86DC4

EPS has a solenoid valve on power steering gear box, and a EPS CM underneath the audio center facia. EPS CM which receives signals from VSS (Vehicle Speed Sensor) and TPS controls the oil flow of steering gear box. EPS CM performs the conventional power steering function in case a failure has occurred in the system. EPS CM electronically controls the current to the solenoid of by-pass valve by inputting sensor's signals to control the hydraulic amount in cylinder chamber and thereby varying the steering effort versus the hydraulic pressure according to vehicle speed.

**DTC DESCRIPTION** E1A7C0D3

This DTC is about general error of inside EPS CM. If this DTC is set, check unstable power or excessive surge influx by faulty power supply and chassis ground.

**DTC DETECTING CONDITION** EAC60287

Item	Detecting Condition	Possible cause
<b>DTC strategy</b>	Voltage monitoring	<ul style="list-style-type: none"> <li>- Contact resistance in ground circuit.</li> <li>- Surge in power circuit.</li> <li>- Faulty EPS CM</li> </ul>
<b>Enable conditions</b>	IG key "ON"	
<b>Threshold value</b>	EEPROM read/write fail PWM management error	
<b>Diagnosis time</b>	1 sec	
<b>Fail safe</b>	Prohibit solenoid current control ( 0 A ) IG2 ON/OFF	




## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -65

## SCHEMATIC DIAGRAM

E8DCCF83




## [CONNECTION INFORMATION]

M70	Connected to	Fuction
1	N-01 terminal 1	Solenoid(+)
2	N-02 terminal 2	Solenoid(-)
3	N-03 terminal 3	Vehicle speed
4	IG SWITCH	Power(IG2)
5	-	DTC
6	B-01 terminal A30	TPS
8	-	Ground

## MONITOR SCANTOOL DATA

E5C9C4C4

1. Ignition "OFF" and connect scantool to Data Link Connector(DLC).
2. Ignition "ON" Engine "OFF".
3. Select "DIAGNOSTIC TROUBLE CODES" mode and monitor "Diagnostic Trouble Code".
4. Clear DTC and drive the vehicle within DTC Enable conditions in General Information.



BPCE604B

BPCE604C

## ST -66

## STEERING SYSTEM

5. Is "C1604" present ?

**YES**

⇒ Fault is intermittent and caused either by poor contact in connectors or wiring harness, or it has been repaired and EPS CM memory is not cleared yet. Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Go to "W/Harness Inspection" procedure.

## TERMINAL AND CONNECTOR INSPECTION E4AFFCBF

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage.
- Has a problem been found?

**YES**

⇒ Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Go to "Power Circuit Inspection" procedure.



## POWER CIRCUIT INSPECTION EFB0DC3F

- Ignition "OFF".
- Connect Scantool to Data Link Connector(DLC) and start engine.
- Select "SCOPEMETER FUNCTION" on scantool and accelerate engine.
- Measure output signal between terminal "4"of EPS CM harness connector and chassis ground with switching (A/C,headlight etc.).

■ Specification : Surge always must not happen when turn IG key ON, OFF with turn the electricity device ON, OFF.

## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -67



1. EPS solenoid "+"
2. EPS solenoid "-"
3. Vehicle speed
4. IG 2
5. OBD
6. TPS PWM
8. Ground

BPCE604E

5. Is the resistance measured within specifications?

**YES**

⇒ Go to "Ground in power harness" procedure.

**NO**

⇒ Check for contact resistance in connections or open in power harness.

Repair as necessary and then go to "Verification of Vehicle Repair" procedure.


## GROUND CIRCUIT INSPECTION

E165624A

## 1.CHECK FOR OPEN IN GROUND HARNESS

1. Ignition "OFF".
2. Disconnect EPS CM connector.
3. Measure resistance between terminal "8" of EPS CM harness connector and chassis ground.

■ Specification : Approx. 0 Ω



1. EPS solenoid "+"
2. EPS solenoid "-"
3. Vehicle speed
4. IG 2
5. OBD
6. TPS PWM
8. Ground

BPCE604F

## ST -68

## STEERING SYSTEM

4. Is the resistance measured within specifications?

**YES**

⇒ Go to "Check for earthing in ground harness" as below.

**NO**



⇒ Check for open or contact resistance in ground harness.

Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

## 2.CHECK FOR EARTHING IN GROUND HARNESS

1. Ignition "OFF".
2. Connect Scantool to Data Link Connector(DLC) and start engine.
3. Select "SCOPEMETER FUNCTION" on scantool and accelerate engine.
4. Measure output signal between terminal "8" of EPS CM harness connector and chassis ground with switching (A/C,headlight etc.).

■ Specification : Surge always must not happen when turn IG key ON, OFF with turn the electricity device ON, OFF.



1. EPS solenoid "+"
2. EPS solenoid "-"
3. Vehicle speed
4. IG 2
5. OBD
6. TPS PWM
8. Ground

BPCE604H

5. Is the output signal within specifications?

**YES**

⇒ Go to "Component Inspection " procedure.

**NO**

⇒ Check for open or poor earthing in ground harness.

Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**EPS (ELECTRONIC POWER STEERING) SYSTEM****ST -69****COMPONENT INSPECTION** EAF9F5FA

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Clear DTC.
3. Drive the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present ?

**YES**

⇒ Check EPS CM for damage or sticking by the naked eye. Substitute with a known-good EPS CM and check for proper operation.

If the problem is corrected, replace EPS CM and then go to "Verification of vehicle Repair" procedure.

**NO**

⇒ Substitute with a known-good EPS CM and check for proper operation.

If the problem is corrected, replace EPS CM and then go to "Verification of Vehicle Repair" procedure.

دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



ST -70

STEERING SYSTEM


**DTC C2230 SOLENID****COMPONENT LOCATION** E5DDAE5D

EPRF602S

**GENERAL DESCRIPTION** E8C48A9C

EPS CM controls current amounts to the solenoid valve which adjust driving force of steering wheel, based on vehicle speed information received from the vehicle speed sensor. The EPS solenoid maintains proper steering force by adjusting fluid amounts into the EPS valvebody according to current values.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Current value HIGH : Handle light

Currentvalue LOW : Handle heavy

Solenoid control current Vs Vehicle speed  
( Vehicle speed increase, solenoid current value is decreased )

BPCE605B

**DTC DESCRIPTION** EC1B81DD

If an open/short is detected in the solenoid circuit. or current value is under/over, while EPS CM is monitoring solenoid's current, EPS CM sets this trouble and the current value will be controlled "0".



## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -71

## DTC DETECTING CONDITION

EE4A56AC

Item	Detecting Condition		Possible Cause
DTC Strategy	Current check		<ul style="list-style-type: none"><li>- Open/short in power circuit and control circuit</li><li>- Contact resistance in connections.</li><li>- Faulty solenoid</li></ul>
Enable Conditions	IG key "ON"		
Threshold Value		Diagnostic Time	
Measuer current > 1.28A		1 sec	
Solenoid open		1 sec	
[target current-measure current] > 0.2A and IG(V) > 13V		2 sec	
Fail Safe	Prohibit solenoid 's current control ( 0 A ) Restoration condition : Power ON reset		

## SPECIFICATION

EBAC1F6B

Solenoid resistance	Frequency	Duty
5.7~7.7Ω [at 20℃(68°F)]	125/333 Hz	5~95%

## SIGNAL WAVEFORM

ED9EF678




Fig 1) Normal signal waveform which is the current control at idle (1A).

Fig 2) Signal waveform which is the current decrease by vehicle speed increase.

BPCE605C

## MONITOR SCANTOOL DATA

EF5A65FC

1. Ignition "OFF" and connect scantool to Data Link Connector(DLC).
2. Ignition "ON" Engine "OFF".
3. Select "DIAGNOSTIC TROUBLE CODES" mode and monitor "Diagnostic Trouble Codes(DTCs)".



1.1 DIAGNOSTIC TROUBLE CODES	1.2 CURRENT DATA 01/04
C2238 SOLENOID OPEN, SHORT TO GND/B+	01. BATTERY VOLTAGE 13.3 V
	02. THROTTLE P. SENSOR 11 %
	03. EPS SOL.VALVE CURR. 0.99 A
	04. VEHICLE SPEED SNSR 0 MPH
NUMBER OF DTC : 1 ITEMS	
HELP ERAS FLOW PART	FIX PART FULL HELP GRPH RCRD

Fig1

Diagnostic Trouble Code (abnormal)

Fig2

Sensor current data (abnormal)

BPCE605D

4. Is parameter within specifications?

**YES**

⇒ Fault is intermittent and caused either by poor contact in connectors or wiring harness, or it has been repaired and EPS CM memory is not cleared yet. Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage.  
Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Go to "W/Harness Inspection" procedure.

## TERMINAL AND CONNECTOR INSPECTION

EB026EB9

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage.
- Has a problem been found?

**YES**

⇒ Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

⇒ Go to "Power Circuit Inspection" procedure.

## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -73


## POWER CIRCUIT INSPECTION

E2A9DBA7

1. Ignition "OFF".
2. Disconnect solenoid connector.
3. Engine "ON".
4. Measure voltage between terminal "1" of solenoid harness connector and chassis ground.

■ Specification : Approx. B+

&lt; N-02 &gt;



- 1.Solenoid (+)
- 2.Solenoid (-)

5. Is the voltage measured within specifications?

YES


⇒ Go to "Control Circuit Inspection" procedure.

NO

⇒ Measure voltage between terminal "1" of EPS CM harness connector and chassis ground in above condition.

■ Specification : Approx. B+

&lt; N-01 &gt;



1. EPS solenoid "+"
2. EPS solenoid "-"
3. Vehicle speed
4. IG 2
5. OBD
6. TPS PWM
8. Ground

BPCE605F

► If it is normal, Check for open/short to ground or control harness in power harness. Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

## ST -74

## STEERING SYSTEM


► If it is abnormal, substitute with a known-good EPS CM and check for proper operation. If the problem is corrected, replace EPS CM and then go to "Verification of Vehicle Repair" procedure.

## CONTROL CIRCUIT INSPECTION

EC16C8C9

1. Ignition "OFF".
2. Disconnect solenoid connector and EPS CM connector.
3. Measure resistance between terminal "2" of solenoid harness connector and terminal "2" of EPS CM harness connector.

■ Specification : Approx. 0  $\Omega$



- |                    |           |                |
|--------------------|-----------|----------------|
| 1.EPS solenoid (+) | 5.OBD     | 1.Solenoid (+) |
| 2.EPS solenoid (-) | 6.TPS PWM | 2.Solenoid (-) |
| 3.Vehicle speed    | 7.Space   |                |
| 4.IG 2             | 8.Ground  |                |

4. Is the measured resistance within specifications?

**YES**

- ⇒ Check for short to ground in control harness.
- If it is normal, go to "Component Inspection" procedure.
- If it is abnormal, repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

- ⇒ Check for open/short to ground in control harness.
- Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

## COMPONENT INSPECTION

E5D9BAB3

## CHECK EPS SOLENOID


1. Ignition "OFF".
2. Disconnect EPS solenoid connector.
3. Measure resistance between terminal "2" and terminal "1" of solenoid harness connector (To sensor side).

■ Specification : 5.7~7.7 $\Omega$  [at 20 $^{\circ}$ C (68 $^{\circ}$ F)]

## EPS (ELECTRONIC POWER STEERING) SYSTEM

ST -75

&lt; N-02 &gt;



- 1.Solenoid (+)
- 2.Solenoid (-)

BPCE605H

4. Is the measured resistance within specifications?

**YES**

- 1) Ignition "OFF".
- 2) Connect Scantool to Data Link Connector(DLC) and then Engine "ON".
- 3) Select "SCOPEMETER FUNCTION" on scantool.
- 4) Measure output signal between terminal "1" of EPS solenoid harness connector and chassis ground.

■ Specification : Refer to 'Signal Waveform'

⇒ If it is normal, substitute with a known-good EPS CM and check for proper operation.


If the problem is corrected, replace EPS CM and then go to "Verification of Vehicle Repair" procedure.

⇒ If it is abnormal, check EPS solenoid for contamination, deterioration, or damage.

Substitute with a known-good EPS solenoid and check for proper operation.

If the problem is corrected, replace EPS solenoid and then go to "Verification of Vehicle Repair" procedure.

&lt; N-02 &gt;



- 1.Solenoid (+)
- 2.Solenoid (-)

BPCE605I

**NO**

⇒ Check EPS solenoid for contamination, deterioration, or damage.

Substitute with a known-good EPS solenoid and check for proper operation.

If the problem is corrected, replace EPS solenoid and then go to "Verification of Vehicle Repair" procedure.