

## EMC-2

## Engine Mechanical System

## General Information

## Specifications

Description	Specification 2.0(D4EA)	Limit
<b>General</b>		
Type	In-line, Single Overhead Camshaft	
Number of cylinders	4	
Bore	83mm (3.27in.)	
Stroke	92mm (3.62in.)	
Total displacement	1991cc (121.5cu.in.)	
Compression ratio	17.3 : 1	
Firing order	1 - 3 - 4 - 2	
<b>Valve timing</b>		
Intake valve		
Opens (BTDC)	7°	
Closes (ABDC)	35°	
Exhaust valve		
Opens (BBDC)	52°	
Closes (ATDC)	6°	
<b>Cylinder head</b>		
Flatness of gasket surface	0.03mm (0.0012in.) for width	
	0.09mm (0.0035in.) for length	
	0.012mm. (0.00047in.) / 51×51mm	
<b>Camshaft</b>		
Cam height		
Intake	34.697mm (1.366in.)	34.197mm (1.346in.)
Exhaust	34.570mm (1.361in.)	34.070mm (1.341in.)
Journal O.D	28mm (1.10in.)	
Bearing oil clearance	0.040 ~ 0.074mm (0.0020 ~ 0.0029in.)	
End play	0.05 ~ 0.15mm (0.002 ~ 0.006in.)	
<b>Valve</b>		
Valve length		
Intake	95.7mm (3.77in.)	
Exhaust	95.4mm (3.76in.)	
Stem O.D.		
Intake	5.953mm (0.234in.)	-0.02 ~ 0
Exhaust	5.925mm (0.233in.)	-0.02 ~ 0

## General Information

## EMC-3

Description	Specification 2.0(D4EA)	Limit
Face angle	45.5°	
Thickness of valve head (margin)		
Intake	1.6mm (0.063in.)	
Exhaust	1.3mm (0.0512in.)	
Valve stem to valve guide clearance		
Intake	0.022 ~ 0.067mm (0.00086 ~ 0.00263in.)	0.1mm (0.0039in.)
Exhaust	0.050 ~ 0.095mm (0.0020 ~ 0.0037in.)	0.15mm (0.0059in.)
<b>Valve guide</b>		
Length		
Intake	36.5mm (1.437in.)	
Exhaust	36.5mm (1.437in.)	
<b>Valve seat</b>		
Width of seat contact	1.21 ~ 1.61mm (0.0477 ~ 0.6634in.) (IN/EX)	
Seat angle	44.5° ~ 45°	
<b>Valve spring</b>		
Free length	38.8mm (1.527in.)	
Load	21.25kg/32mm (47.2lb/1.26in.) at installed height	
<b>Cylinder block</b>		
Cylinder bore	83 + 0.03mm (3.27 + 0.0012in.)	
Flatness of head gasket surface	0.042mm (0.00165in.) for width 0.096mm (0.00378in.) for length 0.012mm (0.00047in.) / 50×50mm	
<b>Piston</b>		
O.D	82.92 ~ 82.95mm (3.26 ~ 3.27in.)	
Piston-to-cylinder clearance	0.07 ~ 0.09mm (0.0027 ~ 0.0036in.)	
Ring groove width		
No.1	1.915 ~ 1.945mm (0.075 ~ 0.076in.)	
No.2	2.06 ~ 2.08mm (0.08 ~ 0.082in.)	
Oil	3.02 ~ 3.04mm (0.119 ~ 0.1196in.)	
Service size	0.25mm (0.010in.), 0.5mm (0.020in.) oversize	
<b>Piston ring</b>		
Side clearance		
No.1	0.083 ~ 0.133mm (0.00327 ~ 0.00524in.)	
No.2	0.065 ~ 0.11mm (0.00256 ~ 0.00433in.)	

## EMC-4

## Engine Mechanical System

Description	Specification 2.0(D4EA)	Limit	
Oil ring	0.03 ~ 0.07mm (0.00118 ~ 0.00276in.)		
End gap			
No.1	0.20 ~ 0.30mm (0.0078 ~ 0.012in.)		
No.2	0.30 ~ 0.45mm (0.012 ~ 0.018in.)		
Oil ring side rail	0.2 ~ 0.40mm (0.0079 ~ 0.0157in.)		
<b>Connecting rod</b>			
Connecting rod pin O.D	28.022 ~ 28.034mm (1.103 ~ 1.104in.)		
Connecting rod bearing oil clearance	0.024 ~ 0.042mm (0.0009 ~ 0.0016in.)		
Crankshaft main bearing oil clearance	0.024 ~ 0.042mm (0.0009 ~ 0.0016in.)		
<b>Crankshaft</b>			
Journal O.D.	60.002 ~ 60.020mm (2.362 ~ 2.363in.)		
Pin O.D.	50.008 ~ 50.026mm (1.9688 ~ 1.9695in.)		
Out-of-round of journal and pin	Less than 0.0035mm (0.0001in.)		
Taper of journal and pin	Less than 0.006mm (0.0002in.)		
End play	0.09 ~ 0.32mm (0.0035 ~ 0.0126in.)		
<b>Flywheel</b>			
Runout	0.45mm/Ø200	0.45mm (0.0170in.)	
<b>Engine oil</b>			
Oil quantity	Total	7.4 L (7.81 US qt, 6.51 Imp qt)	When replacing a short engine or a block assembly
	Oil pan	6.2 L (6.55 US qt, 5.45 Imp qt)	
	Drain and refill	6.7 L (7.07 US qt, 5.89 Imp qt)	Including oil filter
Oil grade	Classification	ACEA C3 (with CPF ) ACEA B4 (without CPF)	
	SAE viscosity grade	Recommended SAE viscosity number	Refer to the "Lubrication System"
Oil pressure (at idle)	78.45kPa (0.8kg/cm <sup>2</sup> , 11.38psi) or above	Oil temperature in oil pan : 80°C (176°F)	
<b>Oil pump</b>			
Oil pump performance [Oil temperature is 95 ~ 105°C (203 ~ 221°F, SAE 10W -30)] & Eng rpm 1500	More than 22l/min (0.012949ft <sup>3</sup> /s) 4.0kgf/cm <sup>2</sup> (8192lbf/ft <sup>2</sup> )		
Tip clearance	0.28 ~ 0.36mm (0.01102 ~ 0.01417in.)		
Radial clearance	0.13 ~ 0.23mm (0.0051 ~ 0.009in.)		
Side clearance	0.02 ~ 0.07mm (0.00078 ~ 0.0027in.)		
<b>Relief spring</b>			

## General Information

## EMC-5

Description	Specification 2.0(D4EA)	Limit
Freen length	47.5mm (1.835in.)	
Opening pressure	570 ± 50kPa (82.67 ± 7.25psi)	
<b>Silent shaft</b>		
Front journal diameter	27.99 ~ 28.01mm (1.102 ~ 1.1027in.)	
Rear journal diameter	41.99 ~ 42.01mm (1.6531 ~ 1.6539in.)	
Oil clearacne		
Front	0.050 ~ 0.09mm (0.0020 ~ 0.0036in.)	
Rear	0.050 ~ 0.091mm (0.0020 ~ 0.0036in.)	
<b>Cooling method</b>		
Cooling system quantity (Radiator)	Forced circulation with electrical fan 7.3L (7.7U.S.qts, 6.42 Imp.qts)	
Thermostat		
Type	Wax pellet type with jiggle valve	
Normal opening temperature	85°C (185°F)	
Opening temperature range	83.5 ~ 86.5°C (182 ~ 188°F)	
Full opening temperature	100°C (212°F)	
Radiator cap	107.9 ± 14.7kPa (1.1±0.15kg/cm <sup>2</sup> , 15.64±2.13psi)	
Main valve openg pressure		
Main valve closing pressure	83.4kPa (0.85kg/cm <sup>2</sup> , 12.1psi )	
Vacuum valve opening pressure	-6.86kPa (-0.07kg/cm <sup>2</sup> , -1.00psi)	
<b>Air cleaner</b>		
Type	Dry type	
Element	Unwoven cloth type	
Exhaust		
Muffler	Expansion resonance type	
Suspension system	Rubber hangers	
<b>Coolant tempreature sensor</b>		
Type	Thermister type	
Resistance		
20°C (68°F)	2.45 ± 0.14kΩ	
80°C (176°F)	0.3222kΩ	



**EMC-6****Engine Mechanical System****SERVICE STANDARDS**

Standard value	
Coolant concentration	
Tropical area	40%
Other area	50%

**Lubricant**

Engine oil	ACEA : C3(CPF EQUIPPED VEHICLE	SAE 15W-40 (ABOVE -15°C)
	ACEA : B4 or API CH-4 AB-	SAE 10W-30 (-20°C ~ 40°C)
	OVE(NON CPF VEHICLE)	SAE 5W-30 (-25°C ~ 40°C)
		SAE 0W-30 (BELOW 10°C)*1 *2

\*1. Restricted to driving condition and area

\*2. Not recommended for sustained high speed

**Sealant**

Engine coolant temperature sensor	3M No.1324 or equivalent
Oil pressure switch	3M ATD No. 8660 or Three bond TB 2403
Bed plate	OMNI FIT FD20, DREIBOND 5105 or HYLOMAR 3000

**NOTICE**

O.D. = Outer Diameter

I.D. = Inner Diameter

O.S. = Oversize Diameter

U.S. = Undersize Diameter

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## General Information

## EMC-7

## Tightening Torques

Items	N.m	kgf.m	lbf.ft
<b>Engine system</b>			
High fuel pipe(reil↔pump) mounting nut	24.5 ~ 28.4	2.5 ~ 2.9	18.1 ~ 21.0
Drive plate	68.6 ~ 78.5	7.0 ~ 8.0	50.6 ~ 57.9
Damper pulley mounting bolt	29.4 ~ 33.3	3.0 ~ 3.4	21.7 ~ 24.6
Real roll stopper bracket sub frame bolt	49.0 ~ 63.7	5.0 ~ 6.5	36.2 ~ 47.0
Real roll mounting insulator bolts	49.0 ~ 63.7	5.0 ~ 6.5	36.2 ~ 47.0
Relief plug	41.2 ~ 51.0	4.2 ~ 5.2	30.4 ~ 37.6
Engine support bracket bolt	42.2 ~ 53.9	4.3 ~ 5.5	31.1 ~ 39.8
Starter motor mounting bolt	42.2 ~ 53.9	4.3 ~ 5.5	31.1 ~ 39.8
Cylinder head bolt	63.7+120°+120°	6.5+120°+120°	46.9+120°+120°
Cylinder head cover mounting bolt(M6)	7.8 ~ 9.8	0.8 ~ 1.0	5.8 ~ 7.2
Cylinder head cover mounting bolt(M8)	21.6 ~ 25.5	2.2 ~ 2.6	15.9 ~ 18.8
Air cleaner mounting bolt	7.8 ~ 10.8	0.8 ~ 1.1	5.8 ~ 8.0
Air cleaner intake hose clamp	2.9 ~ 4.9	0.3 ~ 0.5	2.2 ~ 3.6
Engine mounting bracket bolt & nut	63.7 ~ 83.4	6.5 ~ 8.5	47.0 ~ 61.5
Injector holder bolt	7.8 ~ 10.8	0.8 ~ 1.1	5.8 ~ 8.0
A/T mounting bracket bolt	49.0 ~ 63.7	5.0 ~ 6.5	36.2 ~ 47.0
A/T insulator bolt	49.0 ~ 63.7	5.0 ~ 6.5	36.2 ~ 47.0
Camshaft bearing cap bolt	26.5 ~ 29.5	2.7 ~ 3.0	19.5 ~ 21.7
Camshaft sprocket mounting bolt	122.6 ~ 140.2	12.5 ~ 14.3	90.4 ~ 103.4
Connecting rod cap bolt	24.5 + 90°	2.5 + 90°	18.1 + 90°
Crankshaft bed plate bolt(15mm)	27.5 ~ 31.4+120°	2.8 ~ 3.2+120°	20.3 ~ 23.1+120°
Crankshaft bed plate bolt(12mm)	33.3 ~ 37.3	3.4 ~ 3.8	26.4 ~ 27.5
Crankshaft sprocket bolt	196.1 ~ 205.9	20.0 ~ 21.0	144.7 ~ 151.9
Crankshaft pulley bolt	29.4 ~ 33.3	3.0 ~ 3.4	21.7 ~ 24.6
Crankshaft position sensor mounting bolt	3.9 ~ 5.9	0.4 ~ 0.6	2.9 ~ 4.3
Front roll stopper bracket sub frame mounting bolt	49.0 ~ 63.7	5.0 ~ 6.5	36.2 ~ 47.0
Front roll stopper insulator bolt	49.0 ~ 63.7	5.0 ~ 6.5	36.2 ~ 47.0
Fly wheel	68.6 ~ 78.5	7.0 ~ 8.0	50.6 ~ 57.5
<b>Timing system</b>			
Timing auto tensioner bolt	50 ~ 55	5.1 ~ 5.6	36.8 ~ 40.6
Upper cover mounting bolt	7.8 ~ 11.8	0.8 ~ 1.2	5.8 ~ 8.7
Rear cover mounting bolt	7.8 ~ 11.8	0.8 ~ 1.2	5.8 ~ 8.7

## EMC-8

## Engine Mechanical System


Items	N.m	kgf.m	lbf.ft
Idler mounting bolt	45 ~ 49	4.6 ~ 5.0	33.2 ~ 36.1
Auto tensiner adjustable bolt	10 ~ 12	1.0 ~ 1.2	7.3 ~ 8.9
Lower cover mounting bolt	7.8 ~ 11.8	0.8 ~ 1.2	5.8 ~ 8.7
<b>Lubrication system</b>			
Oil lever gage mounting bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil screen mounting bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil jet mounting bolt	8.8 ~ 12.7	0.9 ~ 1.3	6.5 ~ 9.4
Oil pan drain plug	34.3 ~ 44.1	3.5 ~ 4.5	25.3 ~ 32.5
Oil pan bolt	9.8 ~ 7.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil pump mounting bolt	19.6 ~ 26.5	2.0 ~ 2.7	14.5 ~ 19.5
Oil pump cover bolt	7.8 ~ 9.8	0.8 ~ 1.0	5.8 ~ 7.2
Oil pressure switch	14.7 ~ 21.6	1.5 ~ 2.2	10.8 ~ 15.9
Oil filter	22.6 ~ 24.5	2.3 ~ 2.5	16.6 ~ 18.1
Heater & oil cooler return pipe bracket mounting bolt(10mm)	7.8 ~ 9.8	0.8 ~ 1.0	5.8 ~ 7.2
Heater & oil cooler return pipe bracket mounting bolt(12mm)	19.6 ~ 24.5	2.0 ~ 2.5	14.5 ~ 18.1
<b>Cooling system</b>			
Water pump mounting bolt(10mm)	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Water pump mounting bolt(14mm)	47.1 ~ 51.0	4.8 ~ 5.2	34.7 ~ 37.6
Radiator drain plug	6.8 ~ 13.7	0.7 ~ 1.4	5.1 ~ 10.1
Radiator shroud mounting bolt	8.8 ~ 10.8	0.9 ~ 1.1	6.5 ~ 8.0
Radiator upper bracket mounting bolt	8.8 ~ 10.8	0.9 ~ 1.1	6.5 ~ 8.0
Engine water coolant temperature sensor	19.6 ~ 23.5	2.0 ~ 2.4	14.5 ~ 17.4
Thermostat inlet mounting bolt, nut	19.6 ~ 24.5	2.0 ~ 2.5	14.5 ~ 18.1
<b>Intake &amp; exhaust system</b>			
Main muffler and center exhaust pipe nuts	39.2 ~ 58.8	4.0 ~ 6.0	28.9 ~ 43.4
Cylinder head and exhaust manifold nuts	24.5 ~ 37.3	2.5 ~ 3.8	18.1 ~ 27.5
Catalytic convert and center exhaust pipe nuts	29.4 ~ 39.2	3.0 ~ 4.0	21.7 ~ 28.9
Turbo charger support bolt	34.3 ~ 44.1	3.5 ~ 4.5	25.3 ~ 32.5
Intake manifold mounting nuts & bolt	14.7 ~ 21.6	1.5 ~ 2.2	10.8 ~ 15.9
Inter cooler bracket mounting bolt	6.8 ~ 10.8	0.7 ~ 1.1	5.1 ~ 8.0

## General Information

## EMC-9

### Compression Pressure Inspection

1. Check the engine oil, stater motor and the battery normal condition.
2. Warm up the engine until the normal operating temperature becoming 80~95°C(176~203°F).
3. Turn the engine off, then remove the air cleaner assembly.
4. Remove the Engine Control Module(ECM).
5. Remove the injector.(Refer to Injector in FLC Group).
6. While cranking the engine, remove impurity from the cylinder.
7. Install the pressure gauge (09351 - 27000 , 09351 - 27500) to the injector hall.



8. While cranking the engine, measure the compression pressure.

### Compression pressure

Standard pressure :

2,549kPa (26.0kgf/cm<sup>2</sup>, 369psi) - 270rpm

Minimum pressure :

2,255kPa (23.0kgf/cm<sup>2</sup>, 327psi)

9. Check the power balance between all cylinder are within limit by repeating steps 7) through 8) for each cylinder.

**Limit** : each cylinder pressure 294kPa (3.0kgf/cm<sup>2</sup>, 42psi)

10. If the cylinder compression in 1 or more cylinders is low, pour a small amount of engine oil into the cylinder through the spark plug hole and repeat steps through for cylinders with low compression. Repeat steps 7) through 9) for each cylinder.
  - 1) If adding oil helps the compression, it is likely that the piston rings and/or cylinder bore are worn or damaged.
  - 2) If pressure stays low, a valve may be sticking or seating is improper, or there may be leakage past the gasket.
11. In case of remove the injection nozzle when measure cylinder compressed pressure replace gasket and holder with new one and tighten them Tightening torque.

## EMC-10

## Engine Mechanical System

## Troubleshooting

Symptom	Suspect	Remedy
Engine misfire with abnormal internal lower engine noises.	Loose or improperly installed engine flywheel.	Repair or replace the flywheel as required.
	Worn piston rings (Oil consumption may or may not cause the engine to misfire.)	Inspect the cylinder for a loss of compression. Repair or replace as required.
	Worn crankshaft thrust bearings.	Replace the crankshaft and bearings as required.
Engine misfire with abnormal valve train noise.	Stuck valves (Carbon buildup on the valve stem can cause the valve not to close properly.)	Repair or replace as required
	Excessive worn or mis-aligned timing belt	Replace the timing belt and sprocket as required.
	Worn camshaft lobes.	Replace the camshaft and valve lifters.
Engine misfire with coolant consumption.	<ul style="list-style-type: none"> <li>Faulty cylinder head gasket and/or cracking or other damage to the cylinder head and engine block cooling system.</li> <li>Coolant consumption may not cause the engine to overheat.</li> </ul>	<ul style="list-style-type: none"> <li>Inspect the cylinder head and engine block for damage to the coolant passages and/or a faulty head gasket.</li> <li>Repair or replace as required.</li> </ul>
Engine misfire with excessive oil consumption.	Worn valves, valve guides and/or valve stem oil seals.	Repair or replace as required.
	Worn piston rings. (Oil consumption may or may not cause the engine to misfire)	<ul style="list-style-type: none"> <li>Inspect the cylinder for a loss of compression.</li> <li>Repair or replace as required.</li> </ul>
Engine noise on start-up, but only lasting a few seconds.	Incorrect oil viscosity.	<ul style="list-style-type: none"> <li>Drain the oil</li> <li>Install the correct viscosity oil.</li> </ul>
	Worn crankshaft thrust bearing.	<ul style="list-style-type: none"> <li>Inspect the thrust bearing and crankshaft</li> <li>Repair or replace as required.</li> </ul>

## General Information

## EMC-11

Symptom	Suspect	Remedy
Upper engine noise, regardless of engine speed.	Low oil pressure.	Repair or replace as required.
	Broken valve spring.	Replace the valve spring
	Worn or dirty valve lifters.	Replace the valve lifters.
	Stretched or broken timing belt and/or damaged sprocket teeth.	Replace the timing belt and sprockets.
	Worn timing chain tensioner, if applicable.	Replace the timing chain tensioner as required.
	Worn camshaft lobes.	<ul style="list-style-type: none"> <li>Inspect the camshaft lobes.</li> <li>Replace the timing camshaft and valve lifters as required.</li> </ul>
	Worn valve guides or valve stems.	Inspect the valves and valve guides, then repair as required.
	Stuck valves. (Carbon on the valve stem or valve seat may cause the valve to stay open.)	Inspect the valves and valve guides, then repair as required.
Lower engine noise, regardless of engine speed.	Low oil pressure.	Repair or replace damaged components as required.
	Loose or damaged flywheel.	Repair or replace the flywheel.
	Damaged oil pan, contacting the oil pump screen.	<ul style="list-style-type: none"> <li>Inspect the oil pan.</li> <li>Inspect the oil pump screen.</li> <li>Repair or replace as required.</li> </ul>
	Oil pump screen loose, damage or restired.	<ul style="list-style-type: none"> <li>Inspect the oil pump screen.</li> <li>Repair or replace as required.</li> </ul>
	Excessive piston-to-cylinder bore clearance	<ul style="list-style-type: none"> <li>Inspect the piston and cylinder bore.</li> <li>Repair as required.</li> </ul>
	Excessive piston pin-to bore clearance.	<ul style="list-style-type: none"> <li>Inspect the piston, piston pin and the connecting rod.</li> <li>Repair or replace as required.</li> </ul>
	Excessive connecting rod bearing clearance	Inspect the following components and repair as required. <ul style="list-style-type: none"> <li>The connecting rod bearings.</li> <li>The connecting rods.</li> <li>The crankshaft.</li> <li>The crankshaft journal.</li> </ul>
	Excessive crankshaft bearing clearance	Inspect the following components and repair as required. <ul style="list-style-type: none"> <li>The crankshaft bearings.</li> <li>The crankshaft journals.</li> </ul>
	Incorrect piston, piston pin and connecting rod installation	<ul style="list-style-type: none"> <li>Verify the piston pins and connecting rods are installed correctly.</li> <li>Repair as required.</li> </ul>

## EMC-12

## Engine Mechanical System






Symptom	Suspect	Remedy
Engine noise under load	Low oil pressure	Repair or replace as required.
	Excessive connecting rod bearing clearance	Inspect the following components and repair as required. <ul style="list-style-type: none"> <li>The connecting rod bearings.</li> <li>The connecting rods.</li> <li>The crankshaft</li> </ul>
	Excessive crankshaft bearing clearance	Inspect the following components, and repair as required. <ul style="list-style-type: none"> <li>The crankshaft bearings.</li> <li>The crankshaft journals.</li> <li>The cylinder block crankshaft bearing bore.</li> </ul>
Engine will not crank-crankshaft will not rotate	Hydraulically cylinder <ul style="list-style-type: none"> <li>Coolant/antifreeze in cylinder.</li> <li>Oil in cylinder.</li> <li>Fuel in cylinder</li> </ul>	<ol style="list-style-type: none"> <li>Remove injectors and check for fluid.</li> <li>Inspect for broken head gasket.</li> <li>Inspect for cranked engine block or cylinder head.</li> <li>Inspect for a sticking fuel injector and/or leaking fuel regulator.</li> </ol>
	Broken timing chain and/or timing chain gears.	<ol style="list-style-type: none"> <li>Inspect timing chain and gears.</li> <li>Repair as required.</li> </ol>
	Material cylinder <ul style="list-style-type: none"> <li>Broken valve</li> <li>Piston material</li> <li>Foreign material</li> </ul>	<ol style="list-style-type: none"> <li>Inspect cylinder for damaged components and/or foreign materials.</li> <li>Repair or replace as required.</li> </ol>
	Seized crankshaft or connecting rod bearings.	<ol style="list-style-type: none"> <li>Inspect crankshaft and connecting rod bearing.</li> <li>Repair as required.</li> </ol>
	Bent or broken connecting rod.	<ol style="list-style-type: none"> <li>Inspect connectong rods.</li> <li>Repair as required.</li> </ol>
	Broken crankshaft	<ol style="list-style-type: none"> <li>Inspect crankshaft.</li> <li>Repair as required.</li> </ol>



# General Information






# EMC-13

## Speical Service Tools

Tool (Number and name)	Illustration	Use
Camshaft oil seal installer (09212-27100)	 <p style="text-align: center;">ACIE003A</p>	Installation of the camshaft oil seal
Valve spring compressor (09222-27300)	 <p style="text-align: center;">ACIE004A</p>	Removal and installation of intake and exhaust valves
Valve stem oil seal installer (09222-27200)	 <p style="text-align: center;">ACIE005A</p>	Installation of valve stem oil seals
Crankshaft rear oil seal installer (09231-27000)	 <p style="text-align: center;">ACIE006A</p>	Installation of the crankshaft rear oil seal
Front case oil seal installer (09231-27100)	 <p style="text-align: center;">ACIE003A</p>	Installation of the front case oil seal

## EMC-14

## Engine Mechanical System

Tool (Number and name)	Illustration	Use
Injector oil seal installer (09351-27401)	 <p style="text-align: center;">ACIE007A</p>	Installation of the injector oil seal
Compression gauge & adapter (09351-27000) (09351-27500)	 <p style="text-align: center;">ACIE002A</p>	Checking engine compression pressure
Oil filter wrench (09263-27000)	 <p style="text-align: center;">ACIE008A</p>	Removal and installation of spin on type oil filter
Oil filter wrench (09263-2E000)	 <p style="text-align: center;">ACIE008A</p>	Removal and installation of ECO type oil filter
Engine support fixture and adapter (09200-38001, 09200-1C00)	 <p style="text-align: center;">AMJF002B</p>	Engine fixing

# Engine And Transaxle Assembly

## EMC-15

### Engine And Transaxle Assembly


#### Removal

##### ⚠ CAUTION

- Make sure jacks and safety stands are placed properly.
- Make sure the vehicle will not roll off stands and fall while you are working under it.
- Use fender covers to avoid damaging painted surface.
- Unplug the wiring connectors carefully while holding the connector portion to avoid damage.
- Mark all wiring and hoses to avoid disconnection.

Also, be sure that they do not contact other wiring or hoses or interfere with other parts.

1. Remove the engine cover(A).



SFDM38010L


#### Tightening torque :

7.8 ~ 11.7N.m (0.8 ~ 1.2kgf.m, 5.8 ~ 8.7lb.ft)

2. Remove the air duct.


#### Tightening torque :

7.8 ~ 10.8N.m (0.8 ~ 1.1kgf.m, 5.8 ~ 8.0lb.ft)



SFDM38001L

3. Disconnect the battery negative terminal(A) first, then the positive terminal(B) and remove the battery(C).




SEDM37003L

## EMC-16

## Engine Mechanical System

4. Remove the under cover(A).




SFDM38002L

**Tightening torque :**

8.8 ~ 10.8N.m (0.9 ~ 1.1kgf.m, 6.5 ~ 7.9lb.ft)

5. Loosen the radiator drain plug (A) and drain engine coolant.

Remove the radiator cap to speed draining.



SEDM17003L


6. Remove the air cleaner assembly.

- 1) Disconnect the air flow sensor (AFS) connector (A).
- 2) Remove the air intake hose (B).
- 3) Disconnect the engine control module (ECM) connector (C).
- 4) Remove the air clear assembly (D).

**Tightening torque :**

Hose clamp (B) : 2.9 ~ 4.9N.m (0.3~0.5kgf.m, 2.2 ~ 2.6lb.ft)

Mounting bolt : : 7.8 ~ 10.8N.m (0.8~1.1kgf.m, 5.8 ~ 8.0lb.ft)




SEDM37004L

7. Remove the battery tray (A) and disconnect the front connector (B).

**Tightening torque :**

8.8 ~ 13.7N.m (0.9 ~ 1.4kgf.m, 6.5 ~ 10.1lb.ft)




SEDM37005L

# Engine And Transaxle Assembly

# EMC-17

- Remove the intercooler hose (A) and disconnect the booster pressure sensor (BPS) connector (B).




SEDM37006L

- Remove the fuse box cover.
- Disconnect the terminals(A) from the fuse box.

**Tightening torque :**


9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SFDM38011L

**NOTICE**

When connecting the alternator B+ cable, refer to the illustration below.




SFDM38012L

- After removing the mounting bolts, remove the relay and fuse assembly(A).

**Tightening torque :**

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SFDM38013L



# EMC-18

# Engine Mechanical System

12. Remove the connector wiring (A) and the engine wiring (B).




SHDEM6066D

13. Remove the engine control side ground(A) and, the transaxle control side one(B).


**Tightening torque :**

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SHDEM6014D

14. Remove the solenoid valve vacuum hoses(A).




SFDM38003L

15. Disconnect the fuel hoses(A) and fuel temperature sensor connector(B).



LCIG007A

16. Disconnect the brake booster vacuum hoses(A) and heater hose(B).




LCIG008A


# Engine And Transaxle Assembly

## EMC-19

17. Remove the heater hose(A) and EGR cooler hose(B).




SMGEM6017D




SMGEM6310D

18. Remove the radiator upper hose(A) and the coolant bleed hose(B).



SNFEM6002D

19. Remove the radiator lower hose(A).




SEDM37007L

20. Disconnect the transaxle wire harness and the control cable.

(Refer to Transaxle control system in MTC Group).

21. Remove the high & low pressure pipe. (Refer to Air conditioner compressor in HA Group).

22. Remove the steering column mounting bolt(A), (Refer to Steering column in ST Group).



SFDM38014L

23. Remove the front wheels and tires.

24. Disconnect the stabilizer bar link and remove the mounting bolts from the lower arm and the front axles.

(Refer to front suspension system in SS Group)




# EMC-20

# Engine Mechanical System


25. Remove the front muffler (A).

[C.P.F Equipped Vehicle]



SFDM38004L

[Non C.P.F Vehicle]




SEDM37008L

**Tightening torque :**

40 ~ 60N.m (4.0~6.0kgf.m, 30 ~ 43lb.ft)

26. Install the SST (09200-38001, 09200-1C000), the engine support fixture and the adapter, on the engine and transaxle assembly.



SEDM37009L

27. Remove the engine mounting bracket (A) and the ground line (B).

**Tightening torque :**

Nut (C), Bolt (D) :


63.7 ~ 83.4N.m (6.5 ~ 8.5kgf.m, 47.0 ~ 61.5lb.ft)

Nuts (E) :

49.0 ~ 63.7N.m (5.0 ~ 6.5kgf.m, 36.2 ~ 47.0lb.ft)

Bolt (F) :

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb.ft)



SFDM38032L

# Engine And Transaxle Assembly


## EMC-21

28. Remove the transaxle mounting bracket (A) and the ground line (B).

### Tightening torque :

A : 88.2 ~ 107.8N.m (9.0 ~ 11.0kgf.m, 65.0 ~ 79.5lb.ft)

B : 9.8 ~ 14.7N.m (1.0 ~ 1.5kgf.m, 7.2 ~ 10.8lb.ft)




SEDM37011L


29. Remove the sub frame mounting bolts and nut.

### Tightening torque :

49.0 ~ 63.7N.m (5.0~6.5kgf.m, 36.2 ~ 47.0lb.ft)



SMGEM6020D



SMGEM6021D

30. Remove the engine and transaxle assembly by lifting vehicle.

### NOTICE

*When remove the engine and transaxle assembly, be careful not to damage any surrounding parts or body components.*

### Installation

Install the engine in the reverse order of removal.

Reinstall the mount bolts/nuts in the following sequence.

Failure to follow these procedures may cause excessive noise and vibration, and reduce bushing life.

1. Install the sub frame installation bolt.
2. Tighten the engine and transmission mounting bolts.
3. Connect the power steering oil hoses.
4. Install the front muffler.
5. Install the front tires/wheels and splash shield.
6. Connect the air condition hoses.
7. Install the transmission links.
8. Connect the fuel hoses.
9. Connect the engine wire harness connectors.
10. Connect the radiator upper and lower hoses.
11. Connect the heater hoses.
12. Connect the hose to the reservoir tank.
13. Connect the intercooler hoses.
14. Install the air cleaner and the battery.
15. Perform the following :
  - Clean the areas where the driveshaft contact the transmission thoroughly with solvent or carburetor cleaner, and dry with compressed air.
  - Check that the snap rings on the ends of the driveshaft click into place.


# EMC-22

# Engine Mechanical System

## Timing System

### Timing Belt

#### Components



SFDM38023L


- |                            |  |                           |
|----------------------------|--|---------------------------|
| 1. Damper pulley           | 5. Timing belt                         | 9. Camshaft sprocket      |
| 2. Timing belt lower cover | 6. Alternator and vacuum pump assembly | 10. Timing belt idler     |
| 3. Engine support bracket  | 7. Idler                               | 11. Timing belt tensioner |
| 4. Timing belt upper cover | 8. Air conditioning compressor         | 12. Drive belt tensioner  |

# Timing System

# EMC-23


## Removal

1. Remove the front wheel.(RH)
2. Remove the side cover.
3. The tensioner(B) should be lifted up to remove the drive belt(A).



SFDM38016L

4. Remove the engine mounting bracket(A) and the ground cable(B).




SFDM38032L

### NOTICE


- Set a jack to support the engine before the mounting bracket is removed.
- Place a rubber block between the jack and oil pan.

5. Remove the crankshaft pulley(A).



SFDM38035L

6. Remove the timing belt lower cover(A).




SFDM38036L



# EMC-24


# Engine Mechanical System

7. Remove the timing belt upper cover(A).




SFDM38037L

8. Remove the engine support bracket(A).




SFDM38038L

9. Align the timing marks(A, B) on the camshaft sprocket(C) and the crankshaft sprocket(D) with the marks(E, F) on the cylinder head(G) and the oil pump housing(H) with rotating the engine.



LCIF011A




LCIF012A

# Timing System


# EMC-25

10. Insert a pin(A) into the aligned holes in the auto-tensioner(B).



EDKD536A

11. Using a hexagonal wrench (5mm)(A), loosen the stop bolt(B). And then, turning the auto-tensioner(C) clockwise fully with the boss bolt(D) and 12mm spanner(E), retighten the stop bolt(B).



EDKD537A

12. Remove the timing belt.

### NOTICE


To be prepared in case the removed belt is used, mark an arrow on the timing belt in the direction of rotation before removing it.

### Inspection

1. Remove the upper cover.
2. Inspect the timing belt(A) for cracks and oil or coolant soaking.

### NOTICE

- Replace the belt if oil or coolant soaked.
- Remove any oil or solvent that gets on the belt.



SFDM38039L

### Sprockets, Tensioner, Idler


1. Check the camshaft sprocket.  
Camshaft sprocket, crankshaft, tensioner pulley and idler pulley for abnormal wear, cracks or damage. Replace as necessary.
2. Inspect the tensioner pulley and the idler pulley for easy and smooth rotation and check for play or noise. Replace as necessary.
3. Replace the pulley if there is a grease leak from its bearing.

## EMC-26

## Engine Mechanical System


## Installation

1. Align the timing mark(A) on the camshaft sprocket(B) with the mark(C) on the cylinder head(D).



ACIE051A

2. Align the timing mark(A) on the crankshaft sprocket(B) with the pin(C) press fitted in the oil pump housing(D).




ACIE052A

3. Install the timing belt.


- 1) Install the timing belt(A) tightly in the sequence shown.

① Timing belt drive pulley(B) (crankshaft) → ② Water pump pulley(C) ③ Timing belt idler(D) → ④ Camshaft sprocket(E) → ⑤ Timing belt tensioner(F).



SEDM37013L

- 2) Turn the auto-tensioner(C) counterclockwise fully to install the timing belt using the boss bolt(D) and spanner(E).



ACIE050A

- 3) Rotate the crankshaft by hand 2 complete revolutions (clockwise) to take up any slack and set to TDC(Top Dead Center).
- 4) Using a hexagonal wrench, install the stop bolt.

**Tightening torque :**


10 ~ 12N.m (1.0 ~ 1.2 kgf.m, 7 ~ 9lb-ft)



# Timing System

# EMC-27

5) Remove the fixing pin(A)




EDKD536A

4. Install the engine support bracket(A).

**Tightening torque :**

43 ~ 55N.m (4.3 ~ 5.5kgf.m, 31.72 ~ 40.57lb-ft)




SFDM38038L


5. Install the timing belt upper cover(A) and lower cover(B).

**Tightening torque :**

7.8 ~ 11.8N.m (0.8 ~ 1.2kgf.m, 5.75 ~ 8.70lb-ft)



SFDM38037L



SFDM38017L


# EMC-28

# Engine Mechanical System

6. Install the crankshaft pulley(A).

**Tightening torque :**

30 ~ 34N.m (3.0 ~ 3.4kgf.m, 22 ~ 25lb-ft)




7. Install the engine mounting bracket(A) and the ground cable(B).

**Tightening torque :**

Nut(C), Bolt(D) : 63.7 ~ 83.4N.m(6.5 ~ 8.5kgf.m, 47.0 ~ 61.5lb-ft)

Nuts(E) : 49.0 ~ 63.7N.m (5.0 ~ 6.5kgf.m, 36.2 ~ 47.0lb-ft)


Bolt(F) : 7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)



8. Install the drive belt(A), following the sequence below.

- 1. Alternator → 2. Idler → 3. Air compressor →
- 4. Crankshaft pulley → 5. Tensioner.

The tensioner should be lifted up to install the drive belt(A).



9. Install the side cover.

10. Install the front wheel.(RH)

# Cylinder Head Assembly

# EMC-29

## Cylinder Head Assembly

### Components


**CAUTION**

- To avoid damage, wait until the engine coolant temperature drops before removing cylinder head.
- When handling a metal gasket, take care not to fold damage the contact surface.

21.6 ~ 25.5 (2.2 ~ 2.6, 15.9 ~ 18.8)

8 ~ 10 (0.8 ~ 1.0, 5.90 ~ 7.38)

63.7 (6.5, 46.9) + 120° + 120°




Torque : N.m (kgf.m, lb-ft)

SFDM38024L

- |                               |                                |
|-------------------------------|--------------------------------|
| 1. Fuel return hose           | 6. Cylinder head cover gasket  |
| 2. Clip                       | 7. High pressure pump assembly |
| 3. Injector                   | 8. Cylinder head               |
| 4. Injector installation plug | 9. Cylinder head gasket        |
| 5. Cylinder head cover        | 10. Cylinder block assembly    |

EMC-30

Engine Mechanical System



SFDM38045L

- 1. Camshaft bearing cap
- 2. Camshaft
- 3. Oil seal
- 4. Camshaft sprocket
- 5. Intake cam follower

- 6. Exhaust cam follower
- 7. Lash adjuster
- 8. Valve cap
- 9. Valve spring retainer lock
- 10. Valve spring retainer


- 11. Valve spring
- 12. Valve stem seal
- 13. Cylinder head
- 14. Intake valves
- 15. Exhaust valves

# Cylinder Head Assembly

## EMC-31

### Removal


1. Before removing the cylinder head, the timing belt should be removed first. (Refer to Timing system in this group)
2. Remove the exhaust manifold and the intake manifold. (Refer to Intake and exhaust system in this group)
3. Remove injector connector.
4. Disconnect the fuel return hose after removing the clips(A).



SFDM38046L


5. Remove the fuel tube. (Refer to Fuel pump in FLC group)

6. Remove the plugs(A).
  - a. Pull the plug up slightly. (more than 1mm)
  - b. Rotate the plug 90° clockwise.
  - c. Remove the plug with inserting a (-)driver between the plug assy(B) and the cylinder head cover(C).



SFDM38047L

7. Remove the injector holder bolt using the torx wrench.



EDKD548A


8. Pull the injector holders with the bolts.



# EMC-32

# Engine Mechanical System


9. Remove the injectors(A).



SFDM38048L

- a. Disconnect the camshaft position sensor.
- b. Remove the wiring bracket.
- c. Remove the pipe between the oil pan.
- d. Remove the fuelline hose bolt.


10. Remove the cylinder head cover mounting bolts(A,B).



SNFEM6006D


11. Remove the cylinder head cover.

12. Remove the injector holders(A) with the bolts(B).



SFDM38049L

13. Remove the metal tube(A) between the fuel pump(B) and the common rail(C).




SFDM38052L

# Cylinder Head Assembly


# EMC-33

14. Remove the high pressure pump(A) after removing the mounting bolts(B).



SFDM38061L


15. Remove the cylinder head bolts(A), then remove the cylinder head(B).



SFDM38062L

### CAUTION

To prevent warpage, unscrew the bolts in science 1/3 turn at a time:repeat the sequence until all bolts are loosened.



EDKD557A



## EMC-34

## Engine Mechanical System


## Disassembly

## NOTICE

• Identify parts as they are removed to ensure reinstallation in original locations.


• Inspect camshafts.

1. Remove the engine hangers, the knock bushes and the studs.
2. Remove the camshaft bearing caps(A).




SFDM38063L

3. Remove the camshaft(A) with the oil seal(B).



SFDM38064L

4. Remove the Intake/Exhaust cam followers(A, B).



SFDM38065L

5. Remove the lash adjusters(C).

6. Remove the valve caps(D).

7. Using an appropriate-sized socket and plastic mallet, lightly tap the valve retainer to loosen the valve retainer locks before installing the valve spring compressor.


## NOTICE

Identify valves and valve springs as they are removed so that each item can be reinstalled in its original position.



# Cylinder Head Assembly

# EMC-35

- Using the SST(09222-27300), compress the valve spring(A) in order to remove the valve spring retainer locks(B).



- Remove the valve stem seals(A).



LCIF019A

### Intake Valve Dimensions

- A Standard (New) : 28.5 ~ 28.7mm (1.1220 ~ 1.1299in.)
- B Standard (New) : 94.0 ~ 94.2mm (3.7008 ~ 3.7087in.)
- C Standard (New) : 5.933~5.953mm (0.2336~0.0669in.)
- D Standard (New) : 1.5 ~ 1.7mm (0.0591 ~ 0.0669in.)

### Exhaust Valve Dimensions

- A Standard (New) : 24.3 ~ 24.5mm (0.9567 ~ 0.9646in.)
- B Standard (New) : 94.0 ~ 94.2mm (3.7008 ~ 3.7087in.)
- C Standard (New) : 5.905~5.925mm (0.2325~0.2333in.)
- D Standard (New) : 1.2 ~ 1.4mm (0.0472 ~ 0.0551in.)

# EMC-36

# Engine Mechanical System

## Inspection

### Camshaft


#### NOTICE

Do not rotate the camshaft during inspection.

1. Put the camshaft (A) and the camshaft bearing caps (B) on the cylinder head (C), then tighten the bolts to the specified torque with the following sequence below.

#### Specified torque


26.5 ~ 29.5N.m (2.7 ~ 3.0kgf.m, 19.5 ~ 21.7lb-ft)



2. Seat the camshaft by pushing it toward the rear of the cylinder head.
3. Zero the dial indicator (A) against the end of the camshaft (B).  
Push the camshaft (B) back and forth, and read the end play.

#### Camshaft End Play

Standard (New) : 0.05 ~ 0.15mm (0.002 ~ 0.006in.)



SFDM38068L

4. Remove the bolts, then remove the camshaft bearing caps from the cylinder head(A).

- Lift the camshaft(B) out of the cylinder head(A), wipe it clean. Replace the camshaft if any lobes are pitted, scored, or excessively worn.
- Clean the camshaft bearing surfaces in the cylinder head, then set the camshaft back in place.
- Place a plastigauge strip(C) across each journal.


5. Install the camshaft bearing caps and tighten the bolts to the specified torque.

6. Remove the camshaft bearing caps, then measure the widest portion of the plastigauge(C) on each journal.

#### Camshaft-to-Camshaft bearing cap oil clearance

Standard (New)

0.040 ~ 0.074mm (0.0020 ~ 0.0029in.)



LCIF020A

# Cylinder Head Assembly

# EMC-37


7. If the camshaft-to-camshaft bearing cap oil clearance is out of tolerance :
- And the camshaft(A) has already been replaced, you must replace the cylinder head.
  - If the camshaft has not been replaced, first check the total runout with the camshaft supported on V-blocks.

## Camshaft Total Runout

Standard (New)

0.035mm (0.0014in.) for No.2 and4

0.050mm (0.0019in.) for No.3



- If the total runout of the camshaft is within tolerance, replace the cylinder head.
- If the total runout is out of tolerance, replace the camshaft and recheck the camshaft-to-camshaft bearing cap oil clearance. If the oil clearance is still out of tolerance, replace the cylinder head.

8. Check the cam height wear.

## [Standard]


Intake : 34.697mm (1.366in.)

Exhaust : 34.570mm (1.361in.)

## [Limit]

Intake : 34.197mm (1.346in.)

Exhaust : 34.070mm (1.341in.)



ACIE076A


# EMC-38

# Engine Mechanical System

## Cylinder Head


Check the cylinder head(A) for warpage.

- If warpage is less than 0.03mm (0.0012in.) for width, 0.09mm (0.0035in.) for length and 0.012mm (0.0005in) for 51mm ×51mm, cylinder head is in good condition.
- If warpage is over the standard value, replace the cylinder head.



ACIE084A

Measure along edges, and three ways across center.




ACIE085A

## Reassembly

### NOTICE

Prior to reassembling, cylinder head assembly shall be cleaned sufficiently to remove scrap and clust. (Clean holes with special care.)

1. Using the SST(09222-27200) insert the valve stem seals(A).




ACIE086A

2. Insert the valves through the valve stem seals.

### NOTICE

Make sure the valves move up and down smoothly.

3. Install the valve spring (A) and valve spring retainer (B), then install the SST (09222-27300, the valve spring compressor). Compress the spring (A) and install the valve spring retainer lock (C).



SFDM38069L



# Cylinder Head Assembly

## EMC-39

- Lightly tap the end of each valve stem two or three times with a plastic mallet to ensure proper seating of the valve and valve spring retainer locks.

### NOTICE

Tap the valve stem only along its axis so you do not bend the stem.

- Assembly of lash adjuster.

- Until installing, lash adjuster shall be held upright so that gas oil in lash adjuster should not spill and assured that dust does not adhere to adjuster.
- Lash adjuster shall be inserted tenderly to the cylinder head not to spill gas oil from lash adjuster. In case of spilling air bent shall be done in accordance with the air bent procedure below.

### NOTICE

#### Air bent procedure

- In case of lash adjuster alone.

Stroke lash adjuster in gas oil 4~5 times by pushing its cap while pushing the ball down slightly by hard steel wire.

Take care not to severely push hard steel wire down since ball is several grams.

- After installed on engine


Lash adjuster might give out unusual noise if air is mingled. Apply slow racing from idle to 3,000rpm (Approximately one minute per one racing) and the air shall be removed from adjuster.

Therefore noise can be extinguished.

- Install the valve-caps.
- Put the cam followers on the lash adjusters and valve caps.
- After wiping down the camshaft and camshaft seal in the cylinder head, lubricate both surfaces and install the camshaft with engine oil.
- Confirm that cam followers are located on lash adjusters and their rollers are in touch with camshaft.
- In assembly camshaft bearing cap, to the cylinder head with the cylinder block, all pistons should be in the middle position between TDC(Top Dead Center) and BDC(Bottom ead Center) because valves come out of the bottom surface of the cylinder head.
- Install the bolts loosely.
- Tighten each bolt two turns at a time in the sequence shown below to ensure that the cam followers do not bind on the valves.

### Tightening torque

26.5 ~ 29.5N.m (2.7 ~ 3.0kgf.m, 19.5 ~ 21.7lb-ft)



ACIE073A

# EMC-40

# Engine Mechanical System


## Installation

Install the cylinder head in the reverse order of removal :


### NOTICE

- Always use a new head gasket.
- Cylinder head and cylinder block surface must be clean.
- Turn the crankshaft so the No.1 piston is at TDC(Top Dead Center).

1. Cylinder head dowel pins must be aligned.
2. Select the cylinder head gasket.
  - 1) Measure the piston protrusion from the upper cylinder block face (I) on 8 places (A ~ H) at T.D.C. Measure on the crankshaft center line considering the piston migration.




ACIE088A



ACIE089A

- 2) Install the gasket so that the identification mark faces toward the flywheel side.
- 3) Select the gasket in the table below using the average value of piston protrusions.

Although even the only 1 point is over than the each rank limit, use 1 rank upper gasket than specified in the table below.



ACIE090A

Displacement	2.0 L		
	Average of piston protrusion	0.194 ~ 0.337mm (0.0079 ~ 0.013in.)	0.337 ~ 0.440mm (0.013 ~ 0.017in.)
Gasket thickness	1.13 ± 0.05mm (0.0445 ± 0.0019in.)	1.23 ± 0.05mm (0.0484 ± 0.0019in.)	1.33 ± 0.05mm (0.0523 ± 0.0019in.)
Limit of each rank extent	0.43mm (0.0169in.)	0.53mm (0.0208in.)	-
Identification code			



# Cylinder Head Assembly

# EMC-41

3. Position the cylinder head assembly over the gasket.
4. Tighten the cylinder head bolts slightly.
5. Install the camshaft sprocket, aligning the timing mark.


**Tightening torque**

125 ~ 140N.m (12.7 ~ 14.3kgf.m, 92.2 ~ 103.3lb-ft)

6. Tighten the bolts to the specified torque

**Tightening torque**

63.7N.m (6.5kgf.m, 46.9lb-ft) + 120° + 120°



ACIE094A


**NOTICE**

- Tightening sequence of cylinder head bolt should be confirmed to the upper drawing.
- Cylinder head bolt must be replaced.

7. Install the high pressure pump assembly(A).

**Tightening torque :**

24.5 ~ 34.3N.m (2.5 ~ 3.5kgf.m, 18.0 ~ 25.3lb-ft)




SFDM38061L

8. Install the intake/exhaust manifold assemblies. (Refer to Intake and exhaust system in this group)

9. Install the metal tube(A) between the high pressure pump(B) and the common rail (C).

**Tightening torque :**

24.5 ~ 28.4N.m (2.5 ~ 2.9kgf.m, 18.0 ~ 20.9lb-ft)




SFDM38052L

## EMC-42

## Engine Mechanical System

10. If it is necessary to replace the oil seals on the cylinder head cover for injectors, use the SST(09351-27401).
11. Install the camshaft oil seal with use the SST(09212 - 27100)
12. Install the injector holder(A).



SFDM38049L

13. Install the head cover gasket in the groove of the cylinder head cover.

### NOTICE

- Cylinder head cover gasket must be replaced.
- Before installing the head cover gasket, thoroughly clean the seal and the groove.

14. Apply liquid gasket to the head cover gasket at the four corners of the recesses.

### NOTICE


- Use liquid gasket *LOCTITE 5699* or *TH1212D*.
- Check that the mating surface are clean and dry before applying liquid gasket.
- Do not install the parts if five minutes or more have elapsed since applying liquid gasket. Instead, reapply liquid gasket after removing old residue.
- After assembly, wait at least 30 minutes before filling the engine with oil.

15. Install the cylinder head cover bolts(A, B).

### Tighten torque

(A) : 21 ~ 25N.m (2.2 ~ 2.6kgf.m, 15.9 ~ 18.8lb-ft)

(B) : 8 ~ 10N.m (0.8 ~ 1.0kgf.m, 5.9 ~ 7.38lb-ft)



SNFEM6006D

### NOTICE

After assembly, wait at least 30 minutes before filling the engine with oil.


# Cylinder Head Assembly

## EMC-43


16. Insert the injectors(C), moving back the injector holders(A) with the bolts(B).

### Tighten torque :

24.5 ~ 28.4N.m (2.5 ~ 2.9kgf.m, 18.1 ~ 21.0lb-ft)




SFDM38048L




EDKD548A

17. Install the injector holder bolts(A) using the torx wrench(B).



ACIE059A

18. Install the injector plug(A).



SFDM38047L

- Make sure that the stopper of the plug faces 'OPEN' side. Otherwise pull and rotate the plug clockwise so the stopper should face 'OPEN' side.
- Apply the engine oil on the head cover mating surface or the gasket of the plug.
- Insert the plugs in the head cover.
- Rotate the plug inserted counterclockwise 90°.
- After installation, rotate the plug clockwise. If it is rotated, repeat the step a ~ d.

### NOTICE

*Plug gasket must be replaced.*


- Install the fuel tube. (Refer to Injector in FLC group)
- Install the intake manifold and exhaust manifold. (Refer to Intake and exhaust system in this group)
- Install the timing belt. (Refer to Timing system in this group)

# EMC-44

# Engine Mechanical System

## Cylinder Block

### Components




SFDM38025L

- 1. Oil pan
- 2. Oil screen

- 3. Dual mass flywheel
- 4. Cylinder block assembly

# Cylinder Block

# EMC-45



SFDM38040L


- 1. Badplate assembly
- 2. Center bearings
- 3. Main bearings
- 4. Crankshaft

- 5. Crankshaft position sensor wheel
- 6. Crankshaft rear oil seal
- 7. Piston cooling jet (Oil jet)
- 8. Cylinder block assembly



EMC-46

Engine Mechanical System



SFDM38041L

- 1. Piston ring No. 1
- 2. Piston ring No. 2
- 3. Oil ring
- 4. Piston pin
- 5. Snap ring


- 6. Piston
- 7. Connecting rod
- 8. Connecting rod bearings
- 9. Connecting rod bearing cap
- 10. Cylinder block assembly

# Cylinder Block

# EMC-47


## Removal

1. Remove the engine and transaxle assembly from the vehicle.(Refer to Engine and transaxle assembly in this Group)
2. Remove the alternator. (Refer to Alternator in EEC Group)
3. Remove the intake and the exhaust manifold.(Refer to Intake and exhaust system in this Group)
4. Remove the timing belt.(Refer to Timing system in this Group)
5. Remove the cylinder head assembly. (Refer to Cylinder head assembly in this Group)
6. Remove the engine oil level gauge(A).




SEDM37200L

7. Remove the Crankshaft Position Sensor(CKP)(A) and the oil pressure switch(B).




ACIE103A

8. Remove the heater and oil cooler return pipe assembly(A) after loosening the hose clamps(B) and the bolts(C, D, E).



ACIE104A

9. Remove the tube(A) between the vacuum pump and the cylinder head.




LCIF026A

# EMC-48


# Engine Mechanical System

- 10. Remove alternator lower bracket.
- 11. Remove the water inlet pipe assembly(A) by loosening a bolt(B) and clamps.




ACIE107A

- 12. Remove the air compressor(A). (Refer to Air compressor in HA Group)




ACIE108A

- 13. Remove the auto-tensioner (A) by loosening the bolt (B).




SEDM37105L

- 14. Remove the timing belt rear cover(A).



SFDM38030L

- 15. Remove the water pump assembly(A) with the gasket(B).




SEDM37107L

# Cylinder Block

# EMC-49

16. Remove the oil pan(A).




SEDM37108L

**CAUTION**

- Insert the SST between the oil pan and the bedplate assembly by tapping it with a plastic hammer in the direction of ① arrow.
- After tapping the SST with a plastic hammer along the direction of ② arrow around more than 2/3 edge of the oil pan, remove it from the bedplate assembly.
- Do not turn over the SST abruptly without tapping. It is result in damage of the SST.


17. Remove oil screen for removal of oil pump assembly(B).

18. Remove the crankshaft bolt(A), then separate the crankshaft sprocket(B).




SEDM37109L

19. Remove the oil-pump assembly(B) by loosening the bolts(A).



SEDM37110L

20. Remove the crankshaft key(A).



LCIF029A

# EMC-50

# Engine Mechanical System


## Replacement

### Main Bearing Selection

#### Crankshaft Bore Code Location

1. Letters have been stamped on the end of the block as a code for the size of each of the 5 main journal bores. Write down the crank bore codes.

If you can't read the codes because of accumulated dirt and dust, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.




ACIE129A

#### Discrimination of cylinder block

Discrimination		SIZE
Class	Mark	(Inside diameter of crank bore)
A	A	Ø64mm(2.5197in) (0 ~ +0.006mm)(0 ~ +0.0002in)
B	B	Ø64mm(2.5197in) (+0.006 ~ +0.012mm)(+0.0002~0.0005in)
C	C	Ø64mm(2.5197in) (+0.012 ~ +0.018mm)(+0.0005~0.0007in)

#### Main Journal Code Locations

1. The main Journal Codes are stamped on the No.1 web.



LCIF031A

#### Discrimination of crank shaft

Discrimination		SIZE
Class	Mark	(Outside diameter of main journal)
I	A	Ø60mm(2.3622in) (+0.014 ~ +0.020mm)(+0.0006~+0.0008in)
II	B	Ø60mm(2.3622in) (+0.008 ~ +0.014mm)(+0.0003~0.0006in)
III	C	Ø60mm(2.3622in) (+0.002 ~ +0.008mm)(+0.0001~+0.0003in)



# Cylinder Block

# EMC-51

2. Use the crank bore codes and crank journal codes to select the appropriate replacement bearings from the following table.

**NOTICE**

- Color code is on the edge of the bearing. Refer to the table in the step 6 of the main bearing clearance inspection.
- When using bearing halves of different colors, it dose not matter which color is used in the top or bottom.

**Installing procedure of bearing**

Shaft bore combination		Bearing mark	Oil clearance
Shaft mark	Bore mark		
I (A)	A (A)	A (BLUE)	0.024 ~ 0.042mm (0.0009 ~ 0.0017in)
	B (B)	B (BLACK)	
	C (C)	C (-)	
II (B)	A (A)	B (BLACK)	
	B (B)	C (-)	
	C (C)	D (GREEN)	
III (C)	A (A)	C (-)	
	B (B)	D (GREEN)	
	C (C)	E (YELLOW)	


**Rod Bearing Selection**

1. Inspect each connecting rod for cracks and heat damage.

**Connecting Rod Big End Bore Code Locations**

1. Each rod has tolerance range from 0 to 0.018mm (0.0007in.), in 0.006mm (0.0002in.) increments, depending on the size of its big end bore. It's then stamped with a letter (A, B or C) indicating the range. You may find any combination of letters in any engine.

If you can't read the code because of an accumulation of oil and varnish, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.



SFDM38042L

**NOTICE**

**Discrimination connecting rod**


Discrimination		SIZE
Class	Mark	(Inside diameter of connecting rod big end bore)
A	A	∅ 53mm(2.0866in) (0 ~ +0.006mm)(0~+0.0002in)
B	B	∅ 53mm(2.0866in) (+0.006 ~ +0.012mm)(+0.0002~0.0005in)
C	C	∅ 53mm(2.0866in) (+0.012 ~ +0.018mm)(0.0005~0.0007in)

# EMC-52

# Engine Mechanical System

## Connecting Rod Journal Code Locations

1. The connecting Rod Journal Codes are stamped on the No. 1 web.



LCIF031A

**NOTICE**

**Discrimination of crank shaft pin**

Discrimination		SIZE (Outside diameter of pin)
Class	Mark	
I	A	Ø50mm(1.9685in) (+0.020 ~ +0.026mm)(+0.0008~0.0010in)
II	B	Ø50mm(1.9685in) (+0.014 ~ +0.020mm)(+0.0006~0.0008in)
III	C	Ø50mm(1.9685in) (+0.008 ~ +0.014mm)(+0.0003~0.0006in)

2. Use the big end bore codes and rod journal codes to select appropriate replacement bearings from the following table.

**NOTICE**

Color code is on the edge of the bearing.

Refer to the table in the step 5 of rod bearing clearance inspection.

Shaft bore combination		Bearing mark	Oil clearance
Shaft mark	Bore mark		
I	A (A)	A (BLUE)	0.024 ~ 0.042mm (0.0009~0.0017in)
	B (B)	B (BLACK)	
	C (C)	C (WHITE)	
II	A (A)	B (BLACK)	
	B (B)	C (WHITE)	
	C (C)	D (GREEN)	
III	A (A)	C (WHITE)	
	B (B)	D (GREEN)	
	C (C)	E (YELLOW)	

# Cylinder Block

# EMC-53


## Piston, Pin and Connecting Rod

1. Apply engine oil to the piston pin snap rings and turn them in the ring grooves.

### NOTICE

Take care not to damage the ring grooves.

2. Remove both snap rings(A) carefully so they do not go flying or get lost. Wear eye protection.




LCIF033A

3. Remove the piston pin and the connecting rod assembly.
4. Measure the diameter of the piston pin.

## Piston Pin Diameter

Standard (New)

27.995 ~ 28.000mm (1.1022 ~ 1.1024in.)



ACIE134A

### NOTICE

Inspect the piston, piston pin and connecting rod when they are at room temperature.

5. Zero the dial indicator to the piston pin diameter.
6. Check the difference between the piston pin diameter and piston pin hole diameter in the piston.

## Piston Pin-to-Piston Clearance

Standard (New)

0.015 ~ 0.030mm (0.00059 ~ 0.00118in.)


7. Measure the piston pin-to-connecting rod clearance.

## Piston Pin-to-Connecting Rod Clearance

Standard (New)

0.022 ~ 0.039mm (0.00087 ~ 0.00154in.)

8. Set a snap ring in one side of piston pin hole.
9. Before inserting the piston pin, apply a sufficient amount of the lubricant oil to the outer surface of the piston, the inner surface of the piston pin hole and the small end bore of the connecting rod.
10. Insert the piston pin(A). Assemble the piston and connecting rod with the embossed front marks on the same side.



ACIE133A

### NOTICE

The front mark of the piston is embossed on the piston whereas some letters are located on a side surface of the connecting rod as the front mark.

### CAUTION


- Be sure to keep the small end bore, piston pin hole and piston pin undamaged and unscratched when inserting the piston pin.
- Set the snap rings to be sure for contacting with the groove of the piston pin hole.

## EMC-54

## Engine Mechanical System

### Piston Ring

- Using a piston, push a new ring into the cylinder bore.



ACIE137A

- Measure the piston ring end-gap(B) with a feeler gauge :

- If the gap is too small, check to see if you have the proper rings for your engine.
- If the gap is too large, recheck the cylinder bore diameter against the wear limits.

If the bore is over the service limit, the cylinder block must be rebored.

### Piston Ring End-Gap

Top ring

Standard (New) : 0.20 ~ 0.30mm (0.0079 ~ 0.012in.)

Second Ring

Standard (New) : 0.30 ~ 0.45mm (0.012 ~ 0.018in.)

Oil Ring

Standard (New) : 0.20 ~ 0.40mm (0.0079 ~ 0.0157in.)

- Using a ring expander, remove the old piston rings.

- Clearance all ring grooves thoroughly with a squared-off broken ring or ring groove cleaner with a blade to fit the piston grooves.

### Top ring groove

1.915 ~ 1.945mm (0.07539 ~ 0.07657in.)

### 2nd ring groove

2.060 ~ 2.080mm (0.08110 ~ 0.08189in.)

### Oil ring groove

3.020 ~ 3.040mm (0.11889 ~ 0.11969in.)

File down a blade if necessary.

Do not use a wire brush to clean the ring grooves, or cut the ring grooves deeper with cleaning tools.

### NOTICE

If the piston is to be separated from the connecting rod, do not install new rings yet.

- Install the piston rings.

### Piston Ring Dimensions

Top Ring (Standard)

Width : 2.85 ~ 3.15mm (0.116 ~ 0.128in.)

Thickness : 2mm (0.079in.)

Second Ring (Standard)

Width : 3.60 ~ 3.90mm (0.142 ~ 0.154in.)

Thickness : 1.970 ~ 1.995mm (0.078 ~ 0.079in.)

# Cylinder Block


# EMC-55

6. After installing a new set of rings, measure the ring-to-groove clearances :

## Top Ring Clearance

Standard (New)

0.083 ~ 0.133mm (0.00327 ~ 0.00524in.)



ACIE135A

## Second Ring Clearance


Standard (New)

0.065 ~ 0.110mm (0.00256 ~ 0.00433in.)

## Oil Ring Clearance

Standard (New)

0.03 ~ 0.07mm (0.00118 ~ 0.00276in.)



ACIE136A


## Disassembly

1. Remove the bedplate assembly.

- Remove the bolts(A).

To prevent warpage, unscrew the bolts in sequence 1/3 turn at a time : repeat the sequence until all bolts are loosened.

- Remove the bolts(B).




ACIE117A



## EMC-56

## Engine Mechanical System


2. Remove the connecting rod bearing caps(A) and bearings(B).
  - After removing No. 1 and 4 connecting rod bearing caps and turn the crankshaft No. 2 and 3 crankpins are at the top.
  - Remove the rest bearing caps and bearings.
  - Keep all caps/bearings in order.



ACIE118A


3. If you can feel a ridge of metal or hard carbon around the top of each cylinder, remove it with a ridge reamer. Follow the reamer manufacturer's instructions. If the ridge is not removed, it may damage the pistons as they are pushed out.
4. Drive out the piston assembly from the engine block.
  - a. Reinstall the connecting rod bearings and caps after removing each piston/connecting rod assembly.
  - b. To avoid mixup on reassembly, mark each piston/connecting rod assembly with its cylinder number.

5. Lift the crankshaft(A) out of the cylinder block(B), being careful not to damage the journals.



ACIE119A

6. Remove the piston oil jet(A) by loosening the hexagonal bolt(B) with a hexagonal wrench.



ACIE120A

# Cylinder Block

# EMC-57

## Inspection

### Flywheel

1. Inspect ring gear teeth for wear or damage.
2. Flywheel bolts should be free from detrimental flaws.


### Connecting Rod and Crankshaft End Play

1. Measure the connecting rod end play with a feeler gauge(A) between the connecting rod(B) and crankshaft(C).

### Connecting Rod End play

Standard (New) : 0.10 ~ 0.35mm (0.004 ~ 0.014in.)

Service Limit : 0.40mm (0.016in.)



ACIE131A

2. If the connecting rod end play is out-of-tolerance, install a new connecting rod, and recheck. If it is still out-of-tolerance, replace the crankshaft.
3. If the end play is excessive. Replace parts as necessary.

## Main Bearing Clearance

1. To check main bearing-to-journal oil clearance, remove the bed plate, the crankshaft and the bearing halves.
2. Clean each main journal and bearing half with a clean shop towel.
3. Cut plastigauge to the same length as the width of the bearing.
4. Place one strip of plastigauge across each main journal on the cylinder block and the bed plate, avoiding the oil holes.
5. Reinstall the bearings, crankshaft and bed plate then torque the bolts to the specified value.

### NOTICE

*Do not rotate the crankshaft during inspection.*

6. Remove the bed plate and bearings again and measure the widest part of the plastigauges with a calibrated scale on which an arrow of marks has been printed.

## Main bearing-to-journal Oil Clearance

Standard (valve)


0.024 ~ 0.042mm (0.0009 ~ 0.0017in.)

### NOTICE

**Discrimination of crankshaft main bearing**

## EMC-58

## Engine Mechanical System

Discrimination		SIZE (Thickness of bearing)	Place of identification mark
Class	Mark		
E	Yellow	1.987~1.990mm (0.0782~0.0783in)	
D	Green	1.984~1.987mm (0.0781~0.0782in)	
C	-	1.981~1.984mm (0.0780~0.0781in)	
B	Black	1.978~1.981mm (0.0779~0.0780in)	
A	Blue	1.975~1.978mm (0.0778~0.0779in)	

7. If the plastigauge measure too wide or too narrow, remove the crankshaft, and remove the upper half of the bearing. Install a new, complete bearing with the same color code(s), and recheck the clearance. Do not file, shim, or scrape the bearings to adjust clearance.
8. If the plastigauge shows the clearance is still incorrect, try the next larger or smaller bearing (the color listed above or below that one), and check again. If the proper clearance cannot be obtained by using the appropriate larger or smaller bearings, replace the crankshaft and start over.

**Rod bearing Clearance**

1. Remove the connecting rod cap and bearing half.
2. Clean the crankshaft rod journal bearing half with a clean shop towel.
3. Place plastigauge across the rod journal.
4. Reinstall the bearing half and cap, and torque the bolt.


**NOTICE**

*Do not rotate the crankshaft during inspection.*

5. Remove the rod cap and bearing half and measure the widest part of the plastigauge.

**Connecting Rod Bearing-to-Journal Oil**

Clearance : 0.024 ~ 0.042mm (0.0009 ~ 0.0017in.)



ACIE132A


# Cylinder Block

## EMC-59

6. If the plastigauge measure too wide or too narrow, remove the upper half of the bearing, install a new, complete bearing with the same color code(s), and recheck the clearance. Do not file, shim, or scrape the bearings or the caps to adjust clearance.

### NOTICE

#### Discrimination of connecting rod bearing

Discrimination		Size (Thickness of bearing)	Place of Identification
Class	Mark		
E	Yellow	1.484 ~ 1.487mm (0.0584~0.0585in)	 <p>The diagram shows a cross-section of a bearing cap. An arrow labeled 'Mark' points to a small notch on the inner surface. Another arrow labeled 'Color' points to the outer surface of the cap.</p>
D	Green	1.481 ~ 1.484mm (0.0583~0.0584in)	
C	White	1.478 ~ 1.481mm (0.0582~0.0583in)	
B	Black	1.475 ~ 1.478mm (0.0581~0.0582in)	
A	Blue	1.472 ~ 1.475mm (0.0580~0.0581in)	

7. If the plastigauge shows the clearance is still incorrect, try the next larger or smaller bearings (the color listed above or below that one), and check clearance again. If the proper clearance cannot be obtained by using the appropriate larger or smaller bearing, replace the crankshaft and start over.

## EMC-60

## Engine Mechanical System

### Crankshaft


#### Straightness

##### NOTICE

- Clean the crankshaft oil passages with pipe cleaners or a suitable brush.
  - Check the keyway and threads.
1. Support the crankshaft with V-blocks.
  2. Measure runout on all main journals to make sure the crank is not bent. Rotate the crankshaft two complete revolutions. The difference between measurements on each journal must not be more than the standard value.

#### Crankshaft Total Indicator Runout

Standard (New) : 0.06mm (0.0024in.) max.




LCIF036A

#### Out-of-Round and Taper

1. Measure out-of-round at the middle of each rod and main journal in two places. The difference between measurements on each journal must not be more than the service limit.

#### Journal Out-of-Round

Standard (New) : 0.0035mm (0.0001in.) max.



LCIF037A

2. Measure taper at the edge of each rod and main journal. The difference between measurements on each journal must not be more than the service limit.

#### Journal Taper

Standard (New) : 0.006mm (0.0002in.) max.




# Cylinder Block

# EMC-61

## Block and Piston

1. Check the piston for distortion or cracks.
2. Measure the piston diameter at a point 10mm (0.4in) from the bottom of the skirt. There are three standard-size pistons (A, B and C). The letter is stamped on the top of the piston. Letters are also stamped on the block as cylinder bore sizes.




ACIE129A


### Piston Diameter and Cylinder Bore

Standard value :

Grade	A	B	C
Piston Outer Diameter	82.92 ~ 82.93mm (3.2646~3.2650in)	82.93 ~ 82.94mm (3.2650~3.2654in)	82.94 ~ 82.95mm (3.2654~3.2657in)
Cylinder Bore	83.00 ~ 83.01mm (3.2677~3.2681in)	83.01 ~ 83.02mm (3.2681~3.2685in)	83.02 ~ 83.03mm (3.2685~3.2689in)
Clearance	0.070 ~ 0.090mm(0.0028~0.0035in)		



ACIE139A



ACIE140A

## EMC-62

## Engine Mechanical System

- Measure wear and taper in direction X and Y at three levels in each cylinder as shown. If measurements in any cylinder are beyond the cylinder bore standard value, replace the block.

### Oversize

0.25 : 83.250 ~ 83.280mm (3.2776 ~ 3.2787in.)

0.50 : 83.500 ~ 83.530mm (3.2874 ~ 3.2886in.)

### Bore Taper


Limit : (Difference between first and third measurement)

0.01mm (0.0004in.) MAX.

Level 1 : No. 1 piston ring position at TDC(Top Dead Center).

Level 2 : Center of cylinder.

Level 3: Bottom of cylinder.



ACIE139A

- Scored or scratched cylinder bores must be honed.
- Check the top of the block for warpage. Measure along the edges and across the center.

### Engine Block Warpage

Standard (New)

0.042mm (0.00165in.) for width

0.096mm (0.00378in.) for length

0.012mm (0.00047in.)/50×50mm

Service Limit : 0.10mm (0.004in.)

- Calculate the difference between the cylinder bore diameter and the piston diameter. If the clearance is near or exceeds the standard value, inspect the piston and cylinder block for excessive wear.

### Piston-to-Cylinder Clearance

Standard (New) :

0.070 ~ 0.090mm (0.0028 ~ 0.0035in.)

Oversize Piston Diameter :

0.25 : 83.170 ~ 83.200mm (3.2744 ~ 3.2756in.)

0.50 : 83.420 ~ 83.450mm (3.2843 ~ 3.2854in.)

### Cylinder Honing

Only a scored or scratched cylinder bore must be honed.

- Measure the cylinder bores.

If the block is to be reused, hone the cylinders and remeasure the bores.

- Hone the cylinder bores with honing oil and a fine stone. Do not use stones that are worn or broken.
- When honing is complete, thoroughly clean the engine block of all metal particles. Wash the cylinder bores with hot soapy water, then dry and oil them immediately to prevent rusting. Never use solvent, it will redistribute the grit on the cylinder walls.
- If scoring or scratches are still present in the cylinder bores after honing to the service limit, rebore the cylinder block. Some light vertical scoring and scratching is acceptable if it is not deep enough to catch your fingernail and does not run the full length of the bore.


# Cylinder Block

# EMC-63

## Reassembly

### Piston


1. Remove the connecting rod caps then install the ring compressor and check that the bearing is securely in place.
2. Position the marks facing the timing belt side of the engine.



LCIF039A

3. Position the piston in the cylinder and tap it in using the wooden handle of hammer.

Maintain downward force on the ring compressor to prevent the rings from expanding before entering the cylinder bore.



ACIE146A

4. Stop after the ring compressor pops free, and check the connecting rod-to-crank journal alignment before pushing the piston into place.
5. Check the connecting rod bearing clearance with plastigauge.
6. Apply engine oil to the bolt threads, then install the rod caps with bearings.

### Crankshaft

1. Install the oil jets, tightening the hexagon socket head bolts with the torque 8.8 ~ 12.7Nm (0.9 ~ 1.3kgf.m, 6.5 ~ 9.4lb-ft)
2. Apply a coat of engine oil to the main bearings.
3. Install the bearing halves in the engine block.
4. Hold the crankshaft so rod journal No. 2 and rod journal No. 3 are straight up.
5. Lower the crankshaft into the block.
6. Install the bearing halves in the bed plate after applying a coat of engine oil.
7. Install the bed plate(C) to the cylinder block after applying the sealant (omniFIT FD2.0, DREIBOND 5105 or HYLOMAR 3000).


### Tightening torque

15mm(B)

27.5 ~ 31.4N.m + (2.8 ~ 3.2kgf.m, 20.3 ~ 23.1lb-ft) + 120°

12mm(A)

33.3 ~ 37.3N.m (3.4 ~ 3.8kgf.m, 24.6 ~ 27.5lb-ft)




ACIE117A

8. Rotate the crankshaft clockwise to be seated properly.
9. Check the main bearing clearance with plastigauge.

## EMC-64

## Engine Mechanical System

10. Install the piston and connecting rod assemblies.
  - a. Apply coat of engine oil to the connecting rod bearings.
  - b. Install the bearing halves in the connecting rods.
  - c. Insert the assemblies into the cylinder bores.
  - d. Install the connecting rod caps and bolts finger tight
  - e. Rotate the crankshaft clockwise, seat the journals into connecting rod No.2 and connecting rod No.3. Install the connecting rod caps and bolts finger tight. Install caps so the bearing recess is on the same side as the recess in the rod.
  - f. Check the connecting rod bearing clearance with plastigage.
  - g. Apply engine oil to the bolt threads, then install the rod caps within bearings and torque the bolts to 25N.m + 90° (2.5kgf.m + 90°, 18.44lb-ft + 90°).
11. Using the SST(09231-27000), install the crankshaft oil seal(A) squarely.



ACIE147A

12. Clean and dry the mating surfaces.

Apply a light coat of oil to the crankshaft and to the lip of the seal.

## Installation

1. Clean and dry the oil pump mating surface.
2. Install the oil pump
  - a. Install a new crankshaft oil seal in the oil pump.
  - b. Apply liquid gasket evenly to the block mating surface of the oil pump.


Standard liquid gaskets (or sealants)

LOCTITE5900 or TB1217H

- Apply liquid gasket in a wide bead : 2.5 ± 0.5m
  - Apply the liquid gasket without stoping.
  - Assemble the oil pump within 5 minutes after applying.
- c. Grease the lips of the oil seals.
  - d. Align the oil pump gear with the crankshaft drive gear and install the oil pump(B).

## Tightening torque(A)

19.6 ~ 26.5N.m (2.0 ~ 2.7kgf.m, 14.5 ~ 19.51lb-ft)




SEDM37110L

- e. Clean the excess grease off the crankshaft and check the seals for distortion.

# Cylinder Block

# EMC-65

3. Install the crankshaft key(A) on the crankshaft assembly.



LCIF040A


4. Insert the crankshaft sprocket(B) then tighten the crankshaft bolt(A).

### Tightening torque

196.1 ~ 205.9N.m (20.0 ~ 21.0kgf.m, 144.7 ~ 151.9lb-ft)

### NOTICE

Align the timing mark on the sproket.



SEDM37109L

5. Install oil screen.

### NOTICE

The bolt B should be tightened after the installation of the bolt A.

6. Clean and dry the bedplate and the oil pan mating surfaces.  
7. Apply liquid gasket evenly to the bed plate mating surface of the oil pan. Install the oil pan.


### NOTICE

- Standard liquid gasket : LOCTITE 5900 or TB1217H
- Assemble the oil pan in 5 minutes after applying the liquid gasket.
- Apply liquid gasket in a 3mm wide bead without stopping.
- The clearance between the liquid gasket end and the flange inner end at T-joint should be 2~3mm(2places)

8. Tighten the bolt in two or three steps. In the final step, tighten all bolts.

### Tightening torque

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



KCQG018A

### NOTICE

After installing the oil pump assembly and the oil pan, remove the oil cooler and fill the 50cc engine oil.



# EMC-66

# Engine Mechanical System

9. Install water pump(A) with new gasket(B).


**Tighten torque**

Bolt A

47.1 ~ 51.0N.m (4.8 ~ 5.2kgf.m, 34.7 ~ 37.6lb-ft)

Bolt B

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SEDM37107L

10. Install the timing belt rear cover(A).

**Tightening torque**

7.8 ~ 11.8N.m (0.8 ~ 1.2kgf.m, 5.8 ~ 8.7lb-ft)



SFDM38030L

11. Install the auto-tensioner(A).


**Tightening torque**

Pivot bolt(B)

49.0 ~ 53.9N.m (5.0 ~ 5.5kgf.m, 36.2 ~ 39.8lb-ft)


Stop bolt

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SEDM37105L

12. Install the air compressor(A). (Refer to Air compressor in HA Group)



ACIE108A


# Cylinder Block

# EMC-67

13. Install the water inlet pipe assembly(A), tightening the bolt(B).

**Tightening torque**

19.6 ~ 26.5N.m (2.0 ~ 2.5kgf.m, 14.5 ~ 19.5lb-ft)



EDKD564A

14. Install the heater and oil cooler return pipe(A) assembly.


**Tightening torque**

Rear side bolt and left side bolt(C, D)

19.6 ~ 26.5N.m (2.0 ~ 2.5kgf.m, 14.5 ~ 19.5lb-ft)

Right side bolt(E)

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)




ACIE104A

15. Install the Crankshaft Position Sensor(CKP)(A) and the oil pressure switch(B).

**Tightening torque**

(A) : 3.9 ~ 5.9N.m (0.4 ~ 0.6kgf.m, 2.9 ~ 4.3lb-ft)

(B) : 14.7 ~ 21.6N.m (1.5 ~ 2.2kgf.m, 10.8 ~ 15.9lb-ft)



ACIE103A


16. Install the cylinder head assembly. (Refer to Cylinder head assembly in this group)

17. Install the intake/exhaust manifold assemblies. (Refer to Intake and exhaust system in this group)

18. Install the oil level gauge(A).

**Tightening torque**

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



ACIE102A

**NOTICE**

Apply engine oil to O-ring before assembly.


19. Install the timing belt. (Refer to Timing system in this group)

# EMC-68

# Engine Mechanical System

## Cooling System

### Components



SFDM38026L

- 1. Water pump
- 2. Gasket
- 3. Water inlet pipe

- 4. Heater hose & pipe
- 5. Cylinder block

# Cooling System

## EMC-69


### Inspection

#### Thermostat

Replace the thermostat if it is open at room temperature.

To test closed thermostat :

1. Suspend the thermostat in a container of water.  
Do not let the thermometer touch the bottom of the hot container.



ACIE153A

2. Heat the water and check the temperature with the thermometer. Check the temperature at which the thermostat first opens, and at which it is fully open.
3. Measure the lift height of the thermostat when it is fully open.

#### STANDARD THERMOSTAT

Lift height : above 8.0mm (0.31in.)

Starts opening:  $85 \pm 1.5^{\circ}\text{C}$  ( $185 \pm 34.7^{\circ}\text{F}$ )

Fully open :  $100^{\circ}\text{C}$  ( $212^{\circ}\text{F}$ )




# EMC-70

# Engine Mechanical System

## Removal


### Water Pump

1. Remove radiator cap to speed draining.
2. Drain the engine coolant after removing drain plug(A).




SEDM17003L

3. Remove the timing belt. (Refer to Timing system in this group)
4. Remove the timing belt rear cover(A).



SFDM38030L

5. Remove the water pump(A) with the gasket(B) by removing four bolts. (One bolt A and three bolt B)



LCIF027A

6. Inspect, repair and clean the mating surface on the engine block.
7. Install the water pump, with a new gasket in the reverse order of removal.

### Tightening torque

For timing belt rear cover

7.8 ~ 11.8N.m (0.8 ~ 1.2kgf.m, 5.8 ~ 8.7lb-ft)

For water pump

Bolt A :

47.1 ~ 51.0N.m (4.8 ~ 5.2kgf.m, 34.7 ~ 37.6lb-ft)

Bolt B :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)

8. Clean the spilled engine coolant.



# Cooling System


# EMC-71

## Radiator

1. Remove the radiator cap to speed draining.
2. Loosen the radiator drain plug (A) and drain engine coolant.

### Tightening torque

7.8 ~ 15.7N.m (0.8 ~ 1.6kgf.m, 5.8 ~ 11.6lb-ft)




SEDM17003L

3. Remove the air duct (A).


### Tightening torque

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)




SFDM38001L

4. Remove the radiator upper hose(A) and the coolant bleed hose(B).




SNFEM6002D

5. Remove the intercooler hose (A).



SFDM38018L

6. Remove the radiator lower hose(A).




SEDM37007L

# EMC-72

# Engine Mechanical System

- Remove the mounting clips (10EA), then temporarily loosen the bumper upper cover (A).



SFDM38019L


**NOTICE**

The bumper upper cover is assembled with the front bumper.

If necessary, remove the front bumper.

(Refer to BD group)

- Disconnect the fan motor connector (A) and remove the radiator mounting bracket (B).



SEDM37014L


**Tightening torque**

7 ~ 11N.m (0.7 ~ 1.1kgf.m, 5.0 ~ 7.95lb-ft)

- Pull radiator upper from engine room.
- Install in the reverse order of removal.


**Thermostat**

- Drain the engine coolant.
- Remove the radiator upper hose(A) and coolant bleeder hose(B).



SNFEM6002D

- Remove the coolant inlet fitting.
- Remove the thermostat(A).



SFDM38029L

**Tightening torque**

19.6 ~ 24.5N.m (2.0 ~ 2.5kgf.m, 14.4 ~ 18.08lb-ft)


- To install, reverse the removal order with a new gasket.

# Lubrication System

# EMC-73

## Lubrication System

### Components



SFDM38020L


- |                          |                         |                       |
|--------------------------|-------------------------|-----------------------|
| 1. Oil filter assembly   | 6. Oil cooler           | 11. Oil pump cover    |
| 2. Oil filter upper cap  | 7. Oil pump housing     | 12. Relief plunger    |
| 3. Oil filter element    | 8. Oil seal             | 13. Relief spring     |
| 4. Oil filter lower case | 9. O-ring               | 14. Relief cap washer |
| 5. Oil filter fitting    | 10. Oil pump drive gear | 15. Relief cap        |

## EMC-74

## Engine Mechanical System


Removal  
Oil Pump

1. Drain the engine oil.
2. Remove the crankshaft pulley(A).




SFDM38035L

3. Remove the timing belt. (Refer to Timing system in this group)
4. Remove the timing belt auto tensioner(A).




SMGEM6301D

5. Remove the timing rear cover(A).



SFDM38031L

6. Separate oil pan(A).



SEDM37108L


## ⚠ CAUTION

- Insert the SST between the oil pan and the bedplate assembly by tapping it with a plastic hammer in the direction of ① arrow.
  - After tapping the SST with a plastic hammer along the direction of ② arrow around more than 2/3 edge of the oil pan, remove it from the bedplate assembly.
  - Do not turn over the SST abruptly without tapping. It is result in damage of the SST.
7. Remove the oil screen.

# Lubrication System


# EMC-75

8. Remove the crankshaft sprocket(B) with bolt(A).



KCQG019A

9. Remove the mounting bolts(A) and the oil pump assembly(B).



SEDM37110L

## Replacement Engine Oil Filter

### NOTICE

There are two kinds of oil filters. One is ECO type and the other is spin on type.

ECO type :

1. Remove the oil filter upper cap from lower case with SST(09263-2E000 the oil filter wrench.).
2. Inspect the threads and replace rubber packing with new one. Wipe off the seat on the oil filter assembly, then apply a light coat of oil to the oil filter assembly upper cap packing.
3. Install the new oil filter element by hand to the upper cap.
4. After the rubber seal seats, tighten the oil filter clockwise with the special tool.

### Capacity

Total : 7.4 L (7.81 US qts, 6.51 Imp qts)


Oil pan : 6.2 L (6.55 US qts, 5.45 Imp qts)

Drain and refill including oil filter :

6.7 L (7.07 US qts, 5.89 Imp qts)

Spin on type :

1. Remove the oil filter(A) with the SST(09263-27000, the oil filter wrench).



SEDM37112L

2. Inspect the threads and the packing on the apply a light coat of new oil filter. Wipe off the seat.
3. Install the new oil filter by hand.
4. After the packing seats, tighten the oil filter clockwise with the SST(09263-27000).




# EMC-76

# Engine Mechanical System


## Disassembly Oil Pump

1. Remove the three hexagon socket head bolts(A) from the oil pump cover(B).




ACIE159A

2. Remove the out rotor from the oil pump housing.
3. Remove the old oil seals from the oil pump housing.
4. Remove the O ring(A) from the oil pump housing.



SEDM37113L

5. Remove the relief cap(A), relief cap washer(B), relief spring(C) and relief plunger(D).



SEDM37114L

6. Remove the oil filter. Refer to the engine oil filter replacement.
7. Remove the oil cooler and hose assembly after separating the oil filter fitting.

# Lubrication System

# EMC-77

## Inspection


### Oil Pump

1. Check the inner-to-outer rotor tip clearance between the inner rotor(A) and outer rotor(B). If the inner-to-outer rotor clearance exceeds the service limit, replace the inner and outer rotors.

#### Inner Rotor-to-Outer Rotor tip Clearance

Standard (New)

0.08mm (0.00315in.)




ACIE163A

2. Check the housing-to-rotor axial clearance between the rotor and oil pump cover housing. If the housing-to-rotor axial clearance exceeds the service limit, replace the set of inner and outer rotors and/or the pump housing.

#### Housing-to-Rotor Axial Clearance

Standard (New)

0.020 ~ 0.070mm (0.00079 ~ 0.00276in.)



ACIE162A


3. Inspect both rotors and the oil pump cover housing for scoring or other damage. Replace parts if necessary.

## EMC-78

## Engine Mechanical System


### Oil Pressure Switch

1. Remove the oil pressure switch from the engine block.
2. Connect a tester (ohm range) between the terminal and the body of the switch to check for continuity. The switch is normal if there is continuity. If there is no continuity, replace the switch.



ACIE164A

3. Insert a thin rod in the oil hole of the switch and push it in lightly. The switch is normal if no continuity is detected (infinite resistance on the tester). If there is continuity, replace the switch.



ACIE165A

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# Lubrication System

## EMC-79

### Selection Of Engine Oil

ACEA classificaton : C3 (with CPF), B4 (without CPF)

SAE viscosity grades : Refer to the recommended SAE viscosity number



SCMEM7200L

### NOTICE

For best performance and maximum protection of all types of operation, select only those lubricants which :

1. Satisfy the requirement of the ACEA classification.
2. Have proper SAE grade number for expected ambient temperature range.
  - Lubricants that do not have both an SAE grade number and ACEA service classification on the container should not be used.
  - The ACEA certified engine oil is required as a service engine oil. Only in case that ACEA certified engine oil is not available, the API certified engine oil (API CH-4 or above) is allowed restrictively.
  - For the vehicle equipped with CPF, the service

engine oil quality should meet the ACEA C3 grade. However, oil refill with small amount of ACEA B4 grade between oil change intervals is possible.

## EMC-80

## Engine Mechanical System


### Engine Oil

1. Park the vehicle on the flat ground.
2. Turn the engine off.
3. The oil level should be between the 'L' and 'F' marks on the dipstick, then.

If low, check for leakage and add oil up to the "F" mark.

#### NOTICE

When refill the engine oil, use the same type engine oil with current engine oil.



4. Check the oil for deterioration, entry of coolant or fuel, and engine oil viscosity.

SBLEM6027L


### Reassembly

#### Oil Pump

1. Insert the relief plunger(D), the relief spring(C) and the relief cap washer(B). Then torque the relief cap(A).


#### Tightening torque

41.2 ~ 51.0N.m (4.2 ~ 5.2kgf.m, 30.4 ~ 37.6lb-ft)



SEDM37114L

2. Install the new O ring(A) to the oil pump housing(B) after applying engine oil.




SEDM37113L



# Lubrication System

# EMC-81

3. Assemble the inner/outer rotors with engine oil the drive gear and the oil pump cover.
4. Install the oil pump cover(B)assembly to the oil pump housing with the three hexagon socket head bolts(A).



ACIE159A

5. The oil seal which was disassembled in 'Disassembly' step is recommended to be installed after the installation of the crankshaft.

## Installation

1. Install the oil pump assembly and the oil pan on the cylinder block.

### Tightening torque

19.6 ~ 26.5N.m (2.0 ~ 2.7kgf.m, 14.5 ~ 19.5lb-ft)

#### NOTICE

Standard liquid gasket : LOCTITE 5900 or TB1217H

2. Install the oil screen.
3. Install the oil pan.

### Tightening torque

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)

#### NOTICE

Standard liquid gasket : LOCTITE 5900 or TB1217H

Assemble the oil pan in 5 minutes after applying the liquid gasket.

Apply liquid gasket in a 3mm wide bead without stopping.

The clearance between the liquid gasket end and the flange inner end at T-joint should be 2 ~ 3mm.(2places)

4. Fill the engine oil in the room below the oil cooler (50cc).
5. Tightening the oil filter fitting, install the oil cooler and hose assembly.

#### NOTICE

Before assembling the oil cooler apply engine oil on the O-ring.

### Tightening torque

47.1 ~ 51.0N.m (4.8 ~ 5.2kgf.m, 34.7 ~ 37.6lb.ft)

6. Install the oil filter after applying engine oil on the O-ring.


# EMC-82

# Engine Mechanical System

7. Install the crankshaft sprocket(B) with bolt(A).

**Tightening torque**


196.1 ~ 205.9N.m (20.0 ~ 21.0kgf.m, 144.7 ~ 151.9lb-ft)



8. Install the timing belt rear cover(A).

**Tightening torque**


7.8 ~ 11.8N.m (0.8 ~ 1.2kgf.m, 5.8 ~ 8.7lb-ft)



9. Install the auto tensioner(A).

**Tightening torque**

49.0 ~ 53.9N.m (5.0 ~ 5.5kgf.m, 36.2 ~ 39.8lb-ft)




10. Install timing belt. (Refer to Timing system in this group)

11. Install the crankshaft pulley(A).

**Tightening torque**

29.4 ~ 33.3N.m (3.0 ~ 3.4kgf.m, 21.7 ~ 24.6lb-ft)




# Intake And Exhaust System

# EMC-83

## Intake And Exhaust System

### Intercooler

#### Components



SFDM38006L

- 1. Intercooler assembly
- 2. Intercooler mounting bracket
- 3. Booster pressure sensor


- 4. Intercooler inlet pipe & hose assembly
- 5. Intercooler inlet hose
- 6. Intercooler outlet hose

## EMC-84

## Engine Mechanical System


### Replacement

1. Remove the intercooler outlet hose (A).
2. Disconnect the booster pressure sensor connector (B).



SEDM37006L

3. Remove the mounting clips then temporarily loosen the bumper upper cover (A).
4. Remove intercooler inlet hose and intercooler mounting bracket (B).



SFDM38005L

### Tightening torque

6.8 ~ 10.8N.m (0.7 ~ 1.1kgf.m, 5.1 ~ 8.0lb-ft)

5. Remove the intercooler assembly from the vehicle.
6. Installation is in the reverse order of removal.



# Intake And Exhaust System


# EMC-85

## Intake Manifold

### Components

**NOTE**

- Use new gasket when reassembly.
- Check for folds or scratches on the surface of the gasket.
- Replace with a new gasket if damaged.



Torque : N.m (kgf-m, lb-ft)

SFDM38021L

- |  |                       |
|--|-----------------------|
| 1. Intake manifold & Swirl control actuator assembly | 5. EGR cooler         |
| 2. Water bypass connector                            | 6. EGR cooler hose    |
| 3. Swirl control valve                               | 7. EGR pipe assembly  |
| 4. Wiring mounting bracket                           | 8. EGR valve assembly |
|  | 9. EGR elbow          |




# EMC-86

# Engine Mechanical System


## Removal

1. Remove the radiator upper hose(A) and the coolant bleed hose(B).




SNFEM6002D

2. Remove the alternator. (Refer to Alternator in EEC Group).
3. Remove the intercooler hose(A) and disconnect the booster pressure sensor(BPS) connector(B).




SFDM38022L

4. Disconnect the engine wire harness connectors from intake manifold side.
  - a. Disconnect the rail pressure sensor connector(A) and the water temperature sensor connector(B).



SEDM37115L

5. Disconnect the camshaft position sensor connector (A), pressure control valve connector (B), swirl value control actuator connector (C) and throttle body actuator connector (D).



SMGEM6011D

6. Remove oil level gauge.


# Intake And Exhaust System

# EMC-87

7. Remove the thermostat housing(A).

**Tightening torque :**

20 ~ 25N.m (2.0 ~ 2.5kgf.m, 15 ~ 18lb-ft)




SFDM38027L

8. Remove the throttle body(A).


**Tightening torque :**

10 ~ 12N.m (1.0 ~ 1.2kgf.m, 7 ~ 9lb-ft)



SEDM37116L

9. Remove the thermostat hose(A).




SMGEM6013D

10. Remove the intake manifold(A).

**Tightening torque :**

14.7 ~ 21.6N.m (1.5 ~ 2.2kgf.m, 10.8 ~ 15.9lb-ft)



SEDM37300L

11. Installation is in the reverse order of removal.

# EMC-88


# Engine Mechanical System

## Exhaust Manifold

### Components

**NOTE**

- Use new gasket and self-locking
- Check for folds or scratches on the surface of the gasket.
- Replace with a new gasket if damaged.



Torque : N.m (kgf-m, lb-ft)

SFDM38028L


- |                                   |                                       |                                  |
|-----------------------------------|---------------------------------------|----------------------------------|
| 1. Exhaust manifold               | 6. Turbo charger[C.P.F vehicle]       | 11. Oil drain hose               |
| 2. Turbo charger oil drain gasket | 7. Turbo charger[Non C.P.F vehicle]   | 12. Exhaust manifold gasket      |
| 3. Turbo charger discharger pipe  | 8. Warm up catarytic converter[W.C.C] | 13. Heat protector               |
| 4. Turbo charger exhaust gasket   | 9. Oil feed pipe                      | 14. Turbo charger support braket |
| 5. Turbo charger intake gasket    | 10. Oil drain pipe                    |                                  |

# Intake And Exhaust System

## EMC-89

### Removal


1. Remove the air cleaner assembly.
  - 1) Disconnect the Air Flow Sensor (AFS) connector(A).
  - 2) Remove the air intake hose clamp first, then remove the air cleaner assembly (B).
  - 3) Disconnect the engine control module (ECM) connector (C).
  - 4) Remove the air cleaner assembly(D).



SEDM37004L


2. Remove the front muffler(A).

### [C.P.F Equipped Vehicle]



SFDM38004L

### [Non C.P.F Vehicle]




SEDM37008L

### Tightening torque :

40 ~ 60N.m (4.0 ~ 6.0 kgf.m, 30 ~ 43 lb-ft)

3. Remove the intercooler hose(A).




SMGEM6014D

## EMC-90


## Engine Mechanical System

4. Disconnect the engine wire harness connectors from exhaust manifold.

- 1) Disconnect the injector connector(A).
- 2) Disconnect the Lambda sensor connector(B).
- 3) Disconnect the VGT exhaust gas temperature sensor connector (C). [Only C.P.F]
- 4) Disconnect the EGR actuator(D), fuel temperature sensor(E) and the fuel pressure regulator connector(F).




5. Remove the brake booster vacuum hose(A).




LCIG008A

6. Remove the heater hose(A) and EGR cooler hose(B).



SMGEM6017D



SMGEM6310D

7. Remove VGT actuator vacuum hose.



# Intake And Exhaust System

# EMC-91


8. Remove the EGR valve and cooler assembly(A).

**Tightening torque :**

Nuts(B), Bolt(C)

19.6 ~ 26.5N.m (2.0 ~ 2.7kgf.m, 14.5 ~ 19.5lb-ft)

Nuts(D) : 24.5 ~ 29.4N.m (2.5 ~ 3.0kgf.m, 18.1 ~ 21.7lb-ft)




LCIG024A

9. Remove the oil separator(A).

**Tightening torque :**

8 ~ 12N.m (0.8 ~ 1.2kgf.m, 6 ~ 9lb-ft)




LCIG025A


10. Remove the turbo charger heat protector(A, B).

**Tightening torque :**

16.7 ~ 21.6N.m (1.7 ~ 2.2kgf.m, 12.3 ~ 15.9lb-ft)



LCIG026A




LCIG027A

## EMC-92

11. Remove the heater pipe heat protector(A).

**Tightening torque :**

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)




LCIG028A

12. Disconnect the turbo charger oil feed pipe(A) and oil return hose(B).

13. Remove turbocharger support bracket mounting bolts(C).

**Tightening torque :**

34.3 ~ 44.1N.m (3.5 ~ 4.5kgf.m, 25.3 ~ 32.5lb-ft)



SEDM37206L

## Engine Mechanical System

14. Remove the EGR elbow(A) and turbocharger & exhaust manifold assembly(B).

**Tightening torque :**


EGR elbow bolt and nuts

19.6 ~ 26.5N.m (2.0 ~ 2.7kgf.m, 14.5 ~ 19.5lb-ft)

Exhaust manifold nuts


24.5 ~ 37.3N.m (2.5 ~ 3.8kgf.m, 18.1 ~ 27.5lb-ft)

**[C.P.F Equipped Vehicle]**



SFDM38043L

**[Non C.P.F Vehicle]**



SEDM37016L

15. Installation is in the reverse order of removal.

# Intake And Exhaust System

# EMC-93

## Front Exhaust Pipe


### Removal

1. Remove the front muffler(A).

### Tightening torque :


40 ~ 60N.m (4.0 ~ 6.0kgf.m, 30 ~ 43lb-ft)

### [C.P.F Equipped Vehicle]



SFDM38004L

### [Non Equipped Vehicle]




SEDM37008L

- 1) Remove the Catalyzed Particulate Filter (CPF) (A) after disconnecting the differential pressure hoses (B) and exhaust gas temperature sensor (C). (Only C.P.F)

### Tightening torque :

40 ~ 60N.m (4.0 ~ 6.0kgf.m, 30 ~ 43lb-ft)




SFDM38044L

2. Remove the catalytic converter(A).

### Tightening torque :

40 ~ 60N.m (4.0 ~ 6.0kgf.m, 30 ~ 43lb-ft)



SEDM37017L


## EMC-94

## Engine Mechanical System

3. Remove the main muffler(A).

**Tightening torque :**

40 ~ 60N.m (4.0 ~ 6.0kgf.m, 30 ~ 43lb-ft)



SEDM37018L

4. Installation is in the reverse order of removal.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

