






51. FRONT FOG LAMP

a. CONNECTOR INFORMATION

CONNECTOR NUMBER	WIRING HARNESS	GROUND POSITION
G101	Engine Room	Behind Left Head Lamp
G103	Engine Room	Behind Right Head Lamp
G201	Main	Above Driver Seat Leg Room


b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION





C. POSITION OF CONNECTORS AND GROUNDS

• W/H ENGINE ROOM

FOG LAMP




FOG LAMP SW



• W/H MAIN : FRONT

• W/H INSTRUMENT PANEL




52. FRONT & REAR FOG LAMP

a. CONNECTOR INFORMATION

CONNECTOR NUMBER	WIRING HARNESS	GROUND POSITION
G101	Engine Room	Behind Left Head Lamp
G103	Engine Room	Behind Right Head Lamp
G201	Main	Above Driver Seat Leg Room
G401	Trunk	Left Side Panel of Trunk
G402	Trunk	Right Side Panel of Trunk


b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION



C. POSITION OF CONNECTORS AND GROUNDS

• W/H ENGINE ROOM


FRT FOG LAMP




FRT & REAR FOG LAMP SW




REAR FOG LAMP



• W/H MAIN : FRONT



C204



G201



C208



FRONT FOG LAMP (LH)



G101




FRONT FOG LAMP (LH)

• W/H TRUNK


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

• W/H INSTRUMENT PANEL




G402


REAR FOG LAMP (RH)
(REAR COMBI LAMP)



C402



G401



REAR FOG LAMP (LH)
(REAR COMBI LAMP)

FRONT & REAR FOG LAMP SW

C204

C208

