




Harness connector	Name	Pages
IP09	To roof harness connector	80
IP20	Clock spring 2 (driver airbag) harness connector	80
IP35	Airbag module 1	80
IP46	Passenger side airbag harness connector	80
IP64	To body harness (right) harness connector	89
RF01	To instrument harness connector	93/94
RF02	Harness connector of driver side air curtain	93/94
RF03	Harness connector of passenger side air curtain	93/94
SO08	Harness connector of airbag module 2	97/106
SO16	Harness connector of passenger seat belt pretensioner	97/106
SO17	Passenger side airbag harness connector	97/106
SO20	Passenger side seat belt switch harness connector	97/106
SO23	Harness connector of driver side airbag	97/106
SO25	Driver seat belt pretensioner harness connector	97/106
SO77	To instrument harness connector	99

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

