


SQRD4G15B Starting System

Circuit Diagram (Page 1 of 2)

MT



02 09

EA13T090180

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-067	08-5 (MT) 08-7 (AT)	E-063	08-5 (MT) 08-7 (AT)	E-066	08-5 (MT) 08-7 (AT)
P-002	08-9	E-042	08-5 (MT) 08-7 (AT)	E-041	08-5 (MT) 08-7 (AT)
I-025	08-10	E-028	08-5 (MT) 08-7 (AT)	I-032	08-10

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
SB07	06-2	Engine Compartment Fuse and Relay Box
MF05	06-2	Engine Compartment Fuse and Relay Box
RF22	06-10	IP Fuse and Relay Box
RF21	06-10	IP Fuse and Relay Box
Starter Relay	06-2	Engine Compartment Fuse and Relay Box

Location of Junction Connector


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-035, E-029	08-10, 08-5 (MT) 08-10, 08-7 (AT)				

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-067	12-6	E-063	12-5	E-066	12-5
P-002	12-16	E-042	12-4	E-041	12-4
I-025	12-8	E-028	12-3	I-032	12-9
I-035, E-029	12-9				

Circuit Diagram (Page 2 of 2)

4AT



02 09

www.digitalkhodro.com

EA13T090190

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-067	08-5 (MT) 08-7 (AT)	E-063	08-5 (MT) 08-7 (AT)	E-066	08-5 (MT) 08-7 (AT)
P-002	08-9	E-042	08-5 (MT) 08-7 (AT)	E-041	08-5 (MT) 08-7 (AT)
E-073	08-5 (MT) 08-7 (AT)	I-025	08-10	E-028	08-5 (MT) 08-7 (AT)
I-032	08-10				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
SB07	06-2	Engine Compartment Fuse and Relay Box
MF05	06-2	Engine Compartment Fuse and Relay Box
RF22	06-10	IP Fuse and Relay Box
RF21	06-10	IP Fuse and Relay Box
Starter Relay	06-2	Engine Compartment Fuse and Relay Box

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-035, E-029	08-10, 08-5 (MT) 08-10, 08-7 (AT)				

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-067	12-6	E-063	12-5	E-066	12-5
P-002	12-16	E-042	12-4	E-041	12-4
E-073	12-6	I-025	12-8	E-028	12-3
I-032	12-9	I-035, E-029	12-9		