



Reversing System-3		E-3
Component position index		
Code of component	Name of component	
M23	Reversing radar buzzer	
F14	Left reversing lamp	
F15	Right reversing lamp	
F12	Reversing radar ECU	
R01	Reversing radar left probe	
R02	Reversing radar intermediate probe	
R04	Reversing radar right probe	
Connector		
FR02	Reversing radar harness interface	
CE01	Front compartment harness interface	
MF01	Floor harness interface A	
Ground point		
G04	اولین سامانه دیجیتال تعمیرکاران خودرو در ایران	
G05		

