


4.16A Roof Light/Sunroof System



Refer to chapter 4.3A Wiring Diagram 1 of Engine Management System