


## Electrical Mirrors

item code	description	information
6406	null	rear view mirror control
6411	null	left-hand exterior rear view mirror
6416	null	right-hand exterior mirror
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
CA00	null	ignition switch
EC02A	null	splice of an "ignition +" protected by fuse no. 02
EM37A	null	crimp earth (earth point number 37A)
EM37C	null	crimp earth (earth point number 37C)
MC13	null	body earth point number 13
MC37A	null	body earth point number 37A
MC37C	null	body earth point number 37
MM01	null	engine earth point number 01



# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در کشور



### Electrical Mirrors



دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)



اولین سامانه دیجیتال تعمیرکاران خودرو در کشور

