


13. A/V (AUDIO/VIDEO 600L)


1) NAVIGATION, TV TUNER, REAR ARMREST REMOTE CONTROL, DSP UNIT



a. CONNECTOR INFORMATION


CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G304	Floor	Above Co-Driver Seat "C" Pillar
G402	Trunk	Right Side Panel of Trunk

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS

TV TUNER
NAVIGATION UNIT



DSP UNIT




REAR ARMREST
COVER SW




REAR ARMREST
REMOCON



• W/H FLOOR : CO-DRIVER SEAT



G304



C406

C307

C215


• W/H FLOOR : TRUNK

• W/H RR SEAT


DSP UNIT

C406

C401, C402



G402




NAVIGATION
UNIT

TV TUNER


REAR ARMREST
COVER SW

C307

REAR ARMREST
REMOCON




2) MULTIVISION DISPLAY UNIT, AUTO AMP, AQS



a. CONNECTOR INFORMATION

CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G101	Engine Room	Behind Left Head Lamp
G201	Main	Above Driver Seat Leg Room


b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS

- W/H ENGINE ROOM


DIAGNOSIS CONNECTOR





CONTROL PANEL



STICS



- W/H MAIN : FRONT



- W/H INSTRUMENT PANEL




- W/H FLOOR : CO-DRIVER SEAT

- W/H TRUNK


اولین سامانه دیجیتال تعمیر کاران خودرو (مسئولیت محدود)

شرکت دیجیتال خودرو سامانه

I/P SPEAKER




3) AUDIO HEAD UNIT, AUTO ANTENNA, GLASS ANTENNA AMP.



a. CONNECTOR INFORMATION

CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G201	Main	Above Driver Seat Leg Room
G401	Trunk	Left Side Panel of Trunk

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS


STEERING REMOCON




AUTO AMP




GLASS ANTENNA (LH)




TV TUNER




AUTO ANTENNA




DSP UNIT




• W/H MAIN : FRONT




• W/H FLOOR : CO-DRIVER SEAT



• W/H MAIN : LEFT FLOOR




• W/H FLOOR : TRUNK



a. CONNECTOR INFORMATION


CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G402	Trunk	Right Side Panel of Trunk

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS

IP SPEAKER



POWER AMP




CD CHANGER



DSP UNIT



DOOR SPEAKER



• W/H MAIN : FRONT

C208




I/P
SPEAKER
(LH)

C204


I/P
SPEAKER
(RH)

C204



C208


C204



C351



C361



C214

• W/H FLOOR : TRUNK

• W/H DRIVER SEAT DOOR


• W/H CO - DRIVER SEAT DOOR

REAR
SPEAKER
(LH)

DSP UNIT




C401



C405




G402




REAR
SPEAKER(RH)

POWER AMP

TWEETER
SPEAKER



C361



FRONT DOOR
SPEAKER

C361





14. AUDIO (300,400X,400,500X)

a. CONNECTOR INFORMATION


CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G201	Main	Above Driver Seat Leg Room
G401	Trunk	Left Side Panel of Trunk

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS


IP SPEAKER




AUTO ANTENNA




DOOR SPEAKER




• W/H MAIN : FRONT




• W/H INSTRUMENT PANEL




• W/H FLOOR : CO-DRIVER SEAT




• W/H FLOOR : TRUNK



• W/H DRIVER SEAT DOOR



• W/H CO - DRIVER SEAT DOOR





a. CONNECTOR INFORMATION

CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G201	Main	Above Driver Seat
G401	Trunk	Left Side Panel


CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G201	Main	Above Driver Seat Leg Room
G401	Trunk	Left Side Panel of Trunk

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS


POWER AMP



AUTO ANTENNA




• W/H MAIN : FRONT



• W/H FLOOR : TRUNK


• W/H FLOOR : CO-DRIVER SEAT




2) POWER AMP, SPEAKER

a. CONNECTOR INFORMATION

CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G402	Trunk	Right Side Panel of Trunk




b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS

• W/H MAIN : FRONT



IP SPEAKER



AUTO ANTENNA



DOOR SPEAKER




• W/H INSTRUMENT PANEL

I/P
SPEAKER
(LH)



I/P
SPEAKER
(RH)



• W/H FLOOR : TRUNK


• W/H DRIVER SEAT DOOR

• W/H CO - DRIVER SEAT DOOR



• W/H RR/LH DOOR

• W/H RR/RH DOOR

اولین سامانه دیجیتال تعمیرکاران خودرو (مسئولیت محدود)



TWEETER
SPEAKER




16. DIN CABLE CONNECTION (NAVIGATION UNIT, TV TUNER, MULTIVISION DISPLAY UNIT, JUNCTION BLOCK, AUDIO HEAD UNIT, REAR MONITOR, DSP UNIT, CD CHANGER, POWER AMP)

a. CONNECTOR INFORMATION


CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G304	Floor	Above Co-Driver Seat "C" Pillar

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS


•TV TUNER
•NAVIGATION UNIT



DSP UNIT




POWER AMP



CD CHANGER




• W/H MAIN : FRONT



• W/H FLOOR : CO-DRIVER SEAT

• W/H FLOOR : TRUNK



G304

