



Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)


- * 2 : 2AR-FE
- * 3 : 2AD-FHV, 2AD-FTV
- * 9 : 3ZR-FE
- *11 : 2WW
- *12 : Except 2WW
- *13 : 3ZR-FAE



Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)




Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)




Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)


- * 5 : w/ Stop & Start System
- * 6 : w/o Stop & Start System
- *21 : Radio Receiver Type
- *22 : Radio & Display Receiver Type
- *23 : Navigation Receiver Type
- *34 : w/ Audio System (Separate Type Amplifier)
- *35 : w/ Audio System (Built-in Type Amplifier)




Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)




90980-12372




90980-11250




90980-12362




90980-12A23




90980-11250




90980-12370



90980-12557




90980-10825




90980-10997


اولین امانه دیجیتال تعمیرکاران خودرو در ایران



90980-12555




82824-12510



90980-12372


Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)

G98
Gray




90980-12372

G99
White




90980-12372

G107
Gray



90980-12372

G108
Gray




90980-12372




Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)


G109
White




90980-12372




G114
Gray



90980-12737




G137
White




90980-10997

G139
White




90980-12555

G141
White




90980-10997

G143
White



90980-12555


G166
Black



90980-12924


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

G170
Black




90980-12912

G172
White





90980-12A58





Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)

G174
White





90980-12A58

G189
Gray





90980-12372

G194
White



90980-12372



G195
Blue



90980-12372

Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)


N36
White



90980-12A58

S1


Black



90980-12382

S2


Black



90980-12382

S3


Black



90980-12382

S4


Black



90980-12382

Z1


Black



90980-12382

Z2


Black



90980-12382

Z3


Black



90980-12382

Z4


Black



90980-12382

z1


Black



90980-12559


3B

White




90980-12A15


Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)



90980-12887




90980-12890




90980-12771


90980-12770




90980-12412



90980-12411



90980-12326



90980-12716

Parking Assist (TOYOTA Parking Assist-Sensor) (8 Sensor Type) (From Oct. 2015 Production)

