

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Main					IC20A 13W WI	Dashboard					
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
Reverse Gear Switch	EBB	54W BU	3	220	1A	220	2A	13W BR	IC23B	Reverse Gear Lamp	
Exterior Air Thermistor Ground (Model B)	EBB	54W BU	21	E832	2A	E832	7A	13W BK	IC26A	Evaporator Sensor Ground (Model B)	
							2	2W BK	8033	Sun Sensor Ground (Model B)	
							6	6W BK	8031	Coolant Thermistor Ground (Model B)	
							4B	13W WI	IC20A	Engine Coolant Thermistor (For HVAC) Ground (Model B)	
High Temperature LED	EBB	54W BU	11	405	3A	400	3	16W BK	0004	High Temperature LED	
ECU (+) Switch Step 2 , Start	EBB	54W BU	10	CC1	5A	CC1	2	F8	IPFRB	Switch (+) Step 2	
							15	16W BK	0004	Instrument Panel Power	
							5B	9W BR	IC20K	ABS Unit Power	
							1	16W BK	C001	OBD Connector	
							4	8W BK	8208	Immobilizer Unit Power	
							11	40W WI	CEC	CEC Power	
ECU CAN L	EBB	54W BU	44	9001	6A	9001	5	8W BK	8208	Immobilizer Unit CAN L	
ECU CAN H	EBB	54W BU	46	9002	7A	9002	6	8W BK	8208	Immobilizer Unit CAN H	
Temperature Output	EBB	54W BU	43	401	1B	401	9	20W BK	0004	Temperature Input	
Engine Oil Pressure LED	EBB	54W BU	7	410	2B	410	15	20W BK	0004	Engine Oil Pressure LED	
Alternator LED	EBB	54W BU	35	1070	3B	1070	11	20W BK	0004	Alternator LED	
Engine Coolant Thermistor (For HVAC) Ground	EBB	54W BU	48	E404	4B	E404	7A	13W BK	IC26A	Evaporator Sensor Ground (Model B)	
							2	2W BK	8033	Sun Sensor Ground (Model B)	
							6	6W BK	8031	Coolant Thermistor Ground (Model B)	
							2A	13W WI	IC20A	Exterior Air Thermistor Ground (Model B)	
Tacho Output	EBB	54W BU	49	426	5B	426	2	20W BK	0004	Tacho Input	
Revers Gear Switch	EBB	54W BU	40	A127	6B	A12	2	F11	IPFRB	Reverse Gear Switch Power	
Starter	EBB	54W BU	30	100	7B	100	2	2W BK	SW00	Start Switch	
Main					IC20B 9W BK	Dashboard					
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
Not Used					1A		BBB	2	5W	8616	Motion & Shock Sensor Relay Power (Model A)
							B170	2	F31	IPFRB	F31 (Model B) - option
Not Used					2A		S11	18	40W WI	CEC	Motion & Shock Sensor Signal - option
								4A	9W BK	IC20B	Motion & Shock Sensor Signal (Model A)
Not Used					4A		M11	4A	9W BK	IC20B	Motion & Shock Sensor Signal (Model B) - option
								2A	9W BK	IC02B	Motion & Shock Sensor Signal (Model B) - option
Not Used					4A		M11	18	40W WI	CEC	Motion & Shock Sensor Signal (Model A)
								2A	9W BK	IC20B	Motion & Shock Sensor Signal (Model A)
Start Switch (+)	EBB	54W BU	16	KK2	5A	KK2 (K02)	25	40W GY	8025	HVAC Panel Power (IGN) (Model B)	
							2	F2	IPFRB	F2	
Not Used					1B		4	5W	8048	Blower Relay Power (Model A)	
							1	5W	8048	Blower Relay Power (Model B)	
							5B	9W BR	8110	Screen Heater Switch Power (Model A)	
							2A	13W BK	CEC	CEC Ground (Model A)	
							3	5W	8048	Blower Relay Ground (Model A)	
							5A	13W BK	IC21	Roof Lamp & Map Reading Lamp Ground (Model A)	
							5	5W	6236B	Central Lock Relay Ground (Model A)	
							5	5W	6236A	Central Lock Relay Ground (Model A)	
										E020A	Ground (Model A)
							4	16W BK	C001	OBD Connector Ground (Model A)	
							5	16W BK	C001	OBD Connector Ground (Model A)	
							3B	9W BR	1810B	Petrol/CNG Switch Ground (Model A)	
							5B	9W BR	1810B	Petrol/CNG Switch Ground (Model A)	
							2	2W BR	3115	Glove Box Lamp Ground (Model A)	
							2	7W GY	7225	Digital Clock Ground (Model A)	
3B	9W GY	2300	Hazard Switch Ground (Model A)								
4B	9W GY	2300	Hazard Switch Ground (Model A)								
1A	9W GY	2300	Hazard Switch Ground (Model A)								
3B	9W BR	8110	Screen Heater Switch Ground (Model A)								
3	20W BK	0004	Instrument Panel (Model A)								
3B	9W BK	6215	Boot Lid Switch (Model A)								
5A	11W WI	IC26A	HVAC & Evaporator Sensor Ground (Model A)								
ME11	19	40W WI	CEC	Motion & Shock Sensor Ground (Model B) - option							
Petrol/CNG Select (Model A)	EBB	54W BU	54	1810	2B	1810	4B	9W BR	1810B	Petrol/CNG Switch (Model A)	
Vehicle Speed Sensor	EBB	54W BU	53	1624	3B	1624	1	20W BK	0004	Speed Indicator	
Vehicle Speed Sensor (Model B)	7020	38W BK	28	1620		1624A	7A	13W BK	CEC	Vehicle Speed Sensor	
Not Used					4B	Not Used					
AC Request	EBB	54W BU	22	8053	5B		8053	4B	11W WI	IC26A	AC Request (Model A)
							8053	2A	13W BK	IC26A	AC Request (Model B)

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Main					IC20C 2W BR	Dashboard					
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
F4 Output	EBB	54W BU	29	BB19	1	BB3	1	2W BK	SW00	Switch Power	
F5 Output	EBB	54W BU	27	BB5	2	BB5	1	2W BR	SW00	Switch Power	
Main					IC20D 2W BK	Dashboard					
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
F7 Output	EBB	54W BU	26					BUSBAR	BB10	Main Power	
ECU (+) Battery	EBB	54W BU	34	BB1	1	BB1		3	5W	ECUR (Relay2)	Eco Mode Relay Power (Model B)
								1	5W	ECUR (Relay1)	Eco Mode Relay Power (Model A)
								1A	9W BK	0002	Lightening Switch Power
								2B	9W BK	0002	Lightening Switch Power
								1B	5W WI	0002	Lightening Switch Power
								2B	5W WI	0002	Lightening Switch Power
F6 Output	EBB	54W BU	28	BB2	2	BB2		BUSBAR	BB10	Main Power	
Main					IC20E 13W GY اگر اندیس دسته سیم داشته بود A ر یا OR بود	Dashboard					
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
Front Side Lamp	EBB	54W BU	14	V090	1A	V090	2	F6	IPFRB	F6 Output (Side Lamp Command)	
Left Indicator Output	EBB	54W BU	6	2331	2A	2331	6B	13W BK	CEC	Left Indicator Output	
LH Side Repeater Flasher	2340	2W BR	1	2332			A1	13W BK	IC23A		Rear Left Indicator
Fuel Guage Input (Model A)	EBB	54W BU	36	430B	3A		4B	13W GY	IC22B	Left Indicator On Mirror	
Dipped Lamp	EBB	54W BU	18	PC3	5A		PC11	2	F21	IPFRB	F21
							PC5	14	16W BK	0004	Dipped Lamp LED
Main Lamp LED	EBB	54W BU	19	PR1	6A		PR11	2	F20	IPFRB	F20
Right Indicator Output	EBB	54W BU	15	2341	7A	2341	PR5	3	8BK	0004	Main Lamp LED
							7B	13W BK	CEC	Right Indicator Output	
RH Side Repeater Flasher	2345	2W BR	1	2342			1A	13W GY	IC23C	Rear Indicator Output	
Horn Button Output	EBB	54W BU	9	250	1B	252	2	8W WI	IC20	Horn	
Siren Signal	EBB	54W BU	2	8604	2B	8604	4B	13W BK	CEC	Siren Signal - option	
Siren Power	8605	4W BR	1	B172	3B	B172	2	F32	IPFRB	F32	
Front Fog Lamp Output	EBB	54W BU	12	PB5	4B		PB11	2	F19	IPFRB	F19
							PB4	12	16W BK	0004	Front Fog Lamp LED
Not Used					5B	Not Used					
Fuel Guage GND From ECU (Model A)	EBB	54W BU	42	E03	6B						
Fuel Pump Power	EBB	54W BU	37	121	7B	121	2B	13W GY	IC23C	Fuel Pump Power	
Main					IC20E 13W GY اگر اندیس دسته سیم داشته بود B	Dashboard					
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
Front Side Lamp	EBB	54W BU	14	V090	1A	V090	2	F6	IPFRB	F6 Output (Side Lamp Command)	
Left Indicator Output	EBB	54W BU	6	2331	2A	2331	6B	13W BK	CEC	Left Indicator Output	
LH Side Repeater Flasher	2340	2W BR	1	2332			A1	13W BK	IC23A		Rear Left Indicator
Fuel Guage Input (Model A)	EBB	54W BU	36	430B	3A		4B	13W GY	IC22B	Left Indicator On Mirror	
Dipped Lamp	EBB	54W BU	18	PC3	5A		PC11	2	F21	IPFRB	F21
							PC5	14	16W BK	0004	Dipped Lamp LED
Main Lamp LED	EBB	54W BU	19	PR1	6A		PR11	2	F20	IPFRB	F20
Right Indicator Output	EBB	54W BU	15	2341	7A	2341	PR5	3	8BK	0004	Main Lamp LED
							7B	13W BK	CEC	Right Indicator Output	
RH Side Repeater Flasher	2345	2W BR	1	2342			1A	13W GY	IC23C	Rear Indicator Output	
Horn Button Output	EBB	54W BU	9	250	1B	8604	4B	13W BK	CEC	Horn	
Siren Signal	EBB	54W BU	2	8604	2B						
Siren Power	8605	4W BR	1	B172	3B	B172	2	F32	IPFRB	F32	
Front Fog Lamp Output	EBB	54W BU	12	PB5	4B		PB11	2	F19	IPFRB	F19
							PB4	12	16W BK	0004	Front Fog Lamp LED
Not Used					5B	Not Used					
Fuel Guage GND From ECU (Model A)	EBB	54W BU	42	E03	6B						
Fuel Pump Power	EBB	54W BU	37	121	7B	121	2B	13W GY	IC23C	Fuel Pump Power	

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Main					IC20F 9W GY	Dashboard				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
Wiper Motor Power	5015	5W WI	3	A240	1A	A240	2	F10	IPRFB	F10
							12	40W WI	CEC	CEC Power (step 1)
							5A	9W BK	0002	Lightening Switch Power (Step1)
							7	18W BK	8410	Radio Power (Model B)
							14	18W BK	8410	Radio Power (Model B)
							3	7W GY	7225	Digital Clock Power (Model A)
							4B	9W BK	6215	Boot Lid Switch Power (Model A)
Wiper Motor Low Speed	5015	5W WI	4	500	2A	500	5B	11W GY	0005	Wiper Motor Low Speed Command
Voltage + Output From Zero Position	5015	5W WI	5	503	4A	503	3A	13W BK	CEC	Wiper Zero Position
							503A	5	5W	5005
Left Brake Pad Wear	IC03B	2W WI	1	445	5A	444	20	20W BK	0004	Brake Pad Wear LED
Right Brake Pad Wear	IC03A	2W WI	1	446						Brake Pad Wear LED
Check Engine LED	EBB	54W BU	45	480	1B	480	16	20W BK	0004	Check Engine LED
Wiper Motor High Speed	5015	5W WI	1	501	2B	501	6B	11W GY	0005	Wiper Motor High Speed Command
Wash Pump (+)	5100	2W BK	1	510	3B	510	2B	11W GY	0005	Wash Pump Command
Brake Fluid Level Output	4410	2W BK	1	4410	4B	440	3B	13W BR	IC23B	Brake Fluid Level/Hand Brake LED
										7443
Not Used					5B	Not Used				
Main					IC20G 13W BR	Dashboard				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
Fuel Tank Level (Model A)	EBB	54W BU	51	430	1A	430	3B	13W GY	IC23C	Fuel Tank Level (Model A)
Not Used (Model A)	EBB	54W BU	48	1255	2A	1255	4	16W BK	0004	Not Used (Model A)
Not Used (Model A)	EBB	54W BU	41	1245A	3A	1245A	5	16W BK	0004	Not Used (Model A)
Not Used (Model A)	EBB	54W BU	33	1215	5A	1215	1	8W BK	0004	Not Used (Model A)
Not Used					6A	Not Used				
K Line/W Line	EBB	54W BU	50	1411	7A	141	7	16W BK	C001	K Line/W Line
AC Request	8007	4W BR	1	8054	1B	8054	3B	11W WI	IC26A	AC Request (Model A)
							2A	13W BK	IC26A	AC Request (Model B)
Pressostat Switch Power	8007	4W BR	4	C020	2B	C020	2	F1	IPRFB	F1
Ambient Sensor (Model B)	EBB	54W BU	17	832	3B	832	12	40W GY	8025	Ambient Sensor (Model B)
Bonet Switch	8611	2W BK	1	8601	4B	8601	17	40W WI	CEC	Bonet Switch
Ambient Sensor (Model B)	EBB	54W BU	41	404	5B	404	11	40W GY	8025	Ambient Sensor (Model B)
Not Used (Model A)	EBB	54W BU	39	183	6B	183	1B	13W BK	IC23A	Not Used (Model A)
Not Used (Model A)	EBB	54W BU	47	184	7B	184	3B	13W BK	IC23A	Not Used (Model A)
Main					IC20K 9W BR	Dashboard				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
ABS Signal	7020	38W BK	16	7440	1A	7440	6A	13W BK	CEC	ABS Signal
Stop Lamp Switch Input	7020	38W BK	30	7215	2A	7215	2	2W WI	2100	Stop Lamp Switch
Diagnosis	7020	38W BK	17	779	4A	779	12	16W BK	C001	OBD Connector For ABS
ABS Signal	7020	38W BK	4	7449	5A	7449	5A	13W BK	CEC	ABS Signal
Rear Left ABS Sensor	7020	38W BK	20	702	1B	702	6A	13W BK	IC23A	Rear Left ABS Sensor
Rear Left ABS Sensor	7020	38W BK	33	7021	2B	7021	6B	13W BK	IC23A	Rear Left ABS Sensor
Rear Right ABS Sensor	7020	38W BK	31	703	3B	703	5B	13W BR	IC23B	Rear Right ABS Sensor
Rear Right ABS Sensor	7020	38W BK	19	7031	4B	7031	6B	13W BR	IC23B	Rear Right ABS Sensor
ABS Unit Power	7020	38W BK	32	C307	5B	C308	2	F8	IPRFB	Switch (+) Step 2
							15	16W BK	0004	Instrument Panel Power
							5A	13W WI	IC20A	ECU (+) Switch Step 2 , Start
							1	16W BK	C001	OBD Connector
							4	8W BK	8208	Immobilizer Unit Power
							11	40W WI	CEC	CEC Power
							2A	11W WI	IC26A	Ventilation Relays & Motors Power (Model A)
							1B	11W WI	IC26A	Ventilation Relays & Motors Power (Model A)
3	6W BK	8031	Coolant Thermistor Power (Model B)							

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Front Left Door					IC22A 13W BK	Dashboard				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
Front Left Speaker	8420	2W YL	2	841	1A	841	5	8W WI	8410	Front Left Speaker
						8411	2	3W BK	8440	Left Twitter
Front Left Speaker	8420	2W YL	1	842	2A	8421	1	3W BK	8440	Left Twitter
						842	6	8W WI	8410	Front Left Speaker
FL Door Unlock	6240	2W BR	1	6201	3A	6201	2	5W	6236B	Central Lock Relay Output (Model A)
							5	5W	6236B	Central Lock Relay Output (Model B)
							7A	13W BR	IC23B	Doors Unlock
							3A	13W BK	IC24A	Doors Unlock
FL Door Lock	6240	2W BR	2	6211	5A	6211	1B	13W BR	IC23B	Doors Lock
							5A	13W BK	IC24A	Doors Lock
							2	5W	6236A	Central Lock Relay Output (Model A)
							5	5W	6236A	Central Lock Relay Output (Model B)
FLH Mirror Heater	6410	9W BK	4B	813	6A	813	1B	9W BR	8110	Rear Screen Heater Switch Light (Model A)
							6A	13W BK	IC24A	FRH Mirror Heater (Model A)
Not Used	6200	3W WI	2	6231	7A					Not Used
FLH Door Switch Output	6200	3W WI	1	6251	1B	6251	26	40W WI	CEC	FLH Door Lock Switch Input
FLH Door Lock Switch	4700	2W GY	2				2	8W BK	8208	Immobilizer Unit Ground (Model A)
Rear Window Winder Switch On Driver Side Ground	6100	9W GY	4A				8	16W BK	0004	Instrument Panel Ground (Model A)
LH Mirror Ground	6410	9W BK	5B				9	16W BK	0004	Instrument Panel Ground (Model A)
Window Control Unit	6030	9W RD	2A				16	16W BK	0004	Instrument Panel Ground (Model A)
FLH Door Switch Ground	6200	3W WI	3				5B	9W BK	6220	Master Lock Switch Ground (Model A)
LH Mirror Ground	6410	9W BK	4A				2B	13W BK	IC24A	FLH Door Ground (Model A)
FLH Window Switch	6000	9W BK	4A				6	50W GN	6570	Airbag Unit Ground (Model A)
FLH Window Switch	6000	9W BK	4A							Ground (Model A)
FR Window Down Command	6000	9W BK	4B	606	3B	606	B1	13W GY	IC25A	Isolator Switch Ground (Rear Window Winder Switch Lock) (Model A)
FR Window Up Command	6000	9W BK	5B	607	4B	607	3	3W WI	8100	Cigar Lighter Ground (Model A)
FLH Window Switch	6000	9W BK	3B	6002	5B	6005				Ground (Model B)
Window Control Unit	6030	9W RD	5A	6005	5B	6005				Ground (Model B)
FLH Window Switch Power	6030	9W RD	3B	A302	6B	A301	2	13W GY	IC22B	Window Winder Switch Power (Model B)
Mirror Switch Power	6405	8W BK	2A	A301						F11 Output
Driver Door Switch	4700	2W GY	1	8611	7B	8611	4B	13W BK	IC21	Driver Door Switch
Front Left Door					IC22B 13W GY	Dashboard				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
Right Mirror Switch	6405	8W BK	3B	6411	1A	6411	1A	13W GY	IC24B	Right Mirror
Right Mirror Switch	IC22B	13W GY	6B	641	2A	641	2A	13W GY	IC24B	Right Mirror
Right Mirror Switch	6405	8W BK	1B	6412	3A	6412	3A	13W GY	IC24B	Right Mirror
Rear Window Winder Switch On Driver Side	6100	9W GY	1A	614	5A	614	6B	13W BK	IC23A	RL Window Up
Rear Window Winder Switch On Driver Side	6100	9W GY	2B	615	6A	615	7B	13W BK	IC23A	RL Window Down
Rear Window Winder Switch On Driver Side	6100	9W GY	4B	612	7A	619	7B	13W GY	IC23C	RL Window Down
Right Mirror Switch Backlight	6405	8W BK	1A	V190	2B	V190	2	F5	IPRFB	F5 Output
							6	8W BK	8410	Radio Backlight
							6	40W WI	CEC	Side Lamp Button
							6A	11W WI	IC26A	HVAC Panel Backlight (Model A)
							1A	13W GY	IC25A	Isolator Switch Backlight (Rear Window Winder Switch Lock) (Model A)
							1B	9W GY	2300	Hazard Switch Backlight (Model A)
							2B	9W BK	6215	Boot Lid Switch Backlight (Model A)
							2B	9W BR	8110	Rear Screen Heater Switch Backlight (Model A)
							4	7W GY	7225	Digital Clock Backlight (Model A)
							2B	9W BK	6220	Master Lock Switch Backlight (Model A)
							2B	9W BR	1810B	CNG Switch Backlight (Model A)
							10	16W BK	0004	Side Lamp LED
							1	1W BK	3053	Cigar Lighter Lamp (Model B)
							35	40W GY	8025	HVAC Panel LED (Model B)
							6	18W BK	8410	Panel Switches Backlight (Model B)
							6	8W BK	8410	Radio Backlight (Model B)
Rear Window Winder Switch On Driver Side	6100	9W GY	5B	613	3B	618	6B	13W GY	IC23C	RL Window Up
Left Indicator On Mirror	6410	9W BK	5A	2335	4B	2335	6B	13W BK	CEC	Left Indicator Output
							A1	13W BK	IC23A	Rear Left Indicator
							2A	13W GY	IC20E	Front Left Indicator
							6	20W BK	0004	Left Indicator LED
Rear Window Winder Switch On Driver Side Power	6100	9W GY	3B	6003	5B	6003A	2	5W	6125	Rear Window Winder Relay Output (Model A)
							5B	13W BK	IC24A	Right Hand Window Winder Switch Power (Model B)
							5B	13W BK	IC22A	FLH Window Switch & Window Control Unit (Model B)
Right Mirror Switch	6405	8W BK	3A	640	6B	640	7B	13W GY	IC22B	Left Hand Mirror
Right Mirror Switch	IC22B	13W GY	2A	641						Front Window Winder Relay Output (Model B)
Left Hand Mirror	6410	9W BK	2B	6400	7B	640	6B	13W GY	IC22B	Right Mirror Switch

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Console (Only For 1Airbag Vehicle)					IC25A 13W GY	Dashboard (Model A)					
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
Isolator Switch Backlight (Rear Window Winder Switch Lock)	6120	9W RD	1A	V19W	1A	V19W	2	F5	IPRFB	F5 Output	
							6	8W BK	8410	Radio Backlight	
							6	40W WI	CEC	Side Lamp Button	
							6A	11W WI	IC26A	HVAC Panel Backlight (Model A)	
							B2	13W GY	IC22B	Right Mirror Switch Backlight (Model A)	
							1B	9W GY	2300	Hazard Switch Backlight (Model A)	
							2B	9W BK	6215	Boot Lid Switch Backlight (Model A)	
							2B	9W BR	8110	Rear Screen Heater Switch Backlight (Model A)	
							4	7W GY	7225	Digital Clock Backlight (Model A)	
							2B	9W BK	6220	Master Lock Switch Backlight (Model A)	
2B	9W BR	1810B	CNG Switch Backlight (Model A)								
						10	16W BK	0004	Side Lamp LED		
Not Used					2A				Not Used		
Not Used					3A				Not Used		
Not Used					5A				Not Used		
Not Used					6A				Not Used		
Not Used					7A				Not Used		
Isolator Switch Ground (Rear Window Winder Switch Lock)	6120	9W RD	1B	MC5	B1	MC5	2	8W BK	8208	Immobilizer Unit Ground (Model A)	
							8	16W BK	0004	Instrument Panel Ground (Model A)	
							9	16W BK	0004	Instrument Panel Ground (Model A)	
							16	16W BK	0004	Instrument Panel Ground (Model A)	
							5B	9W BK	6220	Master Lock Switch Ground (Model A)	
							2B	13W BK	IC22A	FLH Door Ground (Model A)	
							6	50W GN	6570	Airbag Unit Ground (Model A)	
									E020	Ground (Model A)	
							2B	13W BK	IC24A	FRH Door Lock & Mirrors Ground (Model A)	
							3	3W WI	8100	Cigar Lighter Ground (Model A)	
Isolator Switch Output	6120	9W RD	2B	6110	B2	6110	6A	13W BK	IC23A	Isolator Switch Output	
Not Used					B3				Not Used		
Not Used					B4				Not Used		
Isolator Switch (Rear Window Winder Switch Lock)	6120	9W RD	5B	610	B5	610	2	5W	6125	Rear Window Winder Relay Output	
Not Used					B6				Not Used		
Not Used					B7				Not Used		
Rear (Rear Lamp)					IC23A 13W BK	Dashboard					
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
Rear Left Indicator	2630	6W BR	2	2333	A1	2333	6B	13W BK	CEC	Left Indicator Output	
							2A	13W GY	IC20E	Left Indicator	
							4B	13W GY	IC22B	Left Indicator On Mirror	
							6	20W BK	0004	Left Indicator LED	
Rear Left Side Lamp	2630	6W BR	6	V09	A2	V09	V04	2A	13W GY	IC23C	Rear Side Lamp (Model B)
							2	F6	IPFRB	F6 Output (Side Lamp Command)	
Rear Left Speaker	8430	2W WI	1	846	A3	846	8	8W WI	8410	Rear Left Speaker	
Rear Left Speaker	8430	2W WI	2	845	A5	845	7	8W WI	8410	Rear Left Speaker	
Rear Left Window Winder Switch Power	IC32	9W BR	1A	6110	A6	6110	B2	13W GY	IC25A	Isolator Switch Output (Model A)	
Rear Right Window Winder Switch Power	IC33	9W BR	1A				6110	3	5W	6125	Rear Window Winder Relay Output (Model B)
Rear Screen Heater	8120A	1W BK	1	811	A7	811	2	5W	8116	Screen Heater Relay Output (Model A)	
							5	5W	8116	Screen Heater Relay Output (Model B)	
Not Used					B1	183	6B	13W BR	IC20G	Not Used (Model A)	
RL Door Switch Output	IC32	9W BR	5B	8613	B2	8613	22	40W WI	CEC	FR-RL-RR Door Switch Input	
RR Door Switch Output	IC33	9W BR	5B	8614			7B	13W BK	IC24A	FR Door Switch Output	
Not Used					B3	184	7B	13W BR	IC20G	Not Used (Model A)	
Rear Left ABS Sensor	7010	2W BK	1	702	B4	702	1B	9W BR	IC20K	Rear Left ABS Sensor	
Rear Left ABS Sensor	7010	2W BK	2	7021	B5	7021	2B	9W BR	IC20K	Rear Left ABS Sensor	
RL Window Up	IC32	9W BR	1B	614	B6	614	5A	13W GY	IC22B	Rear Window Winder Switch On Driver Side	
RL Window Down	IC32	9W BR	2B	615	B7	615	6A	13W GY	IC22B	Rear Window Winder Switch On Driver Side	

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Front Right Door					IC24A 13W BK	Dashboard				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
Front Right Speaker	8425	2W YL	2	843	1A	843	3	8W WI	8410	Front Right Speaker
Front Right Speaker	8425	2W YL	1	844	2A	8431	2	3W BK	8445	Right Twitter
FR Door Unlock	6245	2W BR	1	6202	3A	8441	1	3W BK	8445	Right Twitter
						844	4	8W WI	8410	Front Right Speaker
						2	5W	6236B	Central Lock Relay Output (Model A)	
						5	5W	6236B	Central Lock Relay Output (Model B)	
						7A	13W BR	IC23B	Doors Unlock	
FR Door Lock	6245	2W BR	2	6212	5A	6202	3A	13W BK	IC22A	FL Door Unlock
						6212	1B	13W BR	IC23B	Doors Lock
						5A	13W BK	IC22A	FL Door Lock	
FRH Mirror Heater	6415	9W BK	4B	814	6A	2	5W	6236A	Central Lock Relay Output (Model A)	
						5	5W	6236A	Central Lock Relay Output (Model B)	
FRH Mirror Heater	6415	9W BK	4B	814	6A	814	2	F23	IPRFB	F23 Output
Right Door Lock Switch	6205	3W WI	2	6232	7A	Not Used				
FRH Door Switch Output	6205	3W WI	1	6252	1B	6252	25	40W WI	CEC	FRH Door Switch Input
FRH Door Lock Switch	4701	2W GY	2	MPC	2B	M814	2	8W BK	1466	Instrument Panel Ground (Model A)
							8	16W BK	0004	
							9	16W BK	0004	
							16	16W BK	0004	
RH Mirror Ground	6415	9W BK	4A	MPC	2B	M814	7	8W WI	IC20	Airbag Unit Ground (Model A)
							6	50W GN	6570	
RH Mirror Ground	6415	9W BK	5B	MPC	2B	M814	EQ20		Ground (Model A)	
							2	8W WI	IC20	
FRH Door Switch Ground	6205	3W WI	3	MPC	2B	M814	2	3W WI	8100	Cigar Lighter Ground (Model A)
							10	18W BK	8410	Panel Switches Ground (Model B)
FR Window Down Switch	6005	5W WI	1B	606	3B	606	18	18W BK	8410	Panel Switches Ground (Model B)
							2	6W WI	8410	Radio Ground (Model B)
FR Window Up Switch	6005	5W WI	2A	607	4B	607	4B	13W BK	IC22A	FR Window Up Command
Right Hand Window Winder Switch Power	6005	5W WI	1A	6003	5B	6003	2	5W	6020	Front Window Winder Relay Output (Model A)
							5	5W	6020	Front Window Winder Relay Output (Model B)
Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	5B	13W BK	IC22A	FLH Window Switch & Window Control Unit
							5B	13W GY	IC22B	Window Winder Switch Power (Model B)
FR Door Switch Output	4701	2W GY	1	8612	7B	8612	22	40W WI	CEC	FR-RL-RR Door Switch Input
Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	B2	13W BK	IC23A	RL-RR Door Switch Output
Front Right Door					IC24B 13W GY	Dashboard				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
FRH Mirror UP/DOWN	6415	9W BK	1B	6411	1A	6411	1A	13W GY	IC22B	FLH Mirror UP/DOWN
Right Mirror	6415	9W BK	2B	641	2A	641	2A	13W GY	IC22B	Right Mirror Switch
Right Mirror	6415	9W BK	3B	6412	3A	6412	3A	13W GY	IC22B	Right Mirror Switch
Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used
Outside Temperature Sensor	6415	9W BK	1A	721	7A	721	5	7W GY	7225	Outside Temperature Sensor Display (Model A)
Outside Temperature Sensor	6415	9W BK	2A	722	1B	722	6	7W GY	7225	Outside Temperature Sensor Display (Model A)
Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used
Right Indicator On Mirror	6415	9W BK	5A	2345	4B	2345	7B	13W BK	CEC	Right Indicator Output
							1A	13W GY	IC23C	Rear Indicator Output
							7A	13W GY	IC20E	Right Indicator
							10	20W BK	0004	Right Indicator LED
Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Rear (Rear Lamp)					IC23B 13W BR	Dashboard				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
Boot Lamp (Model A)	3105A	1W BK	1	B15B	1A	B154	2	F14	IPRFB	F14 Output
Rear Roof Lamp	3020	3W BR	2	B15A			2A	13W BK	IC21	Roof Lamp Power
Reverse Gear Left Lamp	2630	6W BR	3	220			2	2W WI	3110	Glove Box Lamp Switch
Reverse Sensor Unit	2220	4W WI	1				3B	13W BK	IC21	Map Reading Lamp Power
Reverse Gear Right Lamp	2635	6W BR	4	221	2A	220	1A	13W WI	IC20A	Reverse Gear Switch
Boot Lamp Power (Model B)	3105A	1W VBK	1	B15B			3A	B155	2	F26
Rear Left Fog Lamp	2630	6W BR	4	202	5A	202	2	F22	IPFRB	F22 Power
Rear Right Fog Lamp	2635	6W BR	3	203			6A	301	2	F18
Rear Roof Lamp	3020	3W BR	1	301	6208	6208			2	5W
Fuel Lock Motor Unlock	6265	2W WI	2	6208			5	5W	6236B	Central Lock Relay Output (Model B)
RL Door Unlock	IC32	9W BR	4A				3A	13W BK	IC24A	Doors Unlock
RR Door Unlock	IC33	9W BR	4A	3A			13W BK	IC22A	FLH Unlock	
Fuel Lock Motor Lock	6265	2W WI	1	6218	1B	6218	5A	13W BK	IC24A	FR Door Lock
RL Door Lock	IC32	9W BR	5A				5A	13W BK	IC22A	FL Door Lock
RR Door Lock	IC33	9W BR	5A	8616	2B	8616	2	5W	6236A	Central Lock Relay Output (Model A)
Trunk Switch Output	3100	2W BR	1				5W	6236A	Central Lock Relay Output (Model B)	
Hand Brake Switch	4400	2W BR	1	440	4B	9W GY	IC20F	Brake Fluid Level/Hand Brake LED		
Third Stop Lamp	2110	2W BR	2	210	4B	216	2	2W WI	2100	Stop Lamp Switch
Rear Left Stop Lamp	2630	6W BR	5				441	14	20W BK	0004
Rear Right Stop Lamp	2635	6W BR	2	703	5B	703	3B	9W BR	IC20K	Rear Right ABS Sensor
Rear Right ABS Sensor	7015	2W BK	1				7031	4B	9W BR	IC20K
Rear Right ABS Sensor	7015	2W BK	2	7031	6B	7031	4B	9W BR	IC20K	Rear Right ABS Sensor
Ground	E027			M841	7B	M841	8	8W BK	8410	Radio Ground
Rear (Rear Lamp)					IC23C 13W GY	Dashboard				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
Rear Right Indicator	2635	6W BR	5	2343	1A	2343	7B	13W BK	CEC	Right Indicator Output
							7A	13W GY	IC20E	Right Indicator
							4B	13W GY	IC24B	Right Indicator On Mirror
							10	20W BK	0004	Right Indicator LED
Rear Right Side Lamp	2635	6W BR	1	V04	2A	V04	2	F6	IPFRB	F6 Output (Side Lamp Command) (Model A)
Rear Right Speaker	8435	2W WI	1	848	3A	848	2	8W WI	8410	Rear Right Speaker
Rear Right Speaker	8435	2W WI	2	847	5A	847	1	8W WI	8410	Rear Right Speaker
Not Used	2220	4W WI	2	226	6A					Not Used
Reverse Sensor Unit	2220	4W WI	3	227	7A	227	16	40W WI	CEC	Reverse Sensor Input
Boot Lock Motor	6260	2W BR	2	6206	1B	6206	2	5W	6233	Boot Lid Relay Output (Model A)
Fuel Pump Power	4310	6W BK	3	121	2B	121	7B	13W GY	IC20E	Boot Lid Relay Output (Model B)
Fuel Tank Level	4310	6W BK	1	430	3B	430	1A	13W BR	IC20G	Fuel Pump Power
Fuel Guage GND From ECU (Model A)	4310	6W BK	6	E03	4B	430	5	8W BK	0004	Fuel Tank Level (Model A)
Driver Seat Belt Switch	4730	2W WI	2	475	5B	475	18	20W BK	0004	Fuel Tank Level (Model B)
							6B	13W GY	IC20E	Fuel Guage GND From ECU (Model A)
							24	40W WI	CEC	Driver Seat Belt Switch
RL Window Up	IC33	9W BR	1B	618	6B	618	3B	13W GY	IC22B	Rear Window Winder Switch On Driver Side
RL Window Down	IC33	9W BR	2B	619	7B	619	7A	13W GY	IC22B	Rear Window Winder Switch On Driver Side

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)


Air Condition					IC26A 11W WI	Dashboard (Only For Model A)				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
Blower Motor Power	8050		1		1A	803	2	5W	8048	Blower Relay Output
Air condition Relay	80158		1							
Actuator Power	8025		8		2A	C05	2	F8	IPFRB	Switch (+) Step 2
							15	16W BK	0004	Instrument Panel Power
							5B	9W BR	IC20K	ABS Unit Power
							1	16W BK	C001	OBD Connector
							4	8W BK	8208	Immobilizer Unit Power
Air Inlet Flap Motor	8070		2				11	40W WI	CEC	CEC Power
Blower Control Ground	8047		5		4A	M805	5A	13W WI	IC20A	ECU (+) Switch Step 2 , Start
Blower Relay B Ground	8015B		3				1B	11W WI	IC26A	Ventilation Relays & Motors Power
CCU Ground	8025		5		5A	M80	E020			Ground
							2A	13W BK	CEC	CEC Ground
							3	5W	8048	Blower Relay Ground
							5A	13W BK	IC21	Roof & Map Reading Lamp Ground
							5	5W	6236B	Central Lock Relay Ground
Evaporator Sensor Ground	8006		1		5A	M80	E020A			Ground
							4	16W BK	0001	OBD Connector Ground
							5	16W BK	0001	OBD Connector Ground
							3B	9W BR	1810B	Petrol/CNG Switch Ground
							5B	9W BR	1810B	Petrol/CNG Switch Ground
A/C AMP Ground	8035		7		5A	M80	2	2W BR	3115	Glove Box Lamp Ground
							2	7W GY	7225	Digital Clock Ground
							3B	9W GY	2300	Hazard Switch Ground
							4B	9W GY	2300	Hazard Switch Ground
							1A	9W GY	2300	Screen Heater Switch Ground
HVAC Panel Backlight	8025		10		6A	V19T	3B	9W BR	8110	Screen Heater Switch Ground
							3	20W BK	0004	Instrument Panel
							3B	9W BK	6215	Hazard Switch Ground
							1B	9W BK	IC20B	HVAC & Evaporator Sensor Ground
							2	F5	IPFRFB	F5 Output
A/C AMP Power	8035		1		1B	C232	6	8W BK	8410	Radio Backlight
							6	40W WI	CEC	Side Lamp Button
							2B	13W GY	IC22B	Isolator Switch Backlight (Rear Window Winder Switch Lock)
							1A	13W GY	IC25A	Right Mirror Switch Backlight
							1B	9W GY	2300	Hazard Mirror Switch Backlight
A/C Relay Power	8015		1		1B	C232	2B	9W BK	6215	Boot Lid Switch Backlight
							2B	9W BR	8110	Rear Screen Heater Switch Backlight
							4	7W GY	7225	Digital Clock Backlight
							2B	9W BK	6220	Master Lock Switch Backlight
							2B	9W BR	1810B	CNG Switch Backlight
A/C Relay Power	8015		5		1B	C232	10	16W BK	0004	Side Lamp LED
							2	F8	IPFRFB	Switch (+) Step 2
							15	16W BK	0004	Instrument Panel Power
							5B	9W BR	IC20K	ABS Unit Power
							1	16W BK	C001	OBD Connector
A/C Power	8025		3		2B	VR2	4	8W BK	8208	Immobilizer Unit Power
							11	40W WI	CEC	CEC Power
							5A	13W WI	IC20A	ECU (+) Switch Step 2 , Start
							2A	11W WI	IC26A	Ventilation Relays & Motors Power
							2	F5	IPFRFB	F5 Output
AC Relay A Output	8015A		3		3B	8054	1B	13W BR	IC20G	AC Request
AC Out	8025		2		4B	8053	5B	9W BK	IC20B	Not Used
AC Relay A (+)	8015A		2							Not Used
Not Used										Not Used
Not Used										Not Used
Air Condition					IC26A 13W BK	Dashboard (Only For Model B) For Vehicle With MFC				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function
Blower Relay (A) (Ignition)	8048A	5W	1		1A	803A	5	5 W	8048	
Blower Relay (A) (Ignition)	8048A	5W	5				7B	13W BK	IC26A	
Blower Relay (B) (Ignition)	8048B	5W	1							
Not Used					2A	8054	1B	13W BR	IC20G	AC Request
Mixing Flap Motor	8065	7W BK	4	8048	3A	8046	33	40W GY	8025	AC Request
Mixing Flap Motor	8065	7W BK	5	8049	5A	8049	9	40W GY	8025	Airmix Potential Signal
Blower Relay (A) Ground	8048A	5W	2				1		E020	
Blower Control Module Ground	8045	3W BK	1		6A	M051	7A	13W GY	IC26B	
Blower Relay (B) Ground	8048B	5W	3							
Evaporator Sensor Ground	8006	2W BK	2	E803	7A	E804	2A	13W WI	IC20A	Exterior Thermistor Ground
							2	2W BK	8033	Sun Sensor Ground
							6	6W BK	8031	Coolant Thermistor Ground
							4B	13W WI	IC20A	Engine Coolant Thermistor (For HVAC) Ground
							3A	40W GY	8025	Sensors Ground
Blower Speed Control	8040	7W BK	1	8040	1B	8040	1	40W GY	8025	Mode M/A Limiting Signal
Blower Speed Control	8040	7W BK	2	8041	2B	8041	21	40W GY	8025	Mode M/A Out1
Blower Speed Control	8040	7W BK	4	8042	3B	8042	32	40W GY	8025	Mode M/A Out2
Blower Speed Control	8040	7W BK	5	8043	4B	8043	8	40W GY	8025	Mode M/A Potential Signal
Blower Speed Control	8040	7W BK	6	8044	5B	8044	29	40W GY	8025	M/A 5V
Mixing Flap Motor	8065	7W BK	6							
Blower Speed Control	8040	7W BK	7	8045	6B	8045	28	40W GY	8025	M/A Ground
Mixing Flap Motor	8065	7W BK	7							
Not Used					7B	803B	5	5W	8048	
Not Used							1A	13W BK	IC26A	

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Air Condition					IC26A 13W BK				Dashboard (Only For Model B) For Vehicle With Out MFC				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function			
Blower Relay (A) (Ignition)	8048A	5W	1		8032	1A	8031	5	5W	8048	Blower Relay Output		
Blower Relay (A) (Ignition)	8048A	5W	5										
Blower Relay (B) (Ignition)	8048B	5W	1										
Not Used					2A	8054	1B	13W BR	IC20G	AC Request			
Mixing Flap Motor	8065	7W BK	4	8048	3A	8048	33	40W GY	8025	Airmix M/A Out2			
Mixing Flap Motor	8065	7W BK	5	8049	5A	8049	9	40W GY	8025	Airmix Potential Signal			
Blower Relay (A) Ground	8048A	5W	2		E804	6A	M805	E020			Ground		
Blower Control Module Ground	8045	3W BK	1										
Blower Relay (B) Ground	8048B	5W	3	E805									
Evaporator Sensor Ground	8006	2W BK	2	E803	7A	E804	2A	13W WI	IC20A	Exterior Thermistor Ground			
							2	2W BK	8033	Sun Sensor Ground			
							6	6W BK	8031	Coolant Thermistor Ground			
							4B	13W WI	IC20A	Engine Coolant Thermistor (For HVAC) Ground			
							34	40W GY	8025	Sensors Ground			
Blower Speed Control	8040	7W BK	1	8040	1B	8040	1	40W GY	8025	Mode M/A Limiting Signal			
Blower Speed Control	8040	7W BK	2	8041	2B	8041	21	40W GY	8025	Mode M/A Out1			
Blower Speed Control	8040	7W BK	4	8042	3B	8042	32	40W GY	8025	Mode M/A Out2			
Blower Speed Control	8040	7W BK	5	8043	4B	8043	8	40W GY	8025	Mode M/A Potential Signal			
Blower Speed Control	8040	7W BK	6	8044	5B	8044	29	40W GY	8025	M/A 5V			
Mixing Flap Motor	8065	7W BK	6										
Blower Speed Control	8040	7W BK	7	8045	6B	8045	28	40W GY	8025	M/A Ground			
Mixing Flap Motor	8065	7W BK	7										
Not Used					7B								
Air Condition					IC26B 13W GY				Dashboard (Only For Model B) For Vehicle With MFC				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function			
Air Inlet Flap Control	8067	7W BK	5	8026	1A	8026	2	40W GY	8025	Intake M/A Out2			
Air Inlet Flap Control	8067	7W BK	4	8027	2A	8027	22	40W GY	8025	Intake M/A Out1			
Air Inlet Flap Control	8067	7W BK	2	8028	3A	8028	23	40W GY	8025	Intake M/A 12V			
Mixing Flap Motor	8065	7W BK	2	8046	5A	8046	3	40W GY	8025	Airmix M/A Out1			
Mixing Flap Motor	8065	7W BK	1	8047	6A	8047	4	40W GY	8025	Airmix M/A Limiting Signal			
Not Used					7A	M052	1	E020					
Not Used					1B	8038	38	40W GY	8025	CCU AC Out			
Blower Relay (B)	8048B	5W	2	8039	2B	8039	7	40W GY	8025	Blower High Relay			
Evaporator Sensor	8006	2W BK	1	8021	3B	8021	13	40W GY	8025	Evaporator Sensor			
Blower Relay (A)	8048A	5W	3		4B	8022	15	40W GY	8025	Blower Voltage			
Blower Motor	8050	2W	1		5B	8023	16	40W GY	8025	Blower Output			
Blower Control Module	8045	3W BK	3	8023	6B	8024	17	40W GY	8025	Blower Feedback			
Blower Motor	8050	2W	2										
Blower Control Module	8045	3W BK	2	8024									
Blower Relay (B)	8048B	5W	5										
Not Used					7B					Not Used			
Air Condition					IC26B 13W GY				Dashboard (Only For Model B) For Vehicle With Out MFC				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function			
Air Inlet Flap Control	8067	7W BK	5	8026	1A	8026	2	40W GY	8025	Intake M/A Out2			
Air Inlet Flap Control	8067	7W BK	4	8027	2A	8027	22	40W GY	8025	Intake M/A Out1			
Air Inlet Flap Control	8067	7W BK	2	8028	3A	8028	23	40W GY	8025	Intake M/A 12V			
Mixing Flap Motor	8065	7W BK	2	8046	5A	8046	3	40W GY	8025	Airmix M/A Out1			
Mixing Flap Motor	8065	7W BK	1	8047	6A	8047	4	40W GY	8025	Airmix M/A Limiting Signal			
Not Used					7A					Not Used			
Not Used					1B	8038	38	40W GY	8025	CCU AC Out			
Blower Relay (B)	8048B	5W	2	8039	2B	8039	7	40W GY	8025	Blower High Relay			
Evaporator Sensor	8006	2W BK	1	8021	3B	8021	13	40W GY	8025	Evaporator Sensor			
Blower Relay (A)	8048A	5W	3		4B	8022	15	40W GY	8025	Blower Voltage			
Blower Motor	8050	2W	1		5B	8023	16	40W GY	8025	Blower Output			
Blower Control Module	8045	3W BK	3	8023	6B	8024	17	40W GY	8025	Blower Feedback			
Blower Motor	8050	2W	2										
Blower Control Module	8045	3W BK	2										
Blower Relay (B)	8048B	5W	5		M86	4B	M86	2	2W GY	4702	RL Door Switch		
RL Lamps Ground	2630	6W BR	1										
Ground		E026G											
Reverse Sensor Unit Ground	2220	4W WI	4										
FR-RL-RR Door Switch Input	IC23A	13W BK	B2	8613	5B	8613	1	2W GY	4702	RL Door Switch			

Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Rear (Rear Lamp)					IC33 9W BR		Rear Right Door				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
Rear Left Window Switch Power	IC32	9W BR	1A	6112	1A	6111	1A	5W WI	6115	Rear Right Window Switch Power	
Rear window washer relay (if separate switch Output)	IC23A	13W BK	A6								
Not Used					2A		Not Used				
Fuel Lock Motor Unlock	6265	2W WI	2	6204	4A	6203	1	2W BR	6255	RR Door Unlock	
RL Door Unlock	IC32	9W BR	4A								
Central Lock Relay Output	IC23B	13W BR	7A								
Fuel Lock Motor Lock	6265	2W WI	1	6214	5A	6213	2	2W BR	6255	RR Door Lock	
RL Door Lock	IC32	9W BR	5A								
Central Lock Relay Output	IC23B	13W BR	1B								
RR Window Up	IC23C	13W GY	6B	618	1B	612	3A	5W WI	6115	RR Window Up	
RR Window Down	IC23C	13W GY	7B	619	2B	613	1B	5W WI	6115	RR Window Down	
Not Used					3B		Not Used				
Fuel Pump Ground (Model B)	4310	6W BK	6	M861	4B	M86	2	2W GY	4703	RR Door Switch	
Hand Brake Switch Ground	4400	2W BR	2								
Fuel Pump Ground	4310	6W BK	4								
Driver Seat Belt Switch Ground	4730	2W WI	1								
Ground	EC26D										
Rear Right Lamps Ground	2635	6W BR	6								
Boot Lock Motor Ground	6260	2W BR	1								
FR-RL-RR Door Switch Input	IC23A	13W BK	B2								
Not Used					5B		8613 1 2W GY 4703 RR Door Switch				
Dashboard					IC20 8W WI		Steering Wheel				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
	8410E	20W RD	8	C8	1	C8	1	8W WI	MFC	Audio Keys (+)	
Horn	IC20E	13W GY	1B	252	2	E252	2	8W WI	MFC (CT00)	Horn & Audio Keys Ground	
	0004A	16W BK	7	B07	3	252	3	8W WI	MFC (CT00)	Horn	
	IPFB	F27	2								
	5005	5W	1								
	ECCR	5W	1								
	6020	5W	1								
	6233	5W	1								
	6236A	5W	1								
	6236B	5W	1								
	6125	5W	1								
Not Used					4		Not Used				
Not Used					5		Not Used				
	8410A	8W BK	6	V841	6	V19	6	8W WI	MFC (CT00)	Illumination(+)	
	8410C	18W BK	6								
	8025	40W GY	35								
	3053	1W BK	1								
	0004A	16W BK	10								
	IPFB	F5	2								
	IC22B	13W GY	2B								
	CECB1	20W BR	6								
	0004A	16W BK	9								
	0004A	16W BK	8								
	8410C	18W BK	18								
	8031	6W BK	2								
	8410C	18W BK	10								
	0004A	16W BK	16								
	8410E	20W RD	11								
	8410C	18W BK	18								
	8100	3W BK	3								
	1466	8W BK	2								
	IC24A	13W BK	2B								
	M020										
	6570	50W GR	6								
	8025	40W GY	24								
	8025	40W GY	36								
Not Used					7		E252 7 8W WI MFC (CT00) Illumination Ground				
Not Used					8		Not Used				



Interconnector – PARS CEC XU7 (Model A: 1Airbag/Manual HVAC Model B: 2Airbag/Automatic HVAC)

Dashboard					IC20 8W WI اگر اتویس داشته باشید اتویس B بود		Steering Wheel				
Function	Part	Connector	Pin Num	Wire Num	Interconnector Pin Num	Wire Num	Pin Num	Connector	Part	Function	
	8410E	20W RD	8	C8	1	C8	1	8W WI	MFC	Audio Keys (+)	
	0004A	18W BK	9								
	0004A	16W BK	8								
	8410E	20W RD	11								
	8031	6W BK	2				2	8W WI	MFC (CT00)	Horn & Audio Keys Ground	
	8410C	18W BK	10								
	0004A	18W BK	16								
	IC20	8W WI	1								
	8410C	18W BK	18	M7	2	E252					
	8100	3W BK	3								
	1466	8W BK	2								
	IC24A	13W BK	2B								
		M020									
	6570	50W GR	6								
	8025	40W GY	24								
	8025	40W GY	36								
Horn	CECB1	20W BR	18	252	3	252	3	8W WI	MFC (CT00)	Horn	
	Not Used				4	Not Used				Not Used	
	Not Used				5	Not Used				Not Used	
	8410A	8W BK	6								
	8410C	18W BK	6								
	8025	40W GY	35								
	3053	1W BK	1								
	0004A	16W BK	10	V841	6	V19	6	8W WI	MFC (CT00)	illumination(+)	
	IPFB	F5	2								
	IC22B	13W GY	2B								
	CECB1	20W BR	6								
	0004A	18W BK	9								
	0004A	16W BK	8								
	IC20	8W WI	2								
	8410E	20W RD	11								
	8031	6W BK	2				2	8W WI	MFC (CT00)	Horn & Audio Keys Ground	
	8410C	18W BK	10								
	0004A	18W BK	16								
	8410C	18W BK	18	M8	7	E252					
	8100	3W BK	3								
	1466	8W BK	2								
	IC24A	13W BK	2B								
		M020									
	6570	50W GR	6								
	8025	40W GY	24								
	8025	40W GY	36								
	Not Used				8	Not Used				Not Used	