




### Power Steering (Without Brake Central Unit Supply Relay)

BSI1



### Power Steering (Without Brake Central Unit Supply Relay)



## Power Steering (Without Brake Central Unit Supply Relay)

item code	description	information
7125	null	power steering power relay
7126	null	electric power steering ECU /
7800	null	calculateur controle de stabilite
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
E900A	null	crimp one information (or equipotential 276A) wire
E900B	null	crimp one information (or equipotential 900B) wire
E901A	null	crimp one information (or equipotential 901A) wire
E901B	null	crimp one information (or equipotential 901B) wire
EC03A	null	splice of an "ignition +" protected by fuse no. 03A
EM10B	null	crimp earth (earth point number 10B)
MC10A	null	body earth point number 10A
MC13	null	body earth point number 13
MC71B	null	body earth point number 71
MM01	null	engine earth point number 01

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در کشور

