


Start system (CVT)



Harness connector	Name	Page
M36	Ignition switch - main body harness connector	13
ME2	Main harness to engine Harness connector 2	25
EM2	Engine to Main harness connector 2	17
EC2	Engine control harness to main harness connector 2	16
A9	Engine harness to control harness 1	22
A10	Engine harness to control harness 2	22
A24	Engine control unit to main harness connector	22
EB1	Engine harness to power harness connector	16
BE1	Power harness to engine harness	13
B02	Starter Harness connector	13
B03	Start coil harness connector	13
B07	Battery positive harness connector	13
G01	Ground	59
G02	Ground	59

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

