



PEPS




Connector	Name	Page
D08	FL Handle SNR	29
F01	BCMC2	25
F20	Standby ANT	26
F30	Third Row PEPS ANT	25
F42	MID PEPS ANT	25
M09	BCM C4	20
M10	BCM C5	20
M33	Front PEPS ANT	21
P04	Rear PEPS ANT	36
G12	Body W.H. GND 1(terminal 1)	42
I1_BRPA	Body W.H. Connector 1 Connecting Reversing Radar W.H.	25
I1_RPAB	Reversing Radar W.H.Connector1 Connecting Body W.H.	36
I3_BM	Body W.H. Connector 3 Connecting Main W.H.	25
I3_MB	Main W.H. Connector 3 Connecting Body W.H.	21
I5_BM	Body W.H. Connector 5 Connecting Main W.H.	27
I5_MB	Main W.H. Connector 5 Connecting Body W.H.	20
I6_BM	Body W.H. Connector 6 Connecting Main W.H.	27
I6_MB	Main W.H. Connector 6 Connecting Body W.H.	20
I_BFLD	Body W.H. Connector Connecting FL Door W.H.	25
I_FLDB	FL Door W.H. Connector Connecting Body W.H.	29

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


D08 FL Handle SNR




F01 BCM C2




F20 Standby ANT




I_BFLD Body W.H. Connector Connecting FL Door W.H.




F30 Third Row PEPS ANT



I_FLDB FL Door W.H. Connector Connecting Body W.H.




F42 MID PEPS ANT




G12Body W.H. GND 1




I1_RPAB Reversing Radar W.H.Connector1 Connecting Body W.H.




I1_BRPA Body W.H. Connector 1 Connecting Reversing Radar W.H.




I3_BM Body W.H. Connector 3
Connecting Main W.H.




I3_MB Main W.H. Connector 3
Connecting Body W.H.




I5_BM Body W.H. Connector 5
Connecting Main W.H.




I5_MB Main W.H. Connector 5
Connecting Body W.H.




I6_BM Body W.H. Connector 6
Connecting Main W.H.




I6_MB
Main W.H. Connector 6
Connecting Body W.H.




M09 BCM C4



M10 BCM C5



M33 Front PEPS ANT



P04 Rear PEPS ANT

