




Circuit Diagram



Circuit Diagram





Circuit Diagram

Electric glass lifting - 5		R-5
Component location index		
Component code	Component name	
D06	Master switch for front left glass lifting control	
D03	Front left glass lifting motor	
D26	Front right glass lifting switch	
D23	Front right glass lifting motor	
D33-1	Rear left glass lifting switch	
D32-1	Rear left glass lifting motor	
D33-2	Rear right glass lifting switch	
D32-2	Rear right glass lifting motor	
Connector		
PFA		
PFB		
PEE		
PMH		
DF1		
DF3		
FD2		
FD4		
GND		
F04		
F36		

