


Step light (Executive Edition)



Harness connector	Name	Pages
C01	Rear Connector of Indoor Fuse Box	17
IP05	To harness connector of indoor fuse box	80
IP11	To body harness connector	80
SO02	To instrument harness connector	97
SO05	To front right door harness connector	97
SO07	To front left door harness connector	97
SO73	Harness connector of driver side step light	99
SO74	Harness connector of passenger side step light	99
SO75	Harness connector of rear left side step light	99
SO76	Harness connector of rear right side step light	99
SO14	To rear right door harness connector	97
SO27	To rear left door harness connector	97
DR21	RL door connecting to body harness connector	118
DR26	Harness connector of RL door lock motor	118
DR31	RR door connecting to body harness connector	118
DR36	Harness connector of RR door lock motor	118
DR11	Front right door connected to body harness connector	114
DR01	Front left door connected to body harness connector	114
DR06	Harness connector of front left door lock motor	114
DR16	Harness connector of FR door lock motor	114

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران