


21. CLUSTER


- 1) METER (TACHO, SPEED, TEMPERATURE, FUEL), FUEL WARNING LAMP, WINTER LAMP, POWER LAMP



a. CONNECTOR INFORMATION


CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G201	Main	Above Driver Seat Leg Room
G401	Trunk	Left Side Panel of Trunk

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS


• W/H ENGINE ROOM




EBCM




ECM



TCM




CLUSTER




FUEL SENSOR


• W/H MAIN : FRONT



ECM
(BOSCH, VDO)




C113




C204



G201



C206
C207
C208




TCM
(WSA300, BTRA)

C210


• W/H FLOOR : TRUNK

• W/H INSTRUMENT PANEL




CLUSTER
C204
C206
C207
C208

G401




FUEL SENSOR



C401


2) A/T SELECT LEVER INDICATOR, TRIP SWITCH, WASHER LEVEL SENSOR, WATER LEVEL SENSOR, OIL LEVEL SWITCH, OVER SPEED WARNING, BRAKE PAD WEAR SENSOR



a. CONNECTOR INFORMATION

CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G101	Engine Room	Behind Left Head Lamp
G201	Main	Above Driver Seat Leg Room


b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS




• W/H ENGINE ROOM




• W/H MAIN : FRONT




• W/H INSTRUMENT PANEL



• W/H FLOOR : TRUNK




3) WARNING LAMP (BRAKE, CHARGING, SPORT, ECS, ABS, AIR BAG, ASR/ ABD), INDICATOR (REAR FOG LAMP)



a. CONNECTOR INFORMATION




CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G101	Engine Room	Behind Left Head Lamp
G201	Main	Above Driver Seat Leg Room

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS


- W/H ENGINE ROOM




- W/H MAIN : FRONT



- W/H INSTRUMENT PANEL



- W/H FLOOR : CO-DRIVER SEAT




WARNING LAMP, ILLUMINATION




C. POSITION OF CONNECTORS AND GROUNDS


ELRICS




STICS




CLUSTER



• W/H MAIN : FRONT



• W/H INSTRUMENT PANEL



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران