





2) P.C. BUPPER PART (Ef1~Ef 36, Relay Pin Number)




2. ENGINE ROOM FUSE & RELAY BOX CIRCUIT


1) SLOW BLOW FUSE (SB A, SB 1~SB 9)








3-8 FUSE BOX & ELECTRICAL WIRING DIAGRAM



(CONVENTIONAL TYPE)



3-10 FUSE BOX & ELECTRICAL WIRING DIAGRAM

(CONVENTIONAL TYPE)

