



CONNECTOR NUMBER	CONNECTING WIRING HARNESS	CONNECTOR POSITION
G202	Main	Below Center Console Box

[illegible][illegible]


C. POSITION OF CONNECTORS AND GROUNDS




• W/H ENGINE ROOM




• W/H MAIN : FRONT



• W/H INSTRUMENT PANEL



• W/H MAIN : LEFT FLOOR



• W/H FLOOR : CO-DRIVER SEAT

